



## Other Profile

- [ThousandEyes, on page 1](#)
- [UCSE, on page 3](#)

## ThousandEyes

Cisco ThousandEyes is a SaaS application that provides you an end-to-end view across networks and services that impact your business. It monitors the network traffic paths across internal, external, and carrier networks and the internet in real time to provide network performance data. Cisco ThousandEyes provides intelligent insights into your WAN and the cloud and helps you optimize application delivery and end-user experience.

For each parameter of the feature that has a default value, the scope is set to Default (indicated by a check mark), and the default setting or value is shown. To change the default or to enter a value, click the scope drop-down to the left of the parameter field and choose one of the following:

Parameter Scope	Scope Description
Device Specific (indicated by a host icon)	<p>Use a device-specific value for the parameter. For device-specific parameters, you cannot enter a value in the feature template. You enter the value when you attach a Cisco Catalyst SD-WAN device to a device template.</p> <p>When you click Device Specific, the Enter Key box opens. This box displays a key, which is a unique string that identifies the parameter in a CSV file that you create. This file is an Excel spreadsheet that contains one column for each key. The header row contains the key names (one key per column), and each row after that corresponds to a device and defines the values of the keys for that device. You upload the CSV file when you attach a Cisco Catalyst SD-WAN device to a device template.</p> <p>To change the default key, type a new string and move the cursor out of the Enter Key box.</p> <p>Examples of device-specific parameters are system IP address, host name, GPS location, and site ID.</p>
Global (indicated by a globe icon)	<p>Enter a value for the parameter and apply that value to all devices.</p> <p>Examples of parameters that you might apply globally to a group of devices are DNS server, syslog server, and interface MTUs.</p>

The following table describes the options for configuring the ThousandEyes feature.

Field	Description
<b>Type</b>	Choose a feature from the drop-down list.
<b>Feature Name</b>	Enter a name for the feature.
<b>Description</b>	Enter a description of the feature. The description can contain any characters and spaces.
<b>Account Group Token</b>	Enter the Cisco ThousandEyes Account Group Token.
<b>VPN</b>	Transport or service VPN. The <b>Default</b> setting indicates transport VPN (VPN 0). The <b>Global</b> or the <b>Device Specific</b> setting indicates service VPN.  When you set the VPN configuration as a <b>Global</b> or a <b>Device Specific</b> setting, enter the ID of the service VPN in which you want to provision the Cisco ThousandEyes Enterprise agent.
<b>Management IP</b>	Enter an IP address for the Cisco ThousandEyes Enterprise agent. This field is available only when you specify the service VPN.
<b>Management Subnet</b>	Choose a subnet mask from the drop-down list for the Cisco ThousandEyes Enterprise agent. This field is available only when you specify the service VPN.  <b>Note</b> This IP-prefix address ( <b>Management IP</b> and <b>Management Subnet</b> ) must be unique within the fabric and must not overlap with the IP addresses of other branch agents.
<b>Agent Default Gateway</b>	Enter a default gateway address. This IP address is assigned to the virtual port group of the router. This field is available only when you specify the service VPN.
<b>Name Server IP</b>	Enter the IP address of your preferred DNS server.  This server can exist within or outside the Cisco Catalyst SD-WAN fabric but must be reachable from the service VPN.
<b>Host Name</b>	Enter the hostname that the agent must use when registering with the Cisco ThousandEyes portal. By default, the agent uses the hostname of the Cisco IOS XE Catalyst SD-WAN device.

Field	Description
<b>Proxy Type</b>	<p>If the Cisco ThousandEyes Enterprise agent must use proxy server for external access, choose one of the following as proxy type:</p> <ul style="list-style-type: none"> <li>• <b>static</b></li> <li>• <b>pac</b></li> <li>• <b>none</b></li> </ul> <p>Static proxy settings:</p> <ul style="list-style-type: none"> <li>• <b>Proxy Host:</b> Set the configuration as a <b>Global</b> setting and enter the hostname of the proxy server.</li> <li>• <b>Proxy Port:</b> Set the configuration as a <b>Global</b> setting and enter the port number of the proxy server.</li> </ul> <p>PAC settings:</p> <ul style="list-style-type: none"> <li>• <b>PAC URL:</b> Set the configuration as a <b>Global</b> setting and enter the URL of the proxy auto-configuration (PAC) file.</li> </ul>

## UCSE

Use the UCSE feature to connect a UCS-E interface with a UCS-E server.

Some parameters have a scope drop-down list that enables you to choose **Global**, **Device Specific**, or **Default** for the parameter value. Choose one of the following options, as described in the table below:

Parameter Scope	Scope Description
<b>Global</b> (Indicated by a globe icon)	<p>Enter a value for the parameter and apply that value to all devices.</p> <p>Examples of parameters that you might apply globally to a group of devices are DNS server, syslog server, and interface MTUs.</p>
<b>Device Specific</b> (Indicated by a host icon)	<p>Use a device-specific value for the parameter.</p> <p>Choose <b>Device Specific</b> to provide a value for the key in the <b>Enter Key</b> field. The key is a unique string that helps identify the parameter. To change the default key, type a new string in the <b>Enter Key</b> field.</p> <p>Examples of device-specific parameters are system IP address, host name, GPS location, and site ID.</p>
<b>Default</b> (indicated by a check mark)	The default value is shown for parameters that have a default setting.

The following tables describe the options for configuring the UCSE feature.

Field	Description
<b>Type</b>	Choose a feature from the drop-down list.

Field	Description
<b>Feature Name*</b>	Enter a name for the feature. The name can be up to 128 characters and can contain only alphanumeric characters.
<b>Description</b>	Enter a description of the feature. The description can be up to 2048 characters and can contain only alphanumeric characters.

### Basic Configuration

Field	Description
<b>Bay*</b>	Specify the number for the SAS drive bays. The input value must be an integer.
<b>Slot*</b>	Specify the slot numbers for the mezzanine adapters. The input value must be an integer.

### IMC

Field	Description
<b>Access Port</b>	Configure the interface as an access port. You can configure only one VLAN on an access port, and the port can carry traffic for only one VLAN.  Not all hardware models have a dedicated access port. See the release notes for your Cisco Catalyst SD-WAN release for the supported hardware.  Available options: <ul style="list-style-type: none"> <li>• <b>Dedicated</b></li> <li>• <b>Shared</b></li> </ul> Configure the appropriate port (GE or TE) based on the hardware module.
<b>IPv4 Address*</b>	Provide the UCS-E management port address.
<b>Default Gateway*</b>	Gateway tracking determine, for static routes, whether the next hop is reachable before adding that route to the device's route table.  Default: Enabled.
<b>VLAN ID</b>	Provide the VLAN number, which can be a value from 1 through 4094.
<b>Assign Priority</b>	Assign the priority.

### Advanced

Field	Description
<b>Interface Name*</b>	Specify the name of the interface.
<b>Layer</b>	Specify the layer details necessary for traffic exchange between different VLANs.

Field	Description
<b>UCSE Interface VPN</b>	Specify the details of the UCS-E interface VPN.
<b>IPv4 Address</b>	Provide the UCS-E management port address.

