



Cisco UCS Server Configuration Utility User Guide, Release 7.1

First Published: 2024-12-19

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

CHAPTER 1	Overview	1
	Introduction	1
	Supported Platforms and Operating Systems	1
	Hardware Requirements	1

CHAPTER 2	Launching UCS Server Configuration Utility	3
	Introduction	3
	Obtaining ISO Image From cisco.com	3
	Booting UCS-SCU	4
	Using vKVM Mapped vDVD	4
	Using Cisco FlexMMC vDVD	5
	Using CIMC Mapped vDVD	8
	Using Physical Media	9
	Using Network Boot Support	9
	Exiting UCS-SCU	10

CHAPTER 3	Understanding UCS Server Configuration Utility User Interface	13
	Introduction	13
	License Agreement	13
	UCS-SCU GUI Home Page	13
	Navigation Pane	14
	Toolbar	15

CHAPTER 4	Installing Operating Systems	17
	Introduction	17
	Installing Linux Server Operating System	18

Installing Windows Server Operating System 20

Installing ESXi 23

 Selecting a Installation Disk 24

 Network Settings 24

CHAPTER 5

Viewing Chassis 25

 Viewing Server Health 25

 Viewing General Details 26

 Viewing CPU Details 27

 Viewing Memory Details 28

 Viewing PCI Details 29

 Viewing Network Details 29

 Viewing Graphics Details 30

 Viewing Storage Details 30

 Viewing Power Supply Details 32

CHAPTER 6

Viewing Task Summary 33

 Viewing Task Summary 33

CHAPTER 7

Non Interactive Operating System Installation 35

 Non Interactive Operating System Installation 35

 Support for Network Boot from PXE, iPXE, HTTP and HTTPS 36

 Modifying the nwboot.cfg File 36

 Modifying the niscu.cfg File 43

 Modifying conf_file 50

 Running the Python Script to Start OS Deployment 53

 Installing Operating Systems Using Commands 53

 Sample nwboot.cfg file 57

 Sample conf_file and niscu.cfg files 59

CHAPTER 8

Configuring RAID Levels 61

 RAID Configuration 61

 Storage Configuration 61

 Physical Disks Area 62

Logical Disks Area	63
Creating RAID Arrays	63
Configuring Single-Level RAID	63
Configuring Nested RAID	64



CHAPTER 1

Overview

- [Introduction, on page 1](#)
- [Supported Platforms and Operating Systems, on page 1](#)
- [Hardware Requirements, on page 1](#)

Introduction

The Cisco UCS Server Configuration Utility (SCU) is an application that helps you manage Operating System installation on your server. The utility helps you easily set up the OS from a single application.

Using the SCU, you can install and support an operating system and its associated drivers on a specific server.

Beginning with Release 6.3, you can install Cisco UCS Server Configuration Utility ISO boot through network like HTTP/HTTPS, PXE and iPXE along with the existing vMedia boot medium. For more information on the different network boot options, see [Support for Network Boot from PXE, iPXE, HTTP and HTTPS, on page 36](#).

Beginning with Release 7.1(1.240100), options provided by Cisco UCS Server Configuration Utility are changed. For more information, refer [Understanding UCS Server Configuration Utility User Interface, on page 13](#).

Supported Platforms and Operating Systems

Supported Platforms and Operating Systems

For details on supported platforms and operating systems, see [Intersight OS Install Overview documentation](#) when using SCU with Intersight OS installation or the associated *Release Notes for Cisco UCS Server Configuration Utility* when using SCU as a standalone utility.

Hardware Requirements

The following are the minimum hardware requirements for UCS-SCU:

- CD-ROM drive—A USB CD/DVD-ROM drive is required to be able to boot and run the UCS-SCU. You can also use the virtual media option in the CMC KVM, CIMC vMedia to boot UCS-SCU.

- Mouse—Some functions require a standard mouse (PS/2 or USB) for navigation.
- RAM—A minimum of 4 GB RAM. If the available RAM is less than the minimum recommended value, UCS-SCU will not function properly.
- Network adapter—Some optional functions, such as, downloading the OS drivers from support.cisco.com, require network access. Any single onboard NIC adapter connection is supported.



Note RAID Cards—RAID configuration and OS installation are supported on selected controllers.



CHAPTER 2

Launching UCS Server Configuration Utility

- [Introduction](#), on page 3
- [Obtaining ISO Image From cisco.com](#), on page 3
- [Booting UCS-SCU](#), on page 4
- [Exiting UCS-SCU](#), on page 10

Introduction

UCS Server Configuration Utility (SCU) is a bootable image based on a 64-bit Linux kernel and can be used to perform operations such as configure RAID logical volume, install operating systems on Cisco rack servers. It is designed to run on one server at a time.

Obtaining ISO Image From cisco.com

Perform this procedure to find the ISO file for your server.

Before you begin

You must have valid Cisco login credentials to perform this procedure.

Procedure

Step 1 Go to [Software Download](#).

Note

Log in using your Cisco credentials.

Step 2 Click **Select a Product > Browse All**.

Step 3 Click **Servers - Unified Computing** in the first column.

Step 4 Click **Cisco UCS C-Series Rack-Mount Standalone Server Software** in the middle column.

Step 5 Click the name of your server model from the last column.

A new page is displayed with the list of available software.

Step 6 Under **Select a Software Type** list, select **Unified Computing System (UCS) Server Configuration Utility**.

The Download Software page appears listing the release version and the UCS-SCU image.

- Step 7** Select the desired release from the left pane.
- Step 8** Click the **Download** icon on the right pane.
- Step 9** Continue through the subsequent screens to accept the license agreement and browse to a location where you want to save the ISO file.
-

Booting UCS-SCU

You can launch the UCS-SCU application using one of the following options:

- [Using vKVM Mapped vDVD, on page 4](#)
- [Using Cisco FlexMMC vDVD, on page 5](#)
- [Using CIMC Mapped vDVD, on page 8](#)
- [Using Physical Media, on page 9](#)
- [Using Network Boot Support, on page 9](#)

Using vKVM Mapped vDVD

Before you begin

Download the UCS-SCU ISO image file from cisco.com. For information on how to download the image, refer [Obtaining ISO Image From cisco.com, on page 3](#).

Procedure

Step 1 Log in to Cisco IMC.

Step 2 From top right hand menu, click **Launch KVM**.

Note

Depending on your browser settings, you may need to accept **KVM server certificate** and click the KVM viewer.

Virtual KVM Console displays the server console.

Step 3 Select **Virtual Media > vKVM-Mapped vDVD**.

The **Map Virtual Media - CD/DVD** window is displayed.

Step 4 Navigate to and select the ISO file and click Open to mount the image.

Step 5 Select **Map Drive** from the **Map Virtual Media - CD/DVD** window.

The following message is displayed in the virtual KVM console:

Successfully inserted media into device "vKVM Mapped DVD".

- Step 6** Select **Power > Power Cycle System**.
- Step 7** Press **F6** when the server starts to select a boot device.
The boot selection menu appears.
- Step 8** Use the arrow keys to select **vKVM Mapped DVD** and then press **Enter**.
The server boots using the UCS-SCU image and launches the application in the KVM tab.

Using Cisco FlexMMC vDVD

Before you begin

Download the UCS-SCU ISO image file from cisco.com. For information on how to download the image, refer [Obtaining ISO Image From cisco.com, on page 3](#).

Procedure

- Step 1** Log in to Cisco IMC.
- Step 2** In the **Navigation** pane, click the **Storage** menu.
- Step 3** In the **Storage** menu, select **Cisco FlexMMC**.
- Step 4** In the **Files Copied** area of the **Cisco FlexMMC** pane, click the **Upload Files** tab.
The **Cisco FlexMMC Upload File** dialog box is displayed.
- Step 5** In the **Cisco FlexMMC Upload File** dialog box, enter the following details:

Field	Description
Partition drop-down list	Type of partition. This can be: <ul style="list-style-type: none"> • IMC Images—Cisco .iso file. • User Files—Any .iso, image or any other file format. Only one .iso file can be uploaded. <p>Note If you choose any other file format, Cisco IMC converts the file into an image file.</p> In case of any other file format, the file size should be more than 10MB. It also takes extra space due to conversion.

Field	Description
<p>Mount Type drop-down list</p>	<p>The type of mapping. This can be one of the following:</p> <p>Note Ensure that the communication port of the mount type that you choose is enabled on the switch. For example, when you are using CIFS as your mount type, ensure port 445 (which is its communication port) is enabled on the switch. Similarly, enable ports 80 for HTTP, 443 for HTTPS and 2049 for NFS when you use them.</p> <ul style="list-style-type: none"> • NFS—Network File System. • CIFS—Common Internet File System. • WWW(HTTP/HTTPS)—HTTP-based or HTTPS-based system.
<p>Remote Share field</p>	<p>The URL of the image to be mapped. The format depends on the selected Mount Type:</p> <ul style="list-style-type: none"> • NFS—Use serverip:/share • CIFS—Use //serverip/share. • WWW(HTTP/HTTPS)—Use http[s]://serverip/share.
<p>Remote File field</p>	<p>The name and location of the .iso or .img file in the remote share.</p>

Field	Description
<p>Mount Options field</p>	<p>Industry-standard mount options entered in a comma separated list. The options vary depending on the selected Mount Type.</p> <p>If you are using NFS, leave the field blank or enter one or more of the following:</p> <ul style="list-style-type: none"> • ro • noexec • soft • port=VALUE <p>If you are using CIFS, leave the field blank or enter one or more of the following:</p> <ul style="list-style-type: none"> • ro • nounix • noserverino • port=VALUE • Ntlm—NT LAN Manager (NTLM) security protocol. Use this option only with Windows 2008 R2 and Windows 2012 R2. • vers=VALUE <p>Note The format of the VALUE should be x.x</p> <p>If you are using WWW(HTTP/HTTPS), leave the field blank or enter the following:</p> <ul style="list-style-type: none"> • noauto <p>Note Before mounting the virtual media, Cisco IMC tries to verify reachability to the end server by pinging the server.</p> <ul style="list-style-type: none"> • username=VALUE • password=VALUE
<p>User Name field</p>	<p>The username for the specified Mount Type, if required.</p>
<p>Password field</p>	<p>The password for the selected username, if required.</p>

Step 6 From top right hand menu, click **Launch KVM**.

Note

Depending on your browser settings, you may need to accept **KVM server certificate** and click the KVM viewer.

Virtual KVM Console displays the server console.

Step 7 Select **Power > Power Cycle System (boot)**.

Step 8 Press **F6** when the server starts to select a boot device.

The boot selection menu appears.

Step 9 Use the arrow keys to select **Cisco FlexMMC vDVD** and then press **Enter**.

The server boots using the UCS-SCU image and launches the application in the KVM tab.

Using CIMC Mapped vDVD

Before you begin

Download the UCS-SCU ISO image file from cisco.com. For information on how to download the image, refer [Obtaining ISO Image From cisco.com, on page 3](#).

Procedure

Step 1 Log in to Cisco IMC.

Step 2 In the **Compute** menu, click **Remote Management > Virtual Media**.

Step 3 In the **Virtual Media** tab > **Current Mappings** area, check for the required mapping.

Step 4 From top right hand menu, click **Launch KVM**.

Note

Depending on your browser settings, you may need to accept **KVM server certificate** and click the KVM viewer.

Virtual KVM Console displays the server console.

Step 5 Select **Virtual Media > CIMC-Mapped vDVD**.

The **Map Virtual Media - Removable Disk** window is displayed.

Step 6 In the **Map Virtual Media - Removable Disk** window, perform the following steps:

- a) Enter the desired name for the CIMC-mapped device.
- b) Select any of the following protocols:
 - NFS
 - CIFS
 - HTTP/S

By default, HTTP/S is selected.

c) Enter the file location in the format:

```
[http[s]://server-IP|DNS-name:Port/path-to-file.img
```

d) Enter the username and password.

e) Enter the desired name for the CIMC mapped device.

f) (Optional) Select the **Auto-remap**.

Step 7 Click **Save**.

Step 8 Select **Map Drive**.

After the host ejects this media, Cisco IMC will automatically re-map this device.

Step 9 Navigate to and select the ISO file and click **Open** to mount the image.

The following message is displayed in the virtual KVM console:

Successfully inserted media into device "CIMC-Mapped vDVD".

Step 10 Select **Power > Power Cycle System (boot)**.

Step 11 Press **F6** when the server starts to select a boot device.

The boot selection menu appears.

Step 12 Use the arrow keys to select **CIMC-Mapped vDVD** and then press **Enter**.

The server boots using the UCS-SCU image and launches the application in the KVM tab.

Using Physical Media

Before you begin

- Download the UCS-SCU ISO image file from cisco.com. For information on how to download the image, refer [Obtaining ISO Image From cisco.com, on page 3](#).
- Create an .iso CD using an application that burns .iso CDs.

Procedure

Step 1 Connect the USB DVD drive to the server through the USB port.

Step 2 Insert the physical media on to your DVD drive.

Step 3 Restart the server and press **F6** to enter the boot selection menu. Select **CDROM** drive as the boot device.

The server boots using the UCS-SCU image and starts the application.

Using Network Boot Support

Prerequisites

- A minimum of two systems is required for a PXE installation
- A server - a system running a DHCP server, a TFTP server, HTTP or FTP server to provide boot files. Theoretically, each of the servers can run on a different physical system; procedures in this section assume a single system runs all of them for simplicity
- A client - the system which you are booting SCU ISO. When the installation begins, the client will query the DHCP server, obtain boot files from the TFTP server

PXE Legacy Boot



Note The following files can be obtained from the mounted SCU ISO:

- `initrd`
- `bzImage`
- `rootfs.img`
- `ucs-scu-container-xxx.squash.fs`

1. Copy bootloader `Pxlinux.0` under `/var/lib/tftpboot` directory.
2. Copy `Pxlinux.cfg` under `/var/lib/tftpboot` directory.
3. Copy `initrd` and `bzImage` files from mounted SCU ISO under `/var/lib/tftpboot` directory.
4. Copy `rootfs.img`, `ucs-scu-container-xxx.squashfs` and `drivers` folder under `/var/www/html` directory or `/var/ftp/pub` directory.

PXE UEFI Boot

1. Copy `bootx64.efi` under `/var/lib/tftpboot` directory from extracted SCU ISO (which will be found in `(EFI/BOOT)` directory).
2. Copy `rootfs.img`, `ucs-scu-container-xxx.squashfs` and `drivers` folder under `/var/www/html` directory or `/var/ftp/pub` directory.

```
niosscubootmedium=pxe #type of the boot pxe/http/ipxe
```

Exiting UCS-SCU

Procedure

- Step 1** Remove the .iso disk from the disk drive.
- Step 2** Click on the **Power Cycle** button at the top right corner.
A pop-up window is displayed.

Step 3 Click on the **Power Cycle** button.



CHAPTER 3

Understanding UCS Server Configuration Utility User Interface

- [Introduction, on page 13](#)
- [License Agreement, on page 13](#)
- [UCS-SCU GUI Home Page, on page 13](#)

Introduction

The UCS-SCU GUI is a web-based management interface that allows you to perform tasks such as operating system installation and RAID configuration.

License Agreement

After UCS-SCU boots up, the first interface is the End User License Agreement.

Click on the **Accept** button to accept the licence and boot to UCS-SCU.

UCS-SCU GUI Home Page

Table 1: UCS-SCU GUI Elements

Element	Description
Navigation Pane	Located on the left side in the UCS-SCU user interface. See for more information.
Actions > Install OS	Located on the right side of the GUI. Different pages appear in the Install OS page depending on what you select.
Storage Configuration	Located on the right side of the GUI. Different pages appear in the Storage Configuration page depending on what you select in the Navigation Pane .

Element	Description
Viewing Chassis - Health and Inventory	Located on the right side of the GUI. Different pages appear in the Health page depending on what you select in the Navigation Pane .
Task Summary	Located at the bottom of the GUI. Shows the progress and completion status of the tasks running on the system.

Navigation Pane

Table 2: Navigation Pane Elements

Element	Description
Actions > Install OS	Installs the RHEL, SLES, Windows, Ubuntu, Oracle Linux, Rocky Linux and ESXi operating systems in a fully unattended mode. The most recent drivers for all onboard components are added from the Tools and Drivers CD or from other supported locations during the operating system installation. For more information about OS Install, see Installing Operating Systems, on page 17 .
Storage Configuration	Configures a RAID volume on attached hard drives of your server. Contains links to the RAID configuration pages: For more information about Storage Configuration, see Configuring RAID Levels, on page 61
Viewing Chassis - Health and Inventory	Displays the overall health of the server: Drives, CPU, Network, Storage Controller, PSU, DIMMs For more information, see Viewing Chassis, on page 25 .
Task Summary	Shows the progress and completion status of the tasks running on the system. For more information, see Viewing Task Summary, on page 33 .
Help	Opens a window in the application that displays context-sensitive help for the displayed page.

Toolbar

Name	Description
Help icon	Click to launch online help from any page.
Settings icon	Click to launch the User Preference dialog box. Select the desired theme and click Save to save changes.
Power Cycle icon	Click to launch Power Cycle dialog box. Click Power Cycle to continue restarting the server.



CHAPTER 4

Installing Operating Systems

- [Introduction, on page 17](#)
- [Installing Linux Server Operating System, on page 18](#)
- [Installing Windows Server Operating System, on page 20](#)
- [Installing ESXi, on page 23](#)

Introduction

Cisco UCS-SCU has integrated device drivers including RAID drivers to seamlessly install operating systems on supported RAID logical arrays without additional load driver steps or devices such as the USB.

UCS-SCU supports OS installation on the following:

- Virtual disks
- NVMe device
- M.2 device
- Disks in JBOD mode
- SD Cards
- SW RAID



Note This is available only on Cisco UCS M5, M6, M7 and M8 servers.



Note Before you begin the operating system installation, be sure that you have disabled the Watchdog Timer. If this feature is enabled and the value is set for a time duration that is less than the time needed to install the OS, the operating system installation process is interrupted. This Watchdog Timer feature automatically reboots or powers off the server after the specified time duration.

Installing Linux Server Operating System

Perform this procedure to install Linux Server OS.

Procedure

Step 1 Select **Install OS** in the left navigation pane.
The **Install Operating System** page displays all the OS installation options.

Step 2 In the **General** area, select the OS and version that you would like to install.
a) From the **Select OS** drop-down list, select the desired OS.

The following are displayed in the drop-down list:

- Red Hat
- SuSE
- Ubuntu
- Oracle
- Rocky Linux

b) From the **OS version** drop-down list, select the desired Linux version.

Step 3 In the **Enter OS Image Details** area, enter the following details:

- a) Select the appropriate protocol that you want to use to install the OS:
NFS / CIFS / HTTP/s
- b) Enter the disk location.
c) Enter the mount option.
d) Enter the user name and password.
e) Click **Next**.

Step 4 In the **Installation Target** area, select the target disk where you want to install the OS.

Step 5 Under the **Local Storage** tab, select the **Physical Drives** tab or the **Virtual Drives** tab.

- a) Select the desired physical drive in the **Physical Drives** tab.

The following fields are displayed in the **Physical Drives** tab to enable appropriate disk selection and proceed with OS installation.

Name	Description
Name	Name of the physical drive
Size (GiB)	Size of the physical drive.
Device Node	Details of the device node.
Serial Number	Serial number of the physical drive.

- b) Select the desired virtual drive in the **Virtual Drives** tab.

The following fields are displayed in the **Virtual Drives**.

Name	Description
VD Id	ID of the virtual drive.
Name	Name of the virtual drive.
Controller Slot	Controller slot details.
Size (GiB)	Size of the virtual drive.
Device Node	Details of the device node.

Step 6

Under the **SAN Storage** tab, select the **iSCSI** tab or the **Fibre Channel** tab.

- a) Enter the following details in the **iSCSI** tab.

Name	Description
Device Node	Details of the device node.
Initiator MAC	Initiator MAC Address
Target IQN	Name of the target in the IQN format
LUN	The LUN ID that corresponds to the location of the boot image.
Size (GiB)	Size of target LUN

- b) Enter the following details in the **Fibre Channel** tab.

Name	Description
Device Node	Details of the device node.
Host WWPN	The host World Wide Port Name with which the binding is associated.
LUN	The LUN ID that corresponds to the location of the boot image.
Size (GiB)	

Note

You can choose to click **Review and Install** option.

The **Summary** page is displayed with the default values for the fields in the next set of steps of the installation.

Step 7

In the **Basic Configuration** area, do the following:

- a. From the **Keyboard** drop down list, select the desired language.

- b. From the **Timezone** drop down list, select the desired time zone.
- c. From the **Language** drop down list, select the desired language.

Step 8 In the **Package Selection** area, select the applicable packages.

Step 9 In the **Network Settings** area, enter the following details:

Select the **IPv4 Settings** or **IPv6 Settings** tab.

To enable IPv4 or IPv6, select the appropriate toggle button.

These tabs display the link status of available network interfaces and the corresponding MAC address, Link Status, IP address, Subnet Mask, Gateway, and DNS.

To edit any of the network setting value, double-click the corresponding row and column.

After editing the field, press **Enter**.

Step 10 In the **Driver Selection** area, select the check box for the drivers that you want to install from the table.

Step 11 Click **Next**.

Step 12 Click **Install**.

OS Installation window is displayed with the following message:

Are you sure you want to proceed with the OS installation?

Warning: OS installation will clear the disk contents, take a backup before proceeding.

Host power cycle is required to proceed with OS installation.

Power cycle post installation checkbox is enabled, by default.

Step 13 Click **Proceed**.

When the installation begins, a task is created in the **Task Summary** page.

For more information, see [Viewing Task Summary, on page 33](#).

Installing Windows Server Operating System

Perform this procedure to install Windows Server OS.

Procedure

Step 1 Select **Install Operating System** in the left navigation pane.

The **Install Operating System** page displays all the OS installation options.

Step 2 In the **General** area, select the OS and version that you would like to install.

- a) From the **Select OS** drop-down list, select **Windows**.
- b) From the **OS version** drop-down list, select the desired Windows version.

Step 3 In the **Enter OS Image Details** area, enter the following details:

- a) Select the appropriate protocol that you want to use to install the OS:
NFS / CIFS / HTTP/s
- b) Enter the disk location.
- c) Enter the mount option.
- d) Enter the user name and password.
- e) Click **Next**.

Step 4

In the **Installation Target** area, select the target disk where you want to install the OS.

Step 5

Under the **Local Storage** tab, select the **Physical Drives** tab or the **Virtual Drives** tab.

- a) The following details are displayed in the **Physical Drives** tab.

Name	Description
Name	Name of the physical drive
Size (GiB)	Size of the physical drive.
Device Node	Details of the device node.
Serial Number	Serial number of the physical drive.

- b) Enter the following details in the **Virtual Drives** tab.

Name	Description
VD Id	ID of the virtual drive.
Name	Name of the virtual drive.
Controller Slot	Controller slot details.
Size (GiB)	Size of the virtual drive.
Device Node	Details of the device node.

Step 6

Under the **SAN Storage** tab, select the **iSCSI** tab or the **Fibre Channel** tab.

- a) Enter the following details in the **iSCSI** tab.

Name	Description
Device Node	Details of the device node.
Initiator MAC	Initiator MAC Address
Target IQN	The name of the target in the IQN format.
LUN	The LUN ID that corresponds to the location of the boot image.
Size (GiB)	Size of target LUN

- b) Enter the following details in the **Fibre Channel** tab.

Name	Description
Device Node	Details of the device node.
Host WWPN	The host World Wide Port Name with which the binding is associated.
LUN	The LUN ID that corresponds to the location of the boot image.
Size (GiB)	Size of target LUN

Note

You can choose to click **Review and Install** option.

The **Summary** page is displayed with the default values for the fields in the next set of steps of the installation.

Step 7 In the **Basic Configuration** area, do the following:

- a. From the **Keyboard** drop down list, select the desired language.
- b. From the **Timezone** drop down list, select the desired time zone.
- c. From the **Language** drop down list, select the desired language.
- d. In the **Organization** field, enter a name of the organization of the administrator.
- e. In the **Workgroup** field, enter a workgroup name.
- f. In the **Host name** field, enter a Windows host.
- g. From the **Auto logon** drop-down list, select **ON** or **OFF**.
- h. In the **Product key** field, enter OS license key.

Step 8 In the **Package Selection** area, select the applicable packages.

Step 9 In the **Network Settings** area, enter the following details:

Select the **IPv4 Settings** or **IPv6 Settings** tab.

To enable IPv4 or IPv6, select the appropriate toggle button.

These tabs display the link status of available network interfaces and the corresponding MAC address, Link Status, IP address, Subnet Mask, Gateway, and DNS.

To edit the any of the network setting value, double-click the corresponding row and column.

After editing the field, press **Enter**.

Step 10 In the **Driver Selection** area, select the check box for the drivers that you want to install from the table.

Step 11 Click **Next**.

Step 12 Click **Install**.

OS Installation window is displayed with the following message:

Are you sure you want to proceed with the OS installation?

Warning: OS installation will clear the disk contents, take a backup before proceeding.

Host power cycle is required to proceed with OS installation.

Power cycle post installation checkbox is enabled, by default.

Step 13 Click **Proceed**.

When the installation begins, a task is created in the **Task Summary** page.

For more information, see [Viewing Task Summary, on page 33](#).

Installing ESXi

The ESXi Install option allows you to install the operating system and customize the default settings.

Procedure

Step 1 Select **OS Installation** in the left navigation pane.

The **OS Installation** page displays all the OS installation options.

Step 2 From the **OS category** drop-down list, select **VMware**.

Step 3 From the **OS version** drop-down list, select the desired ESXi version.

Step 4 From the **Installing Disk** drop-down list, select the disk location.

(Optional) Select **Review & Install** to review the details and proceed with the installation.

Step 5 Click **Install** to proceed with the OS installation.

(Optional) Click the **Custom install** button.

The **VMware ESXi Custom Install** page of the selected ESXi version appears.

Step 6 Perform the following in the **VMware ESXi Custom Install** page:

a) In the **Basic Configuration** area, do the following:

1. From the **Keyboard** drop down list, select the desired language.

By default, the language is English.

2. In the **Root Password** field, enter the root password.

3. In the **Confirm Root Password** field, re-enter the root password.

4. In the **Product key** field, enter the product license key.

b) For **Installation Disk** area, perform the steps in [Selecting a Installation Disk, on page 24](#).

c) For **Network Settings** area, perform the steps in [Network Settings, on page 24](#).

Selecting a Installation Disk

In the **Installation Disk** area, do the following:

Procedure

Select the radio button of the installation disk you wish to use.

Network Settings

Network Settings allows you to enter the network configuration settings for the onboard network adapters that are detected by the operating system during installation. These settings do not affect the network settings for the Cisco IMC. We recommend that you set different IP addresses for the operating system and Cisco IMC. The network interface column lists each network adapter detected by the UCS-SCU. Your operating system may have a different name for the interface after you install the operating system.



Note Only one of the active network should be configured, and this network interface becomes ESXi management network.

In the **Network Settings** area, do the following:

Procedure

- Step 1** Select the **IPv4 Settings** or **IPv6 Settings** tab.
- These tabs display the link status of available network interfaces and the corresponding MAC address, Link Status, IP address, Subnet Mask, Gateway, and DNS.
- Step 2** To edit the any of the network setting value, double-click the corresponding row and column.
- This activates the field for editing.
- Step 3** After editing the field, click **Save**.
- (Optional) Select **Review & Install** to review the details and proceed with the installation.
- Step 4** Click **Next** to proceed with the installation.
-



CHAPTER 5

Viewing Chassis

-
- [Viewing Server Health, on page 25](#)
- [Viewing General Details, on page 26](#)
- [Viewing CPU Details, on page 27](#)
- [Viewing Memory Details, on page 28](#)
- [Viewing PCI Details, on page 29](#)
- [Viewing Network Details, on page 29](#)
- [Viewing Graphics Details, on page 30](#)
- [Viewing Storage Details, on page 30](#)
- [Viewing Power Supply Details, on page 32](#)

Viewing Server Health

This procedure describes the overall server health summary displayed in the **Health Summary** page

SUMMARY STEPS

1. Navigate to **Chassis > Overview** .
2. Following information is displayed:

DETAILED STEPS

Procedure

	Command or Action	Purpose						
Step 1	Navigate to Chassis > Overview .							
Step 2	Following information is displayed:	<table border="1"> <thead> <tr> <th>Area</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Server Area</td> <td>Displays the status of the server.</td> </tr> <tr> <td>CPU Area</td> <td>Displays the number of CPUs and their status</td> </tr> </tbody> </table>	Area	Description	Server Area	Displays the status of the server.	CPU Area	Displays the number of CPUs and their status
Area	Description							
Server Area	Displays the status of the server.							
CPU Area	Displays the number of CPUs and their status							

	Command or Action	Purpose	
		Area	Description
		DIMM Area	Displays the total number of DIMMs available in the server. Also displays the number of populated and unpopulated DIMM slots and their status.
		PSU Area	Displays the number of PSUs used in the server and their status.
		Storage Controller Area	Displays the number of storage controllers used and their status.
		Network Area	Displays the number of network card used in the server and their status.
		Drives Area	Displays the total number of drives available in the server. Also displays the status of the drives.

Viewing General Details

Procedure

-
- Step 1** Navigate to **Chassis > Inventory**
- Step 2** Select the **General** tab.
- Step 3** Following information is displayed under **Details** area.

Table 3: Details Area

Name	Description
Health	Displays the overall status of the server
Product ID	Cisco PID of the server
Serial Number	Product serial number
BIOS Firmware Version	Current BIOS version on the server

Name	Description
Chassis Type	Type of the server, rack or blade.
Manufacturer	Server manufacturer.

Step 4 Following information is displayed under **Properties** area:

Table 4: Properties Area

Name	Description
Server Name	Name of the Cisco UCS server
Front/Rear/Top tabs	<p>Note The graphics is only for example purpose. The actual server view may vary.</p> <p>Click to change the server graphical view.</p>
CPUs	Number of CPUs in the server
Cores	Number of cores in each CPU
Cores Enabled	Number of cores, which are enabled
Threads	Number of threads supported by each core
PCI Adapters	Number of PCIe cards in the server
CPU Capacity = Number of Sockets X Enabled Cores	Value represented by multiplying the number of sockets by number of enabled cores
Memory Capacity (GiB)	DIMM capacity in GB
Storage Capacity (GiB)	Storage capacity in GB
Disks	Number of storage drives in the server
UUID	Universally Unique Identifier of the server

Viewing CPU Details

Procedure

Step 1 Navigate to **Chassis > Inventory**.

Step 2 Select the **CPU** tab.

Step 3 Following information is displayed:

Name	Description
Model	CPU manufacturer name and model name
Health	Displays the overall status of the CPU
Number of Enabled Cores	Number of cores, which are enabled
Number of Threads	Number of threads supported by each core
Max Speed (Mhz)	Processor speed in Mhz
Vendor	CPU manufacturer name
Signature	CPU type, Family, Model and Stepping

Viewing Memory Details

Procedure

Step 1 Navigate to **Chassis > Inventory**.

Step 2 Select the **Memory** tab.

Step 3 Following information is displayed:

Table 5: Memory Details

Name	Description
Name	DIMM slot information
Status	Whether the DIMM is populated or not
Health	Overall status of the DIMM
Locator	Not applicable if the slot is empty. If the slot is populated, locator LED information is provided.
Capacity (MiB)	DIMM capacity in MB
Speed (MHz)	DIMM speed in Mhz
Channel Type	The type of memory channel.
Manufacturer	Name of the manufacturer
Serial Number	Serial number of the DIMM

Name	Description
Asset Tag	The asset tag associated with the DIMM, if any.
Part Number	The part number for the DIMM assigned by the vendor.
Data Width	The amount of data the DIMM supports, in bits.

Viewing PCI Details

Procedure

Step 1 Navigate to **Chassis > Inventory**.

Step 2 Select the **PCI** tab.

Step 3 Following information is displayed:

Name	Description
Name	Name of the PCIe card
Slot	Server slot information in which the card is placed
Vendor ID	The adapter ID assigned by the vendor
Sub Vendor ID	The secondary adapter ID assigned by the vendor.
Device ID	The device ID assigned by the vendor
Sub Device ID	The secondary device ID assigned by the vendor

Viewing Network Details

Procedure

Step 1 Navigate to **Chassis > Inventory**.

Step 2 Select the **Network** tab.

Step 3 Following information is displayed:

Name	Description
Name	Name for the adapter.
Health	Overall status of the adapter
Slot	Server slot information in which the card is placed
Link Status	Link status with the external interface
Mac Address	The MAC address for the external ethernet interface.

Viewing Graphics Details

Procedure

- Step 1** Navigate to **Chassis > Inventory**.
- Step 2** Select the **Graphics** tab.
- Step 3** Following information is displayed:

Name	Description
Name	Name of the GPU card
Slot	Server slot information in which the card is placed
Vendor	The GPU ID assigned by the vendor
Serial Number	The serial number assigned by the vendor

Viewing Storage Details

Procedure

- Step 1** Navigate to **Chassis > Inventory**.
- Step 2** Select the **Storage** tab.
- Step 3** Following information is displayed in the **Controller** area:

Table 6: Controller Area

Name	Description
Name	Name of the controller card
Slot	Server slot information in which the drive is placed
Firmware Version	Drive firmware version
Serial Number	Serial number assigned by the vendor
Battery Backup Unit	Status of the battery
Boot Loader Version	Boot Loader Version

Step 4 Following information is displayed in the **Physical Drive** area:

Table 7: Physical Drives Area

Name	Description
Vendor	Name of the vendor
Health	Overall status of the drive
Protocol	Protocol
Media Type	Whether the drive is a hard drive (HDD) or a solid state drive (SSD).
Slot	Slot number in which the physical drive resides.
Model	The drive vendor name.
Serial Number	The serial number for the drive.
Revision	Revision
Capacity (GiB)	The capacity of drive in GB, including the space used for formatting.
Capacity (Bytes)	The capacity of drive in Bytes, including the space used for formatting.
BlockSize Bytes	BlockSize Bytes
Capable Speed (Gbs)	Capable Speed (Gbs)
Operating Temperature (°c)	The current temperature of the drive at which the selected drive operates at the time of selection.
Predictive Failure Counts	The number of times that the controller has predicted that the drive could fail.

Name	Description
Media Error Counts	The number of media errors encountered since the drive was first installed or the host was rebooted.
Non Coerced Size Bytes	The capacity in megabytes, including space lost to coercion.
Coerced Size	The capacity in megabytes after any coercion rounding has been performed.

Viewing Power Supply Details

Procedure

- Step 1** Navigate to **Chassis > Inventory**.
- Step 2** Select the **Power Supply** tab.
- Step 3** Following information is displayed:

Name	Description
Name	Name of the PSU vendor
Health	Overall status of the PSU
Power Input (Watts)	The input into the power supply, in watts.
Power Output (Watts)	The maximum output from the power supply, in watts.



CHAPTER 6

Viewing Task Summary

- [Viewing Task Summary, on page 33](#)

Viewing Task Summary

The details of all the tasks running on the system, including the progress and completion status is displayed on this page.

Procedure

Step 1 Navigate to **Task Summary** on the **Navigation Pane**.

Step 2 Following information is displayed for a specific task:

Name	Description
Details	The following details of the task is displayed on the left column of the table: <ul style="list-style-type: none">• State• Status• Task Id• Name• Duration• Start Time• End Time
Execution Flow	<ul style="list-style-type: none">• The status of the progress of task is displayed.• The sub-task details of the task are displayed with the timestamp.

Step 3

Step 4



CHAPTER 7

Non Interactive Operating System Installation

This chapter contains the following sections:

- [Non Interactive Operating System Installation, on page 35](#)
- [Support for Network Boot from PXE, iPXE, HTTP and HTTPS, on page 36](#)
- [Modifying the nwboot.cfg File, on page 36](#)
- [Modifying the niscu.cfg File, on page 43](#)
- [Modifying conf_file, on page 50](#)
- [Running the Python Script to Start OS Deployment, on page 53](#)
- [Installing Operating Systems Using Commands, on page 53](#)
- [Sample nwboot.cfg file, on page 57](#)
- [Sample conf_file and niscu.cfg files, on page 59](#)

Non Interactive Operating System Installation

Non Interactive Server Configuration Utility (NI-SCU) helps deploy operating systems without user intervention.

To install operating systems using NI-SCU, do the following:

- Modify the `nwboot.cfg` file to include information such as the target server, the SCU ISO file location, and the log collection details.
- Modify the `niscu.cfg` configuration file to include information such as the target server, the SCU ISO file location, and the log collection details.
- See [Modifying the niscu.cfg File, on page 43](#).
- See [Modifying conf_file, on page 50](#).
- Prepare the answer file for kickstart installation.

For sample answer files, see the Custom OS Installation Examples chapter.

- Run the `os_install-4.2.yc.yyyymmddab.py` script to begin the installation.
See [Running the Python Script to Start OS Deployment, on page 53](#).

Support for Network Boot from PXE, iPXE, HTTP and HTTPS

Beginning with Release 6.3, you can perform SCU Network boot from the following network options with IPv4 and IPv6.

- PXE
- iPXE
- HTTP
- HTTPS

The above network boot options are available in addition to the existing boot medium options like CIMC vMedia.

You can perform the SCU ISO boot from the above network options using the NISCU-XML API and NISCU-Redfish interfaces on Cisco UCS M5, M6 and M7 servers.

Beginning with Release 6.3, for non interactive operating system installation using HTTP/HTTPS, PXE and iPXE, you must first configure the `nwboot.cfg` file.

Modifying the nwboot.cfg File

Beginning with Release 6.3, for non interactive operating system installation using HTTP/HTTPS, PXE and iPXE, you must first configure the `nwboot.cfg` file.

The `nwboot.cfg` file consists of the following sections:

Default

The Default section consists of the following parameter:

Table 8: Parameters in the Default Section

Parameter	Description
Update_Timeout	The time (in minutes) the python script is active after it has been started. The default value is 240 minutes. The valid range is 30 to 240 minutes.

Example

```
[defaults]
update_timeout=240
```

SCU Repository

The SCU Repository section consists of the following parameters:

Table 9: Parameters in the SCU Repository Section

Parameter	Description
BootMedium	<p>The boot medium to install SCU boot.</p> <p>The following types are supported:</p> <ul style="list-style-type: none"> • vMedia • HTTP • FlexMMC • MicroSD • PXE • IPXE



Note See the below sections for the details of the fields available for the respective boot medium under **SCU Repository**.

Table 10: HTTP Boot Medium

Parameter	Description
ImageRepository	Path where SCU ISO resides in the HTTP share
MACAddress	The MAC address assigned to the active network interface to SCU
PCIEslot	The name of the PCIe slot in which the controller is located.
PhysicalPortNumber	Physical Port Number

Parameter	Description
IPv4Address and IPv6Address	<p>IP address for IPv4 and IPv6</p> <p>These are the following parameters for IPv4:</p> <ul style="list-style-type: none"> • AddressOrigin - Server IP address from which IPv4 or IPv6 origins • Address - Host IP Address for the network interface • Gateway - IPv4 Gateway Address • Subnetmask - IPv4 Subnet Address • Static Name Server <p>The value is Static.</p> <p>These are the following parameters for IPv6:</p> <ul style="list-style-type: none"> • AddressOrigin - Server IP address from which IPv4 or IPv6 origins • Address - Host IP Address for the network interface • Gateway - IPv6 Gateway Address • Subnetmask - Prefix length for IPv6 • Static Name Server

Table 11: vMedia Boot Medium

Parameter	Description
ImageRepository	Path where SCU ISO resides in the HTTP share
TransferProtocol	The transfer protocol type.
Username	User credentials
Password	
MountOptions	Mounting options

Table 12: PXE Boot Medium

Parameter	Description
ImageRepository	Path where SCU ISO resides in the HTTP share

Parameter	Description
MACAddress	The MAC address assigned to the active network interface to SCU
PCIEslot	The name of the PCIe slot in which the network adapter is located.
PhysicalPortNumber	Physical port number
AddressOrigin	Server IP address from which IPv4 or IPv6 origins The value is DHCP.

Table 13: iPXE Boot Medium

Parameter	Description
ImageRepository	Server IP address from which IPv4 or IPv6 origins The value is DHCP.
MACAddress	The MAC address assigned to the active network interface to SCU
PCIEslot	The name of the PCIe slot in which the network adapter is located.
PhysicalPortNumber	Physical port number

Example

```
"BootMedium": {
  "VMEDIA": {
    "ImageRepository": "10.10.10.1/home/nfsshare/iso/scu.iso",
    "TransferProtocol": "nfs",
    "Username": "root",
    "Password": "password",
    "MountOptions": ""
  },
  "HTTP": {
    "ImageRepository": "http://10.10.10.1:80/iso/scu.iso",
    "MACAddress": "70:df:2f:86:af:02",
    "PCIEslot": "L",
    "PhysicalPortNumber": 1,
    "IPv4Address": {
      "AddressOrigin": "Static",
      "Address": "10.104.255.179",
      "Gateway": "10.104.255.129",
      "SubnetMask": "255.255.255.128",
      "StaticNameServer": "64.104.76.247"
    },
    "IPv6Address": {
      "AddressOrigin": "DHCPv6",
      "Address": "fc00:1234::a:b:c:d",
      "PrefixLength": 64,
      "Gateway": "fe80::fe15:b4ff:fe97:90cd",
      "StaticNameServer": "fe80::fe15:b4ff:fe97:90cd"
    }
  }
},
```

```

"FLEXMMC": {
  "ImageRepository": "scu.iso"
},
"MICROSD": {},
"PXE": {
  "ImageRepository": "ftp://10.104.255.224/pub/scu",
  "MACAddress": "70:df:2f:86:af:02",
  "PCIEslot": "L",
  "PhysicalPortNumber": 1,
  "IPv4Address": {
    "AddressOrigin": "DHCP"
  }
},
"IPXE": {
  "ImageRepository": "http://10.10.10.1/iso/scu.iso",
  "MACAddress": "70:df:2f:86:af:02",
  "PCIEslot": "L",
  "PhysicalPortNumber": 1
}
}

```

OS Details

In the OS Details section, provide the OS Repository and Target OS details of the share where the SCU ISO image is located.

The OS Details section consists of the following parameters for OS Repository, vMedia boot medium and Target OS:

Table 14: OS Repository

Parameter	Description
MediaType	Type of media. By default, the value is local.
BootMedium	The boot medium to install SCU boot. By default, the value is vMedia.

Table 15: vMedia Boot Medium

Parameter	Description
ImageRepository	SCU ISO boot image repository location
Transfer Protocol	The transfer protocol type.
Username	User credentials
Password	
Mount Options	Mounting options

Example

```

"OSDetails": {
  "OSRepository": {
    "MediaType": "Local",

```

```

        "BootMedium": {
            "VMEDIA": {
                "ImageRepository":
"10.10.10.1/home/nfsshare/iso/rhel/RHEL-8.5.0-20211013.2-x86_64-dvd1.iso",
                "TransferProtocol": "nfs",
                "Username": "root",
                "Password": "password",
                "MountOptions": ""
            }
        },
        "TargetOS": {
            "OSName": "rhel8u5x64",
            "OSEdition": "None"
        }
    }

```

Target Disk

In the Target Disk section, provide the type of disk details.

The Target Disk section consists of the following parameters:

Table 16: Target Disk

Parameter	Description
PHYSICALDISK	Enter the Drive Serial Number.
VIRTUALDISK	Enter the following details: <ul style="list-style-type: none"> • Storage Controller Slot ID • Virtual Drive Number
DISKNAME	Enter the OS Drive details.
VIRTUALDRIVENAME	Enter the virtual drive name.
ONBOARDSATAM2SSD	Enter the slot details for SATAM2SSD.
M2SWVDNAME	Enter the details for M2 SW RAID Name.
FC	Enter the following details: <ul style="list-style-type: none"> • HostWWPN • TargetWWPN • LUN
ISCSI	Enter the following details: <ul style="list-style-type: none"> • MACAddress • Primary Target Name • Primary LUN

Example

```

"TargetDisk": {
  "PHYSICALDISK": {
    "DriveSerialNumber": "06VSGVVB"
  },
  "VIRTUALDISK": {
    "StorageControllerSlotID": "MRAID",
    "VirtualDriveNumber": 0
  },
  "DISKNAME": {
    "OSDrive": "/dev/sdk"
  },
  "VIRTUALDRIVENAME": {
    "VirtualDriveName": "Hypervisor"
  },
  "ONBOARDSATAM2SSD": {
    "SATAM2SSD": "slot1"
  },
  "M2SWVDNAME": {
    "M2SWRAIDName": "RAID0"
  },
  "FC": {
    "HostWWPN": "10:00:54:88:DE:A7:32:6F",
    "TargetWWPN": "50:06:01:68:3E:A0:62:22",
    "Lun": 200
  },
  "ISCSI": {
    "MACAddress": "70:DF:2F:86:AE:FD",
    "PrimaryTargetName":
"iqn.2001-05.com.equallogic:0-af1ff6-082b3ebe6-cf2005780845d665-iqn.siva-25.com",
    "PrimaryLUN": 1
  }
}

```

Remote Log

In the Remote Log section, provide the IP address and access details of the share where the installation logs will be saved.

The Remote Log section consists of the following parameters:

Table 17: Parameters in the Remote Log Section

Parameter	Description
ImageRepository	The IP address of the share where the log file is generated during the installation.
TransferProtocol	The protocol type used to access the share. The following protocols are supported: <ul style="list-style-type: none"> • SCP • SFTP
Username Password	The user credentials to access the share.

Example

```

"RemoteLog": {
  "ImageRepository": "10.10.10.10/home/nfstest/scu.log",

```



```
"TransferProtocol": "scp",
"Username": "root",
"Password": "John123"
```

Answer File

In the Answer File section, provide access details of the share where the answer file is located. The answer file contains details about OS deployment.

Example

```
"AnswerFile": {
  "ImageRepository": "10.10.10.10/home/nfstest/answerfile",
  "TransferProtocol": "scp",
  "Username": "root",
  "Password": "John123"
```

Table 18: Parameters in the Answer File Section

Parameter	Description
ImageRepository	The IP address of the share where the log file is generated during the installation.
TransferProtocol	The protocol type used to access the share. The following protocols are supported: <ul style="list-style-type: none"> • SCP • SFTP
Username Password	The user credentials to access the share.

Modifying the niscu.cfg File

Beginning with Release 6.3, for non interactive operating system installation using HTTP/HTTPS, PXE and IPXE, you must first configure the `nwboot.cfg` file.

For non interactive operating system installation using vMedia, you must first configure the `niscu.cfg` file.



Note You do not have to configure `nwboot.cfg` file while installing non interactive operating system using vMedia.

The `niscu.cfg` file consists of the following sections:

- [Default, on page 44](#)
- [SCU, on page 44](#)
- [NIOS Install, on page 45](#)
- [Log Collection, on page 46](#)
- [OS, on page 47](#)

- [Answer File, on page 48](#)
- [Target System, on page 49](#)

Each section must have a unique name. The section name is provided by the user.

Default

The Default section consists of the following parameters:

Table 19: Parameters in the Default Section

Parameter	Description
[section_name]	Enter a name for the section.
use_http_secure=	The HTTP type. The default value is 'Yes'. Type 'No' if the connection is insecure.
update_timeout=	The time (in minutes) the python script is active after it has been started. The default value is 120 minutes. The valid range is 30 to 240 minutes.

Example

```
[defaults]
use_http_secure=yes
update_timeout=120
```

SCU

In the SCU section, provide the IP address and access details of the share where the SCU ISO image is located.

The SCU section consists of the following parameters:

Table 20: Parameters in the SCU Section

Parameter	Description
[section_name]	Enter a name for the section.
isoshareip=	The IP address of the SCU ISO share.
isosharepath=	The location of the ISO image in the share.
imagefile=	The name of the SCU ISO image.
isosharetype=	The share type. The following share types are supported: <ul style="list-style-type: none"> • NFS • CIFS • WWW (HTTP or HTTPS)

Parameter	Description
isoshareuser=	The user credentials to access the share.
isosharepassword=	
bootmedium=	The medium to be used to boot from. The following types are supported: <ul style="list-style-type: none"> • vmedia - To boot from vmedia • flexmmc- To boot from eMMC • microsd - To boot from microsd
nios_section=	The nios_install section containing the OS installation process.

Example

```
[scu_iso]
isoshareip=192.0.2.10
isosharepath=/cifsshare
imagefile=ucs-cxxx-scu-5.0.0.39.iso
isosharetype=cifs
isoshareuser=Administrator
isosharepassword=John123
bootmedium=vmedia
```

NIOS Install

The NIOS Install section initiates the OS installation process and consists of the following parameters.

Table 21: Parameters in the NIOS Install Section

Parameter	Description
remoteShareIp=	IP Address of the <code>scuConfigFile</code> remote share
remoteSharePath=	<code>scuConfigFile</code> remote share path.
remoteShareFile=	<code>scuConfigFile</code> in the remote share
remoteShareType=	Remote share protocol. The following are supported: <ul style="list-style-type: none"> • SCP • SFTP • TFTP • WWW (HTTP or HTTPS)
username=	The user credentials to access the remote share.
password=	

Parameter	Description
scubootmedium=	The medium to be used to SCU boot from. The following types are supported: <ul style="list-style-type: none"> • HTTP - To boot from HTTP or HTTPS • PXE - To boot from PXE • IPXE - To boot from IPXE • vmedia - To boot from vmedia • flexmmc- To boot from eMMC • microsd - To boot from microsd
osBootMedium=	The medium to be used to boot SCU ISO from. vmedia is the supported medium.
targetDiskType=	The type of target disk. The following types are supported: <ul style="list-style-type: none"> • physicaldisk • virtualdisk • microsd

Example

```
[nios_install]
niosremoteshareip=10.10.10.10
niosremotesharepath=/home/nfstest/xyz/config/
niosremotesharefile=scuConfigFile_VMEDIA_VMEDIA_RHEL8_4
niosremotesharetype=scp
niosusername=root
niospassword=Jack123
niosscubootmedium=vmedia
niososbootmedium=vmedia
niostargetdisktype=physicaldisk
```

Log Collection

In the Log Collection section, provide the IP address and access details of the share where the installation logs will be saved.

The Log Collection section consists of the following parameters:

Table 22: Parameters in the Log Collection Section

Parameter	Description
[section_name]	Enter a name for the section.
remshareip=	The IP address of the share where the log file is generated during the installation.

Parameter	Description
remsharepath=	The location of the log file in the share. The log data generated during the installation is saved in this file. Enter the absolute path of the share.
remsharefile=	The file name to store SCU NI-OSI logs on the remote server. The default value is share_file.
remsharetype=	The protocol type used to access the share. The following protocols are supported: <ul style="list-style-type: none"> • SCP • SFTP
remshareuser= remsharepassword=	The user credentials to access the share.

Example

```
[log_info]
remshareip=192.0.2.100
remsharepath=PATH
remsharefile=share_file
remsharetype=scp
remshareuser=user
remsharepassword=xxxx
```

OS

In the OS section, provide access details of the share where the config file is located. The config file contains the operating system details that are used in niscu.cfg. The OS section is for a single operating system only. If you want to install a different OS, repeat this section with the corresponding config file. See [Modifying conf_file, on page 50](#) for information about config_file.

The OS section consists of the following parameters:

Table 23: Parameters in the OS Section

Parameter	Description
[section_name]	Enter a name for the section. The name provided here should be used as the value for the config_section parameter in the Target Server section.
ip=	The IP address of the share where the config file is located.
path=	The location of the config file in the share.

Parameter	Description
file=	The config file that contains the operating system details.
username=	The user credentials to access the share.
password=	
protocol=	<p>The protocol used to access the share.</p> <p>The following protocols are supported:</p> <ul style="list-style-type: none"> • SCP • SFTP • HTTP • TFTP

Example

```
[OS_iso]
ip=192.0.2.200
path=/var/www/html/huu
file=conf_file
username=root
password=Huudefault369
protocol=scp
```

Answer File

In the Answer File section, provide access details of the share where the answer file is located. The answer file contains details about custom OS deployment. This section is optional if you want to install an operating system with default settings (Quick installation).

Table 24: Parameters in the Answer File Section

Parameter	Description
[section_name]	<p>Enter a name for the section.</p> <p>The name defined here should be used as the value in the "answerfile_section" parameter in the target server section.</p>
ip=	The IP address of the share that contains the answer file.
path=	The location of the answer file in the share.
file=	The kickstart file. For custom installation, the kickstart file contains the required installation details.
username=	The user credentials to access the share.
password=	

Parameter	Description
protocol=	The protocol type used to mount the share. The following protocols are supported: <ul style="list-style-type: none"> • SCP • SFTP • HTTP • TFTP

Example

```
[OS_answerfile]
ip=192.0.2.254
path=/home/SCU/NI_SCU/Files/
file=esxi_ks.cfg
username=root
password=root@123
protocol=scp
```

Target System

In this section, provide details about the target server where the operating system is being installed. This section also contains details about the config file and answer file that are passed to the niscu.cfg file. For deploying operating systems in multiple servers, repeat this section with the details of target server, config file, and answer file.

Table 25: Parameters in the Target System Section

Parameter	Description
[section_name]	When naming this section, use this format: cimc, followed by an underscore (_), and a number. The number defines the target server instance.
address=	The IP address of the target server where the OS is being installed.
user=	The user credentials to access the target server.
password=	
imagefile=	The SCU image file name.
config_section=	The name given for the OS section should be provided here. For example, if the OS section name is "rhel_iso", then provide that name here.

Parameter	Description
servernode=	Select the node where you want to install the OS. This option is applicable for only C3260 and S3260 M4 servers. Enter 1 to select node 1. Enter 2 to select node 2. Enter 'all' to select both the nodes.
[answerfile]	The name given for the Answer File section should be provided here. For example, if the Answer File section is "OS_answerfile", then provide that name here. This is an optional parameter. The Answer file section is required only for custom installation.

Example

```
[cimc_1]
address=192.0.2.10
user=admin
password=Cisucs891
imagefile=ucs-cxxx-scu-5.0.0.39.iso
config_section=OS_iso
servernode=1
answerfile_section=OS_answerfile

[cimc_2]
address=192.0.2.20
user=admin
password=Ciscoucs345
imagefile=ucs-cxxx-scu-5.0.0.39.iso
config_section=OS_iso
servernode=2
answerfile_section=OS_answerfile
```

Modifying conf_file

The `conf_file` contains details about the operating system being deployed on the target server. The `conf_file` includes the following parameters:

Table 26: Parameters in conf_file

Parameter	Description
shareMapType:	The share type. The following share types are supported: <ul style="list-style-type: none"> • NFS • CIFS • WWW (HTTP and HTTPS)

Parameter	Description
shareIP:	The IP address of the share where the OS ISO file is saved.
sharePath:	The location of the OS ISO file.
sharefile:	The name of the OS ISO file.
username:	The user credentials to access the share.
password:	Enter the user name and password.
osName:	The operating system format. See Modifying conf_file for the operating system formats.
osDrive:	<p>The drive where the operating system is installed.</p> <p>For example, <code>sdd</code> and <code>sde</code> might represent the first and second VDs.</p> <p>However, the enumeration of disks depends on the number of JBODs and VDs configured. Suppose a single JBOD has been configured. Then the JBOD is enumerated first and <code>sde</code> and <code>sdf</code> represent the first and second VDs.</p> <ul style="list-style-type: none"> • DriveSerialNumber: Z1W4PB48000R610JQWP #Serial Number of the drive connected to LSI/Noe-Valley RAID controller or NVMe disk, on which OS has to be installed. • StorageControllerSlotID: MRAID #Controller Slot ID. This will be ignored, if DriveSerialNumber is present. <p>VirtualDriveNumber: 0 #VD Number of the drive on which OS has to be installed.</p> <p>For LSI/Noe-Valley RAID controllers, VirtualDriveNumber should be specified along with StorageControllerSlotID.</p> <ul style="list-style-type: none"> • VirtualDriveName: Hypervisor #VD Name on which OS has to be installed. Applicable only for SD Card Drives. <p>Note The above options are exclusive. You can provide any one of the above.</p>

Parameter	Description
Edition:	<p>Windows parameter only. This parameter is applicable for both custom and quick installation of Windows.</p> <p>The following editions are supported:</p> <ul style="list-style-type: none"> • STANDARD • DATACENTER • STANDARDCORE • DATACENTERCORE

Example

```

shareMapType:www
shareIp:192.0.2.100
sharePath:/hvu
shareFile:VMware-VMvisor-Installer-5-5-0_update03-3116895_x86_64.iso
userName:root
password:HuuWelcome123
osName:esxi5u5x64
osDrive:/dev/sde
Edition:STANDARD
MediaType:Local
Interface:eth0
BootProto:static
IP:192.0.2.254
Subnet:255.255.255.0
Gateway:192.0.2.100
DNS:192.0.2.100

```

The following table lists a few examples of operating system formats.

Table 27: Operating System Formats

Operating System	Version	Format
Rocky Linux	Rocky Linux 8 Update 6	rocky8u6x64
	Rocky Linux 8 Update 7	rocky8u7x64
	Rocky Linux 9 Update 1	rocky9u1x64
Oracle Linux	Oracle Linux 7 Update 9	oracle7u9x64
	Oracle Linux 8 Update 6	oracle8u6x64
	Oracle Linux 9	oracle9u0x64
RHEL	RHEL 8.0	rhel8ux64
	RHEL 8.4	rhel8u4x64
SLES	SLES 15 SP3	sles15sp3x64
	SLES 15.0	sles15x64

Operating System	Version	Format
Ubuntu	Ubuntu 20.4.2	ubuntu20042x64
Esxi	Esxi 7.0U3	esxi7u03x64
	Esxi 6.7.3	esxi6u73x64
Windows	Windows Server 2019 and 2022	w2k19x64
		w2k22x64

Running the Python Script to Start OS Deployment

Procedure

	Command or Action	Purpose
Step 1	Install the following components on the Linux client system from where you want to run the Python script:	<ul style="list-style-type: none"> • Python 2.7.x for 4.1.1 and below • Python 3.x for 4.2.1 and above • Open SSL Version 1.0.1e-fips or later
Step 2	On the Linux client system, run the following command:	<p>python os_install-4.2.yc.yyyymmddab.py -c niscu.cfg</p> <p>Here, <code>os_install-4.2.yc.yyyymmddab.py</code> is the Python script, and <code>niscu.cfg</code> is the configuration file that contains information about the SCU ISO image and the OS details.</p> <p>When the Python script is executed, the target server boots to the SCU ISO. After SCU boots, it mounts the OS ISO image that is mapped in the configuration file. SCU then installs the operating system on the target server.</p>

Installing Operating Systems Using Commands

Use the following options to install an operating system on a single server:

Table 28: Options to Install OS on a Single Server

Option	Description
<code>-a a.b.c.d, --address=a.b.c.d</code>	The IP address of the target server.
<code>-u USERNAME, --user=USERNAME</code>	The admin user credentials to access the target server.
<code>-p PASSWORD, --password=PASSWORD</code>	
<code>-m scu.iso, --imagefile=scu.iso</code>	The name of the SCU ISO file.

Option	Description
-i a.b.c.d, --isoshareip=a.b.c.d	The IP address of the remote share where the SCU ISO image is located.
-d /data/image, --isosharepath=/data/image	The location of the ISO file in the share.
-t cifs/nfs/www, --isosharetype=cifs/nfs/www	The type of remote share. The following share types are supported: <ul style="list-style-type: none"> • CIFS • NFS • WWW (HTTP or HTTPS)
-r ISOSHAREUSER, --isoshareuser=ISOSHAREUSER	The admin user credentials to access the share where the SCU ISO image is located.
-w ISOSHAREPASSWORD, --isosharepassword=ISOSHAREPASSWORD	
-o BOOTMEDIUM, --bootMedium=BOOTMEDIUM	The boot medium used to update. The following share types are supported: <ul style="list-style-type: none"> • vmedia • microsd • flexmmc
-q TIMEOUT, --timeout=TIMEOUT	NISCU OS Installation timeout
-M ISOMOUNTOPTION, --isomountoption=ISOMOUNTOPTION	Use mount option in case of CIFS share to specify the security option.
-I a.b.c.d, --remshareip=a.b.c.d	The IP address of the remote share where the snapshot results will be saved.
-D /data/image, --remsharepath=/data/image	The directory to store snapshot results in the share.
-F REMOTESHAREFILE, --remoteShareFile=REMOTESHAREFILE	The name of the share file.
-T scp/sftp, --remsharetype=scp/sftp	The type of share. The following protocols are supported: <ul style="list-style-type: none"> • SCP • SFTP
-U REMSHAREUSER, --remshareuser=REMSHAREUSER	The user credentials to access the share to save snapshot results.
-W REMSHAREPASSWORD, --remsharepassword=REMSHAREPASSWORD	

Option	Description
-x CONFIGSHAREIP, --configShareIp=CONFIGSHAREIP	The IP address of the remote share where the config file is located.
-y CONFIGSHAREPATH, --configSharePath=CONFIGSHAREPATH	The path to the location of the config file in the share.
-z CONFIGSHAREFILE, --configShareFile=CONFIGSHAREFILE	The name of the config file.
-j CONFIGSHARETYPE, --configShareType=CONFIGSHARETYPE	The type of share.
-b CONFIGSHAREUSERNAME, --configShareUsername=CONFIGSHAREUSERNAME	The user credentials to access the share where the config file is located.
-e CONFIGSHAREPASSWORD, --configSharePassword=CONFIGSHAREPASSWORD	
-X ANSWERFILESHAREIP, --answerFileShareIp=ANSWERFILESHAREIP	The IP address of the share where the answer file is located.
-Y ANSWERFILESHAREPATH, --answerFileSharePath=ANSWERFILESHAREPATH	The path to the location of the answer file in the share.
-Z ANSWERFILESHAREFILE, --answerFileShareFile=ANSWERFILESHAREFILE	The name of the answer file.
-J ANSWERFILESHARETYPE, --answerFileShareType=ANSWERFILESHARETYPE	The type of share.
-B ANSWERFILEUSERNAME, --answerFileUsername=ANSWERFILEUSERNAME	The user credentials to access the share where the answer file is located.
-E ANSWERFILEPASSWORD, --answerFilePassword=ANSWERFILEPASSWORD	
-N SERVERNODE, --serverNode=SERVERNODE	Select the node where you want to install the OS. This options is applicable for only C3260 and S3260 M4 servers. Type 1 to select node 1. Type 2 to select node 2. Type ALL to select both the nodes.
-f LOGFILE, --logrecordfile=LOGFILE	The name of the log file that contains the log data.

Table 29: CLI Options for NIOS_Install Section

Option	Description
-A NIOSREMOTESHAREIP, --niosremoteshareip=NIOSREMOTESHAREIP	IP address of remote share for non-interactive OS install

Option	Description
-G NIOSREMOTESHAREPATH, --niosremotesharepath=NIOSREMOTESHAREPATH	Path in remote share for non-interactive OS install
-H NIOSREMOTESHAREFILE, --niosremotesharefile=NIOSREMOTESHAREFILE	Filename in remote share for non-interactive OS install
-K NIOSREMOTESHARETYPE, --niosremotesharetype=NIOSREMOTESHARETYPE	Remote share type for non-interactive OS install
-L NIOSUSERNAME, --niosusername=NIOSUSERNAME	Username of the Cisco IMC admin user
-O NIOSPASSWORD, --niospassword=NIOSPASSWORD	Password of the Cisco IMC admin user
-P NIOSSCUBOOTMEDIUM, --niosscubootmedium=NIOSSCUBOOTMEDIUM	Boot medium for non-interactive OS install
-Q NIOSOSBOOTMEDIUM, --niososbootmedium=NIOSOSBOOTMEDIUM	OS medium for non-interactive OS install
-R NIOSTARGETDISKTYPE, --niostargetdisktype=NIOSTARGETDISKTYPE	Target Disk type for non-interactive OS install

Example

Example 1: Options for Quick Installation

In this example, the command options help in quick installation of Windows on 198.51.100.10. The SCU ISO image is located in 198.51.100.100. The conf_file is placed in 198.51.100.100. The OS installation log files are saved in 198.51.100.254. The NI-SCU script log files are saved in the same client system where the script is executed.

```
python3 os_install.py -a 198.51.100.10 -u user1 -p passwd
-m ucs-cxxx-scu-6.2.xx.iso -o vmedia -i 198.51.100.100
-d /utils_share/scu/kb -t nfs -r user2 -w passwd1 -I 198.51.100.100
-D /niscu/new_TH2U
-F niscu_cli_remsharefile1 -T scp -U user3 -W passwd2 -x 198.51.100.254
-y /niscu/new_TH2U
-z conf_file -j sftp -b abcd -e passwd -f log_latest
```

Example 2: Options for Custom Installation

In this example, the command options help in custom installation of Windows on 198.51.100.10. The SCU ISO image is located in 198.51.100.100. The conf_file is placed in 198.51.100.100. The answer file required for custom installation is located in 198.51.100.110, and is named win_answer_file. The OS Installation log files are saved in 198.51.100.254. The NI-SCU script log files are saved in the same client system where the script is executed.

```
python3 os_install.py -a 198.51.100.10 -u user1 -p passwd
-m ucs-cxxx-scu-6.2.xx.iso -o vmedia -i 198.51.100.100
-d /utils_share/scu/kb -t nfs -r user2 -w passwd1 -q 120 -I 198.51.100.100
-D /niscu/new_TH2U
-F niscu_cli_remsharefile1 -T scp -U user3 -W passwd2 -x 198.51.100.254
-y /niscu/new_TH2U
-z conf_file -j sftp -b abcd -e passwd -X 198.51.100.254
-Y /niscu/answer_files
-Z rhel.cfg -J sftp -B user4 -E passwd-f log_latest
```

Sample nwboot.cfg file

Sample nwboot.cfg file

```
{
  "Update_Timeout": 240,
  "SCURepository": {
    "BootMedium": {
      "VMEDIA": {
        "ImageRepository": "10.10.10.1/home/nfsshare/iso/scu.iso",
        "TransferProtocol": "nfs",
        "Username": "root",
        "Password": "password",
        "MountOptions": ""
      },
      "HTTP": {
        "ImageRepository": "http://10.10.10.1:80/iso/scu.iso",
        "MACAddress": "70:df:2f:86:af:02",
        "PCIEslot": "L",
        "PhysicalPortNumber": 1,
        "IPv4Address": {
          "AddressOrigin": "Static",
          "Address": "10.104.255.179",
          "Gateway": "10.104.255.129",
          "SubnetMask": "255.255.255.128",
          "StaticNameServer": "64.104.76.247"
        },
        "IPv6Address": {
          "AddressOrigin": "DHCPv6",
          "Address": "Fc00:1234::a:b:c:d",
          "PrefixLength": 64,
          "Gateway": "fe80::fe15:b4ff:fe97:90cd",
          "StaticNameServer": "fe80::fe15:b4ff:fe97:90cd"
        }
      },
      "FLEXMMC": {
        "ImageRepository": "scu.iso"
      },
      "MICROSD": {},
      "PXE": {
        "ImageRepository": "ftp://10.104.255.224/pub/scu",
        "MACAddress": "70:df:2f:86:af:02",
        "PCIEslot": "L",
        "PhysicalPortNumber": 1,
        "IPv4Address": {
          "AddressOrigin": "DHCP"
        }
      },
      "IPXE": {
        "ImageRepository": "http://10.10.10.1/iso/scu.iso",
        "MACAddress": "70:df:2f:86:af:02",
        "PCIEslot": "L",
        "PhysicalPortNumber": 1
      }
    }
  },
  "OSDetails": {
    "OSRepository": {
      "MediaType": "Local",
      "BootMedium": {
```

```

        "VMEDIA": {
            "ImageRepository":
"10.10.10.1/home/nfsshare/iso/rhel/RHEL-8.5.0-20211013.2-x86_64-dvd1.iso",
            "TransferProtocol": "nfs",
            "Username": "root",
            "Password": "password",
            "MountOptions": ""
        }
    },
    "TargetOS": {
        "OSName": "rhel8u5x64",
        "OSEdition": "None"
    }
},
"TargetDisk": {
    "PHYSICALDISK": {
        "DriveSerialNumber": "06VSGVVB"
    },
    "VIRTUALDISK": {
        "StorageControllerSlotID": "MRAID",
        "VirtualDriveNumber": 0
    },
    "DISKNAME": {
        "OSDrive": "/dev/sdk"
    },
    "VIRTUALDRIVENAME": {
        "VirtualDriveName": "Hypervisor"
    },
    "ONBOARDSATAM2SSD": {
        "SATAM2SSD": "slot1"
    },
    "M2SWVDNAME": {
        "M2SWRAIDName": "RAID0"
    },
    "FC": {
        "HostWWPN": "10:00:54:88:DE:A7:32:6F",
        "TargetWWPN": "50:06:01:68:3E:A0:62:22",
        "Lun": 200
    },
    "ISCSI": {
        "MACAddress": "70:DF:2F:86:AE:FD",
        "PrimaryTargetName":
"iqn.2001-05.com.equallogic:0-af1ff6-082b3ebe6-cf2005780845d665-iqn.siva-25.com",
        "PrimaryLUN": 1
    }
},
"RemoteLog": {
    "ImageRepository": "10.10.10.10/home/nfstest/scu.log",
    "TransferProtocol": "scp",
    "Username": "root",
    "Password": "john123"
},
"AnswerFile": {
    "ImageRepository": "10.10.10.10/home/nfstest/answerfile",
    "TransferProtocol": "scp",
    "Username": "root",
    "Password": "john123"
}
}

```


Sample conf_file and niscu.cfg files

Sample conf file

```
shareMapType:www
shareIp:10.10.10.10
sharePath:/path/to/iso
shareFile:rhel66.iso
userName:www
password:www
osName:rhel6u6x64
osDrive:/dev/sdk

DriveSerialNumber:Z1W4AC480000Z610ABCD

StorageControllerSlotID:MRAID

VirtualDriveNumber:0

VirtualDriveName:Hypervisor
SATAM2SSD:slot1
M2SWRAIDName:RAID00
Edition:STANDARD
```

Sample niscu.cfg file

```
#
# This file is just a template file and suggest user not to use this file directly without
# deleting comments and other info
#
# User has to create their own config file instead of using this.
#
#
[defaults]
use_http_secure=yes
update_timeout=120

[scu_iso]
isoshareip=10.10.10.10
isosharepath=/path/to/file
imagefile=ucs-cxx-scu.iso
isosharetype=www
isoshareuser=root
isosharepassword=password
mountoption=noauto # Multiple mount options shall be passed as a comma separated list.
Example - nolock,rw
bootmedium=vmedia # Value shall be vmedia - to boot from vmedia or flexmmc- to boot
from eMMC or microsd - to boot from microsd

##### Section to store SCU NI-OSI logs on Remote Server #####

[output_location]
remshareip=10.10.10.10
remsharepath=/path/to/file
remsharefile=share_file
remsharetype=scp/sftp
remshareuser=root
remsharepassword=password

#####Section for one server starts here#####
```

```

[rhel_iso]
ip=10.10.10.10
path=/path/to/conf_file
file=conf_file
username=root
password=password
protocol=scp # supports scp, sftp, tftp and www

[rhel_answerfile]
ip=10.10.10.10
path=/path/to/answer_file
file=rhel66_custom.ks#Keep this field blank for quick install else give name of kickstart
file to perform Custom install for RHEL,CENT, SLES, Ubuntu
username=root
password=password
protocol=scp # supports scp, sftp, tftp and www

##### Section for Network Boot Support starts here #####
[nios_install]
niosremoteshareip=10.10.10.10
niosremotesharepath=/home/nfstest/config #config templete file path for scu boot from network
location
niosremotesharefile=nwboot.cfg #config template file for scu boot from network location
niosremotesharetype=scp
niosusername=root
niospassword=Ucsrcak4All
niosscubootmedium=pxe #type of the boot pxe/http/ipxe
niososbootmedium=vmedia #currently only vmedia is supported
niostargetdisktype=physicaldisk #target disk details

[cimc_1]
address=10.10.10.10
user=admin
password=password
imagefile=ucs-cxx-scu.iso
config_section=rhel_iso
answerfile_section=rhel_answerfile #Mandatory for Custom Install for RHEL,CENT, SLES and
Ubuntu. Remove this line, to perform Quick install.
nios_section=nios_install #nios_install section, if this section is present then it takes
the priority over scu_iso section.
servernode=1/2/all # For Colusa2 .

#servernode option to be passed only in case of colusa2 For other server dont specify this
option
#####Section for one server ends here#####
#####
#### To trigger os installation for multiple servers simply repeate above section with
details for other server
#### and OS, also define separate conf_file for other server
#####

```



CHAPTER 8

Configuring RAID Levels

- [RAID Configuration, on page 61](#)
- [Storage Configuration, on page 61](#)
- [Creating RAID Arrays, on page 63](#)

RAID Configuration

You can use the RAID Configuration functionality to configure the on-board or PCIe supported RAID controller cards.

If your system has multiple RAID controllers, UCS-SCU displays a list of all available RAID cards, and physical and logical disks on the RAID Configuration page.

The following RAID configuration options are available:

- Single RAID levels—RAID 0, RAID 1, RAID 5 and RAID 6
- Nested RAID levels—RAID 10, RAID 50 and RAID 60

Storage Configuration

RAID Configuration page contains the following components:

Table 30: RAID Configuration Page

Component	Description
Physical Disks Area	Contains the list of physical disk available in the server in table format. See Physical Disks Area, on page 62 .
Logical Disks Area	Contains the list of virtual disk available in the server in table format. See Logical Disks Area, on page 63 .
Create RAID button	You can use this feature to create new RAIDs. See Configuring Single-Level RAID, on page 63 and Configuring Nested RAID, on page 64 .

Component	Description
Delete RAID button	You can use this feature to delete an existing RAID. To delete an existing RAID, select it from the Logical Disks area and click Delete .
Refresh button	You can use this feature to refresh the RAID list.

Physical Disks Area

The Physical Disks table in the RAID Configuration page lists the following:

Table 31: Physical Disks

Column	Description
Enc ID	The identifying number of the physical disk.
Slot ID	The slot in which the physical disk belongs.
Device Node	The device node in which the physical disk belongs.
Size (MB)	The size of the physical disk.
Serial No	The status of the disk. For more information see .
State	The status of the disk. For more information, see Table 32: Disk State Condition, on page 62 .
Block Size	The block size of the physical disk.
Type	Type of physical disk.

Table 32: Disk State Condition

Status	Description
Online	The drive is already used in another array.
Global Hotspare	The drive will be used to repair any array in the system that had a drive failure, if the failed drive is equal to, or smaller than the hot spare drive.
Un-configured Good	The drive is unused or available.
Ready	The drive is online and operating correctly.
Offline	The drive is offline or absent. No actions can be performed on the drive until it is back online.
Un-configured Bad	The drive is not operational and needs to be replaced. Disks with a status of "Unconfigured bad" cannot be used for RAID configurations.

Status	Description
Foreign	The drive is part of an array created on a different controller, or created within one enclosure and moved to another on the same controller. It can be used to create a new array after clearing the configuration.

Logical Disks Area

The Logical Disks table in the RAID Configuration page lists the following:

Table 33: Logical Disks

Column	Description
Select check box	Select check box is used to select one or more disk.
VD No	The identifying number of the VD.
Name	Name of the VD.
Device Node	The device node in which the VD belongs.
Size (MB)	Logical drive size. The maximum value depends on RAID level selected and the physical disks size involved.
RAID Level	RAID 0 (Data striping), 1 (Disk Mirroring), 5 (Data Striping with Striped Parity), 6 (Distributed Parity and Disk Striping).
RAID PDs	Physical disk to which the VDs belong.

Creating RAID Arrays

Configuring Single-Level RAID

Procedure

-
- Step 1** Select **Server Configuration > Storage Configuration** from the navigation pane
The **RAID Configuration** window is displayed.
- Step 2** Click **Create RAID**.
The **Configure RAID** page is displayed.
- Step 3** From the **RAID** drop-down list, select a RAID level (0 or 1 or 5 or 6).

Step 4 From the Physical Disks list on the left side, select the physical disks that you want to include in the Drive Groups list.

Table 34: Minimum Number of Required Physical Drives

RAID Level	Number of Physical Disks Required
RAID 0	1
RAID 1	2
RAID 5	3
RAID 6	4

Step 5 Enter the following information:

Field	Description
Name field	Enter a name of the RAID.
Read Policy drop-down list	From the Read Policy list, choose a read policy for the RAID level.
Disk Cache Policy drop-down list	From the Disk Cache Policy list, choose a disk cache policy for the RAID level.
Stripe Size (KB) drop-down list	From the Stripe Size list, choose a stripe size for the RAID level.
Access Policy drop-down list	From the Access Policy list, choose an access policy for the RAID level.
Cache Policy drop-down list	From the Cache Policy list, choose a cache policy for the RAID level.
Write Policy drop-down list	From the Write Policy list, choose a write policy for the RAID level.
Size field and Unit drop-down list	In the Size text field, enter the size of the logical disk and from the unit drop-down list, select the unit.

Step 6 Click **OK**.

Note

The Create Drive Group button remains disabled until the minimum number of physical disks for a RAID level is selected.

The selected physical disks are included in the Drive Groups list.

Configuring Nested RAID

Nested RAID levels have primary and secondary RAID levels. You should create a minimum of two drive groups in nested RAID levels and the drive groups should have the same number of physical disks.

Procedure

Step 1 Select **Server Configuration > Storage Configuration** from the navigation pane

The **RAID Configuration** window is displayed.

Step 2 Click **Create RAID**.

The **Configure RAID** page is displayed.

Step 3 From the **RAID** drop-down list, select a nested RAID level (10 or 50 or 60).

Step 4 From the **Physical Disks** list, select the physical disks that you want to include in the Drive Groups list.

Table 35: Minimum Number of Required Physical Drives and Data Groups

RAID Level	Minimum Number of Physical Disks	Minimum Number of Data Groups
RAID 10	4	2
RAID 50	6	2
RAID 60	8	2

Step 5 Enter the following information:

Field	Description
Name field	Enter a name of the RAID.
Read Policy drop-down list	From the Read Policy list, choose a read policy for the RAID level.
Disk Cache Policy drop-down list	From the Disk Cache Policy list, choose a disk cache policy for the RAID level.
Stripe Size (KB) drop-down list	From the Stripe Size list, choose a stripe size for the RAID level.
Access Policy drop-down list	From the Access Policy list, choose an access policy for the RAID level.
Cache Policy drop-down list	From the Cache Policy list, choose a cache policy for the RAID level.
Write Policy drop-down list	From the Write Policy list, choose a write policy for the RAID level.
Size field and Unit drop-down list	In the Size text field, enter the size of the logical disk and from the unit drop-down list, select the unit.

Step 6 Click **OK**.

Note

The Create Drive Group button remains disabled until the minimum number of physical disks for a RAID level is selected.

The selected physical disks are included in the Drive Groups list.
