



capwap Commands

- [capwap ap](#), on page 1
- [capwap ap auth-token](#), on page 2
- [capwap ap erase](#), on page 2
- [capwap ap ethernet](#), on page 3
- [capwap ap hostname](#), on page 3
- [capwap ap ip](#), on page 4
- [capwap ap lag](#), on page 4
- [capwap ap mesh strict-wired-uplink](#), on page 5
- [capwap ap mode](#), on page 6
- [capwap ap restart](#), on page 6

capwap ap

To configure the primary, secondary and tertiary controllers for the AP, use the **capwap ap** command.

```
capwap ap {primary-base | secondary-base | tertiary-base}  
controller-name controller-ip-address
```

Syntax Description		
	primary-base	Configure AP's primary controller
	secondary-base	Configure AP's secondary controller
	tertiary-base	Configure AP's tertiary controller
	<i>controller-name</i>	Name of the controller
	<i>controller-ip-address</i>	IP address of the controller.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	8.1.111.0	This command was introduced.

Examples

The following example shows how to configure the primary controller for the AP:

```
cisco-ap# capwap ap primary-base wlc-5520 209.165.200.224
```

capwap ap auth-token

To configure authentication token, use the **capwap ap auth-token** command.

```
capwap ap auth-token ssc-token
```

Syntax Description	<i>ssc-token</i> SSC token; valid range is 8 to 32 characters
Command Modes	Privileged EXEC (#)
Command History	Release Modification
	8.1.111.0 This command was introduced.

Examples

The following example shows how to configure authentication token,:

```
cisco-ap# capwap ap auth-token myauthtoken
```

capwap ap erase

To erase CAPWAP configuration, use the **capwap ap erase** command.

```
capwap ap erase {all | static-ip}
```

Syntax Description	all Erases all CAPWAP configuration
	Note If the AP is in Bridge mode, then the same Bridge mode is retained after the factory reset of the AP; if the AP is in FlexConnect, Local, Sniffer, or any other mode, then the AP mode is set to Local mode after the factory reset of the AP. If you press the Reset button on the AP and perform a true factory reset, then the AP moves to a cookie configured mode.
	static-ip Erase static IP or DNS configuration
Command Modes	Privileged EXEC (#)

Command History**Release Modification**

8.1.111.0 This command was introduced.

Examples

The following example shows how to erase all the CAPWAP configuration on the AP:

```
cisco-ap# capwap ap erase all
```

capwap ap ethernet

To configure AP Ethernet parameters, use the **capwap ap ethernet** command.

capwap ap ethernet tag *ethernet-vlan-id*

Syntax Description

ethernet-vlan-id Ethernet VLAN ID; valid range is 0 to 4094. If you enter the VLAN ID value as 0, the VLAN tagging is disabled.

Command Modes

Privileged EXEC (#)

Command History**Release Modification**

8.1.111.0 This command was introduced.

Examples

The following example shows how to configure Ethernet VLAN tagging on the AP:

```
cisco-ap# capwap ap ethernet tag 2
```

capwap ap hostname

To configure AP hostname, use the **capwap ap hostname** command.

capwap ap hostname *ap-name*

Syntax Description

ap-name AP name

Command Modes

Privileged EXEC (#)

Usage Guidelines

If the AP is already associated with a Cisco WLC, the new hostname is reflected on the Cisco WLC only after the AP dissociates and reassociates with the Cisco WLC.

Command History	Release	Modification
	8.1.111.0	This command was introduced.

Examples

The following example shows how to configure a hostname for the AP:

```
cisco-ap# capwap ap hostname cisco-wave2-ap-2802
```

capwap ap ip

To configure static IP address and DNS for the CAPWAP AP, use the **capwap ap ip** command.

```
capwap ap ip static-ip-addr static-netmask ip-addr-default-gateway [ip-addr-dns1 | ip-addr-dns2] [domain-name]
```

Syntax	Description
<i>static-ip-addr</i>	Static IP address of the AP
<i>static-netmask</i>	Static netmask
<i>ip-addr-default-gateway</i>	IP address of the default gateway
[<i>ip-addr-dns1</i> <i>ip-addr-dns2</i>]	(Optional parameters) IP address(es) of the DNS
[<i>domain-name</i>]	(Optional parameter) Domain name

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	8.1.111.0	This command was introduced.

Examples

The following example shows how to configure static IP address and DNS for the CAPWAP AP:

```
cisco-ap# capwap ap ip 209.165.200.225 255.255.255.224 209.165.200.227 209.165.200.226 example.org
```

capwap ap lag

To configure CAPWAP lag, use the **capwap ap lag** command.

```
capwap ap lag {enable | disable}
```

Syntax Description	enable Enables LAG
	disable Disables LAG

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	8.1.111.0	This command was introduced.

Examples

The following example shows how to enable LAG on the AP:

```
cisco-ap# capwap ap lag enable
```

capwap ap mesh strict-wired-uplink

To configure the root access points (RAPs) to stay as persistent RAPs even if the wired uplink is lost, use the **capwap ap mesh strict-wired-uplink** command.

capwap ap mesh strict-wired-uplink {enable | disable}

Syntax Description	enable Enables strict wired uplink on the Cisco AP.
	disable Disables strict wired uplink on the Cisco AP.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	8.9 Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

Examples

The following example shows how to enable the root access points (RAPs) to stay as persistent RAPs even if the wired uplink is lost:

```
cisco-ap# capwap ap mesh strict-wired-uplink enable
```

capwap ap mode

To configure AP mode, use the **capwap ap mode** command.

```
capwap ap mode { bridge | local }
```

Syntax Description	bridge Enables bridge mode
	local Enables local mode
Command Modes	Privileged EXEC (#)
Command History	Release Modification
	8.1.111.0 This command was introduced.

Examples

The following example shows how to configure the AP to operate in local mode:

```
cisco-ap# capwap ap mode local
```

capwap ap restart

To restart the CAPWAP protocol, use the **capwap ap restart** command.

```
capwap ap restart
```

Syntax Description	restart Restart the CAPWAP protocol
Command Modes	Privileged EXEC (#)
Command History	Release Modification
	8.1.111.0 This command was introduced.

Examples

The following example shows how to restart CAPWAP protocol:

```
cisco-ap# capwap ap restart
```