

6-GHz Band Operations

The following topics describe the features that are specific to 6-GHz band radio:

- Configuring Preferred Scanning Channels in the RF Profile (GUI), on page 1
- Configuring Preferred Scanning Channels in the RF Profile (CLI), on page 2
- Configuring Broadcast Probe Response in RF Profile (GUI), on page 2
- Configuring Broadcast Probe Response in RF Profile (CLI), on page 2
- Configuring FILS Discovery Frames in the RF Profile (GUI), on page 3
- Configuring FILS Discovery Frames in the RF Profile (CLI), on page 4
- Configuring Multi BSSID Profile (GUI), on page 4
- Configuring Multi BSSID Profile, on page 5
- Configuring Multi-BSSID in the RF Profile (GUI), on page 5
- Configuring Multi-BSSID in the RF Profile (CLI), on page 6
- Configuring Dynamic Channel Assignment Freeze (CLI), on page 6
- Information About 6-GHz Client Steering, on page 7

Configuring Preferred Scanning Channels in the RF Profile (GUI)

Step 1	Choose Configuration > Tags & Profiles > RF/Radio.	
Step 2	In the RF tab, click Add . The Add RF Profile page is displayed.	
Step 3	Choose the RRM tab.	
Step 4	Choose the DCA tab.	
Step 5	In the Dynamic Channel Assignment section, select the required channels in DCA Channels section.	
Step 6	In the PSC Bias field, click the toggle button to enable the preferred scanning channel bias for DCA.	
Step 7	Click Apply to Device.	

Configuring Preferred Scanning Channels in the RF Profile (CLI)

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	ap dot11 6ghz rf-profile rf-profile-name	Configures an RF profile and enters RF profile
	Example:	configuration mode.
	<pre>Device(config)# ap dot11 6ghz rf-profile rf-profile-name</pre>	
Step 3	channel psc	Configures the RF Profile DCA settings and
	Example:	enables the preferred scanning channel bias for
	Device(config-rf-profile)# channel psc	

Configuring Broadcast Probe Response in RF Profile (GUI)

Procedure

Step 1	Choose Configuration > Tags & Profiles > RF/Radio.	
Step 2	In the RF tab, click Add . The Add RF Profile page is displayed.	
Step 3	Choose the 802.11ax tab.	
Step 4	In the 6 GHz Discovery Frames section, click the Broadcast Probe Response option.	
Step 5	In the Broadcast Probe Response Interval field, enter the broadcast probe response time interval in milli-seconds (ms). The value range is between 5 ms and 25 ms. The default value is 20 ms.	
Step 6	Click Apply to Device.	

Configuring Broadcast Probe Response in RF Profile (CLI)

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	

	Command or Action	Purpose
	Device# configure terminal	
Step 2	ap dot11 6ghz rf-profile rf-profile-name	Configures an RF profile and enters RF profile configuration mode.
	Example:	
	<pre>Device(config)# ap dot11 6ghz rf-profile rf-profile-name</pre>	
Step 3	dot11ax bcast-probe-response	Configures broadcast probe response.
	Example:	
	<pre>Device(config-rf-profile)# dot11ax bcast-probe-response</pre>	
Step 4	dot11ax bcast-probe-response time-interval	Configures broadcast probe response interval.
	time-interval	
	Example:	
	Device(config-rf-profile)# dot11ax bcast-probe-response time-interval 20	

Configuring FILS Discovery Frames in the RF Profile (GUI)

Procedure

Step 1	Choose Configuration > Tags & Profiles > RF/Radio.	
Step 2	In the RF tab, click Add . The Add RF Profile page is displayed.	
Step 3	Choose the 802.11ax tab.	
Step 4	In the 6 GHz Discovery Frames section, click the FILS Discovery option.	
	Note To prevent the transmission of discovery FILS frames when the disco	

0 10 61

Note To prevent the transmission of discovery FILS frames when the discovery frames are set to **None** in the RF profile, ensure that you disable FILS discovery frames by either switching to the 5-GHz or the 2.4-GHz bands on the AP or by selecting the Broadcast Probe Response option.

DE/D

٦.

Step 5 Click Apply to Device.

I

Configuring FILS Discovery Frames in the RF Profile (CLI)

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	ap dot11 6ghz rf-profile rf-profile-name	Configures an RF profile and enters RF profile
	Example:	configuration mode.
	<pre>Device(config)# ap dot11 6ghz rf-profile rf-profile-name</pre>	2
Step 3	dot11ax fils-discovery	Configures the 802.11ax FILS discovery.
	Example: Device(config-rf-profile)# dot11ax fils-discovery	Note To prevent the transmission of discovery FILS frames when the discovery frames are set to None in the RF profile, ensure that you disable FILS discovery frames by either switching to the 5-GHz or the 2.4-GHz bands on the AP or by changing to Broadcast Probe Response.

Configuring Multi BSSID Profile (GUI)

Step 1	Choose Configuration > Tags & Profiles > Multi BSSID.		
Step 2	Click Add. The Add Multi BSSID Profile page is displayed.		
Step 3	Enter the name and the description of the BSSID profile.		
Step 4	Enter the following 802.11ax parameters:		
	a) Downlink OFDMA		
	b) Uplink OFDMA		
	c) Downlink MU-MIMO		
	d) Unlink MU-MIMO		

- d) Uplink MU-MIMO
- e) Target Waketime
- f) TWT Broadcast Support

Step 5 Click Apply to Device.

Configuring Multi BSSID Profile

To configure the multi BSSID profile for 6-Ghz band radio, follow the steps given below:

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	wireless profile multi-bssid multi-bssid-profile-name	Configures the multi BSSID profile. Enters the multi BSSID profile configuration.
	Example:	
	Device (config)# wireless profile multi-bssid multi-bssid-profile-name	
Step 3	dot11ax {downlink-mumimo downlink-ofdma target-waketime twt-broadcast uplink-mumimo uplink-ofdma}	Configures the 802.11ax parameters.
	Example:	
	Device (config-wireless-multi-bssid-profile)# dotllax downlink-mumimo	

Configuring Multi-BSSID in the RF Profile (GUI)

Step 1	Choose Configuration > Tags & Profiles > RF/Radio.	
Step 2	In the RF tab, click Add .	
	The Add RF Profile page is displayed.	
Step 3	Choose the 802.11ax tab.	
Step 4	In the Multi BSSID Profile field, choose the profile from the drop-down list.	
Step 5	Click Apply to Device.	
Step 5	Click Apply to Device .	

Configuring Multi-BSSID in the RF Profile (CLI)

Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	ap dot11 6ghz rf-profile rf-profile-name	Configures an RF profile and enters RF profile
	Example:	configuration mode.
	<pre>Device(config)# ap dot11 6ghz rf-profile rf-profile-name</pre>	
Step 3	dot11ax multi-bssid-profile multi-bssid-profile-name	Configures 802.11ax multi BSSID profile name, in the RF profile configuration mode.
	Example:	
	<pre>Device(config-rf-profile)# dotllax multi-bssid-profile multi-bssid-profile-name</pre>	

Configuring Dynamic Channel Assignment Freeze (CLI)

When the 6-GHz radios receive the right channels, disable DCA for 6-GHz by issuing the following command:

Before you begin

Ensure that Dynamic Channel Assignment (DCA) for 6-GHz is enabled. Wait for the 6-GHz radios to get stabilized with the right set of channel assignments.

	Command or Action	Purpose
Step 1	no ap dot11 6ghz rrm channel dca global auto	Disables DCA for 6-GHz bands.
	Example:	
	Device# no ap dotl1 6ghz rrm channel dca global auto	

Information About 6-GHz Client Steering

The 6-GHz band provides more channels, more bandwidth, and has less network congestion when compared to the existing 2.4-GHz and 5-GHz bands. As a result, wireless clients that are 6-GHz capable connect to the 6-GHz radio to take advantage of these benefits.

This topic provides details about 6-GHz client steering for APs supporting 6-GHz band.

The 6-GHz client steering takes place when the controller receives a periodic client statistics report from the 2.4-GHz band or the 5-GHz band. The client steering configuration is enabled under WLAN, and is configured only for clients that are 6-GHz capable. If a client in the report is 6-GHz capable, then client steering is triggered, and the client is steered to the 6-GHz band.

Configuring 6-GHz Client Steering in the Global Configuration Mode (GUI)

Procedure

Step 1	Choose Configuration > Wireless > Advanced .		
Step 2	Click the 6 GHz Client Steering tab. Client steering is configurable per WLAN.		
Step 3	In the 6 GHz Transition Minimum Client Count field, enter a value to set the minimum number of clients for client steering. The default value is three clients. The value range is between 0 and 200 clients.		
Step 4	In the 6 GHz Transition Minimum Window Size field, enter a value to set the minimum window size of client steering. The default value is three clients. The value range is between 0 and 200 clients.		
Step 5	In the 6 GHz Transition Maximum Utilization Difference field, enter a value to set the maximum utilization difference for steering. The value range is between 0 percent to 100 percent. The default value is 20.		
Step 6	In the 6 GHz Transition Minimum 2.4 GHz RSSI Threshold field, enter a value to set the minimum value for client steering 2.4-GHz RSSI threshold.		
Step 7	In the 6 GHz Transition Minimum 5 GHz RSSI Threshold field, enter a value to set the minimum value for client steering 5-GHz RSSI threshold.		
Step 8	Click Apply.		

Configuring 6-GHz Client Steering in the Global Configuration Mode

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		

I

	Command or Action	Purpose	
Step 2	wireless client client-steering client-count min-num-clients	Sets the minimum number of clients for client steering. The value range is between 0 and 200.	
	Example:		
	Device(config)# client-steering client-count 3		
Step 3	wireless client client-steering window-size window-size	Sets the minimum window size of client steering. The value range is between 0 and 200.	
	Example:		
	Device(config)# client-steering window-size 5		
Step 4	wireless client client-steering util-threshold	Sets the maximum channel utilization difference	
		value range is between 0 to 100 percent.	
	Example:		
	Device(config)# wireless client client-steering util-threshold 25		
Step 5	wireless client client-steering min-rssi-24ghz -70	Sets the minimum value for client steering the 2.4-GHz RSSI threshold.	
	Example:		
	Device(config)# wireless client client-steering min-rssi-24ghz -70		
Step 6	wireless client client-steering min-rssi-5ghz -75	Sets the minimum value for client steering the 5-GHz RSSI threshold.	
	Example:		
	Device(config)# wireless client client-steering min-rssi-5ghz -75		

Configuring 6-GHz Client Steering on the WLAN (GUI)

Procedure

Step 1	Choose Configuration > Tags & Profiles > WLANs.
Step 2	Click Add.
	The Add WLAN page is displayed.
Step 3	Click the Advanced tab.
Step 4	Check the 6 GHz Client Steering check box to enable client steering on the WLAN.
Step 5	Click Apply to Device.

L

Configuring 6-GHz Client Steering on the WLAN

Procedure

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	wlan wlan-name wlan-id SSID-name	Enters WLAN configuration submode.	
	Example:		
	Device(config)# wlan <i>wlan-name</i> 18 <i>ssid-name</i>		
Step 3	client-steering	Configures 6-GHz client steering on the WLAN.	
	Example:		
	Device(config-wlan)# client-steering		

Verifying 6-GHz Client Steering

To verify client steering, run the following commands:

```
Device# show wlan wlan-id
WLAN Profile Name : wlan1
_____
Identifier
                                           : 1
Description
                                            :
Network Name (SSID)
                                           : ssid-demo
Status
                                           : Disabled
Broadcast SSID
                                            : Enabled
٠
6Ghz Client Steering
                                           : Enabled
.
Device# show wireless client steering
Client Steering Configuration Information
                                                  : -55 dBm
 Macro to micro transition threshold
 Micro to Macro transition threshold
                                                  : -65 dBm
                                                  : 3
 Micro-Macro transition minimum client count
 Micro-Macro transition client balancing window
                                                  : 3
  Probe suppression mode
                                                   : Disabled
                                                  : 3
 Probe suppression transition aggressiveness
 Probe suppression hysteresis
                                                  : -6 dB
  6Ghz transition minimum client count
                                                  : 3
  6Ghz transition minimum window size
                                                  : 3
                                              : 20%
: -60 dBm
  6Ghz transition maximum channel util difference
  6Ghz transition minimum 2.4Ghz RSSI threshold
  6Ghz transition minimum 5Ghz RSSI threshold
                                                 : -65 dBm
```

WLAN Configuration Information

I

WLAN	Profile Name	11k Neighbor Report	11v BSS Transition
12	testl	Enabled	Enabled
8	test	Enabled	Enabled