



Slot and Subslot Configuration

This chapter contains information on slots and subslots. Slots specify the chassis slot number in your device and subslots specify the slot where the service modules are installed.

For further information on the slots and subslots, see the “About Slots and Interfaces” sections:

- [Hardware Installation Guide for Cisco Catalyst 8300 Series Edge Platforms](#)
- [Hardware Installation Guide for Cisco Catalyst 8200 Series Edge Platforms](#)

The following section is included in this chapter:

- [Configuring the Interfaces, on page 1](#)

Configuring the Interfaces

The following sections describe how to configure Gigabit interfaces and also provide examples of configuring the router interfaces:

- [Configuring Gigabit Ethernet Interfaces, on page 1](#)
- [Configuring the Interfaces: Example, on page 3](#)
- [Viewing a List of All Interfaces: Example, on page 3](#)
- [Viewing Information About an Interface: Example, on page 4](#)

Configuring Gigabit Ethernet Interfaces

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface GigabitEthernet *slot/subslot/port***
4. **ip address *ip-address mask* [secondary] dhcp pool**
5. **negotiation auto**
6. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: <pre>Router> enable</pre>	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	configure terminal Example: <pre>Router# configure terminal</pre>	Enters global configuration mode.
Step 3	interface GigabitEthernet slot/subslot/port Example: <pre>Router(config)# interface GigabitEthernet 0/0/1</pre>	Configures a GigabitEthernet interface. <ul style="list-style-type: none"> • GigabitEthernet—Type of interface. • <i>slot</i>—Chassis slot number. • <i>/subslot</i>—Secondary slot number. The slash (/) is required. • <i>/port</i>—Port or interface number. The slash (/) is required.
Step 4	ip address ip-address mask [secondary] dhcp pool Example: <pre>Router(config-if)# ip address 10.0.0.1 255.255.255.0 dhcp pool</pre>	Assigns an IP address to the GigabitEthernet <ul style="list-style-type: none"> • ip address ip-address—IP address for the interface. • <i>mask</i>—Mask for the associated IP subnet. • secondary (optional)—Specifies that the configured address is a secondary IP address. If this keyword is omitted, the configured address is the primary IP address. • dhcp—IP address negotiated via DHCP. • pool—IP address autoconfigured from a local DHCP pool.
Step 5	negotiation auto Example: <pre>Router(config-if)# negotiation auto</pre>	Selects the negotiation mode. <ul style="list-style-type: none"> • auto—Performs link autonegotiation.
Step 6	end Example: <pre>Router(config-if)# end</pre>	Ends the current configuration session and returns to privileged EXEC mode.

Configuring the Interfaces: Example

The following example shows the **interface gigabitEthernet** command being used to add the interface and set the IP address. **0/0/0** is the slot/subslot/port. The ports are numbered 0 to 5.

```
Router# show running-config interface gigabitEthernet 0/0/0
Building configuration...
Current configuration : 71 bytes
!
interface gigabitEthernet0/0/0
no ip address
negotiation auto
end

Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface gigabitEthernet 0/0/0
```

Viewing a List of All Interfaces: Example

In this example, the **show platform software interface summary**, **show interfaces summary**, and **show platform software status control-process brief** commands are used to display all the interfaces:

```
Router# show platform software interface summary
Interface                IHQ  IQD  OHQ  OQD  RXBS  RXPS  TXBS  TXPS  TRTL
-----
* GigabitEthernet0/0/0    0    0    0    0    0    0    0    0    0
* GigabitEthernet0/0/1    0    0    0    0    0    0    0    0    0
* GigabitEthernet0/0/2    0    0    0    0    0    0    0    0    0
* GigabitEthernet0/0/3    0    0    0    0    0    0    0    0    0
* Te0/0/4                  0    0    0    0    0    0    0    0    0
* Te0/0/5                  0    0    0    0    0    0    0    0    0
```

```
Router# show interfaces summary
```

```
*: interface is up
IHQ: pkts in input hold queue      IQD: pkts dropped from input queue
OHQ: pkts in output hold queue     OQD: pkts dropped from output queue
RXBS: rx rate (bits/sec)           RXPS: rx rate (pkts/sec)
TXBS: tx rate (bits/sec)           TXPS: tx rate (pkts/sec)
TRTL: throttle count
```

```
Interface                IHQ  IQD  OHQ  OQD  RXBS  RXPS  TXBS  TXPS  TRTL
-----
* GigabitEthernet0/0/0  0    0    0    0    0    0    0    0    0
* GigabitEthernet0/0/1  0    0    0    0    0    0    0    0    0
* GigabitEthernet0/0/2  0    0    0    0    0    0    0    0    0
* GigabitEthernet0/0/3  0    0    0    0    0    0    0    0    0
* Te0/0/4                0    0    0    0    0    0    0    0    0
* Te0/0/5                0    0    0    0    0    0    0    0    0
```

```
Router#show platform software status control-process brief
```

```
Load Average
Slot  Status  1-Min  5-Min  15-Min
RP0  Healthy  0.83   0.91   0.91
```

```
Memory (kB)
```

```
Slot  Status  Total    Used (Pct)    Free (Pct)  Committed (Pct)
RP0  Healthy  7768456  2654936 (34%)  5113520 (66%)  3115212 (40%)
```

```
CPU Utilization
```

Slot	CPU	User	System	Nice	Idle	IRQ	SIRQ	IOWait
RPO	0	2.70	1.70	0.00	95.59	0.00	0.00	0.00
	1	0.00	0.00	0.00	100.00	0.00	0.00	0.00
	2	0.00	0.00	0.00	100.00	0.00	0.00	0.00
	3	0.00	0.00	0.00	100.00	0.00	0.00	0.00
	4	2.40	1.40	0.00	96.19	0.00	0.00	0.00
	5	0.80	1.60	0.00	97.59	0.00	0.00	0.00
	6	12.40	12.30	0.00	75.30	0.00	0.00	0.00
	7	11.20	12.40	0.00	76.40	0.00	0.00	0.00
	8	2.80	1.80	0.00	95.40	0.00	0.00	0.00
	9	0.00	0.00	0.00	100.00	0.00	0.00	0.00
	10	0.00	0.00	0.00	100.00	0.00	0.00	0.00
	11	0.00	0.00	0.00	100.00	0.00	0.00	0.00

Viewing Information About an Interface: Example

The following example shows how to display a brief summary of an interface's IP information and status, including the virtual interface bundle information, by using the **show ip interface brief** command:

```
Router# show ip interface brief
GigabitEthernet0/0/0    10.10.3.1           YES NVRAM  up           up
GigabitEthernet0/0/1    192.0.5.2           YES NVRAM  up           up
GigabitEthernet0/0/2    192.0.2.5           YES NVRAM  down        down
GigabitEthernet0/0/3    unassigned          YES NVRAM  down        down
Te0/0/4                 unassigned          YES NVRAM  down        down
Te0/0/5                 10.20.4.8           YES NVRAM  down        down
Te0/1/0                 unassigned          YES NVRAM  down        down
```