



Cisco Nexus Dashboard Insights  
Integrations, Release 6.5.1 - For Cisco  
NDFC or Standalone NX-OS

# Table of Contents

New and Changed Information .....	2
Integrations .....	3
About Integrations .....	3
AppDynamics Integration .....	4
About AppDynamics Integration .....	4
Guidelines and Limitations .....	5
Installing AppDynamics .....	5
Onboard AppDynamics Controller .....	6
Cisco Nexus Dashboard Insights and AppDynamics Integration Dashboard .....	7
AppDynamics Integration Application .....	7
Topology View .....	8
vCenter Integration .....	10
About VMware vCenter Server Integration .....	10
Prerequisites .....	10
Guidelines and Limitations .....	10
Add vCenter Server Integration .....	11
vCenter Virtual Machine Dashboard .....	11
vCenter Hosts Dashboard .....	16
DNS Integration .....	24
About DNS Integration .....	24
Guidelines and Limitations .....	26
Configure DNS .....	26
Panduit PDU Integration .....	29
Panduit PDU Integration .....	29
Prerequisites .....	29
Guidelines and Limitations .....	29
Add PDU Integration .....	30
View PDU Integration .....	31
Copyright .....	34

First Published: 2024-06-28

**Americas Headquarters**

Cisco Systems, Inc.

170 West Tasman Drive

San Jose, CA 95134-1706

USA

<http://www.cisco.com>

Tel: 408 526-4000

800 553-NETS (6387)

Fax: 408 527-0883

# New and Changed Information

The following table provides an overview of the significant changes up to the current release. The table does not provide an exhaustive list of all changes or of the new features up to this release.

## *New Features and Changed Behavior in the Cisco Nexus Dashboard Insights*

<b>Feature</b>	<b>Description</b>	<b>Release</b>	<b>Where Documented</b>
Terminology change	The term "sites" is renamed to "fabrics".	6.5.1	Entire document

This document is available from your Nexus Dashboard Insights GUI as well as online at [www.cisco.com](http://www.cisco.com). For the latest version of this document, visit [Cisco Nexus Dashboard Insights Documentation](#).

# Integrations

## About Integrations

Navigate to **Admin > Integrations**.

**Integrations**

Integrations Add Integration

Name	Connectivity Status	Type	IP	Last Active	Associations
<a href="#">sjc18_vc</a>	<span>Active</span>	vCenter	[Redacted]	Feb 02 2024 09:51:08.892 AM	DC-NDI-A04 ...
<a href="#">appd</a>	<span>Active</span>	AppDynamics	[Redacted]	Feb 02 2024 09:51:08.663 AM	DC-NDI-A04 ...

All the integrations are listed in a tabular form with the following fields:

- Name
- Connectivity Status
- Type
- IP
- Last Active
- Associations

The connected status indicates that the controller is active to fetch data. The down status indicates that the Nexus Dashboard Insights will not fetch data from the controller. Use the filter bar to search for a specific integration. You can filter based on the name and type of integration.

- Click **Add Integration** to add a new integration.
- Click the ellipsis icon to perform to edit or delete an integration.
- Click the integration names to view further details about the integration. .



DNS Integration is not clickable and do not have any further information to display apart from the data available in the table.

## Guidelines and Limitations

- In Nexus Dashboard Insights, Integrations are supported on both Management and Data networks.
- By default, Nexus Dashboard Insights will use Data network to connect to the Integrations such as vCenter server, DNS, AppDynamics, Nexus Dashboard Orchestrator. If you want to use Management network, you can add a specific route in Nexus Dashboard's Admin Console from **Admin > System Settings > General > Routes**. The route can be a /32 pointing to Integrations or a larger subnet that includes it.

# AppDynamics Integration

## About AppDynamics Integration

Cisco Nexus Dashboard Insights provides insights to monitor the most common and complex challenges in the maintenance of infrastructure operations, which involves monitoring, troubleshooting, identification and resolving the network issues.

AppDynamics provides application performance management (APM) and IT operations analytics that helps manage the performance and availability of applications in the data center. It also provides the required metrics for monitoring, identifying, and analyzing the applications that are instrumented with AppDynamics agents.

AppDynamics is associated only at the Fabric level. Onboarding of the AppDynamics controller is only at the Fabric level.

AppDynamics hierarchy consists of the following components:

- Network Link—Provides the functional means to transfer data between network entities.
- Node—A working entity of an application and is a process running on a virtual machine.
- Tier—Grouping of nodes into a logical entity. Each tier can have one or more nodes.
- Application—A set of tiers make up an application.
- Controller—A controller consists of a set of accounts with each account comprising a list of applications. Each account in the controller is an instance.

Integrating AppDynamics allows Nexus Dashboard Insights to collect operational data and metrics of the applications monitored by AppDynamics, and then correlate the collected information with the data collected from the fabric nodes.

In a scenario where an application communicates through the fabric, AppDynamics provides various metrics about the application and the network, which can be used to isolate the cause of the anomaly. The anomaly can be in the application or the underlying network. This in turn allows network operators to monitor the network activity and detect anomalies.

The AppDynamics agents are plug-ins or extensions, hosted on the application. They monitor the health and performance of the network nodes and tiers with minimal overhead, which in turn report to the AppDynamics controller. The controller receives real-time metrics from thousands of agents and helps troubleshoot and analyze the flows.

Nexus Dashboard Insights connects to the AppDynamics controller and pulls the data periodically. This data from AppDynamics controller, rich in application specific information is fed to Nexus Dashboard Insights, thereby providing Cisco Nexus Dashboard Insights for the traffic flowing through the fabric nodes.

From AppDynamics, you can create your own health rule on the available metrics, which contributes to the overall anomaly score of the entity.

The integration of Nexus Dashboard Insights with AppDynamics enables the following:

- Monitoring and presenting AppDynamics hierarchy in Nexus Dashboard Insights.
- Gathering and importing network related metrics into Nexus Dashboard Insights.
- Presenting statistics analytics, flow analytics, and topology view on the data collected from AppDynamics controller.
- Detecting anomaly trends on metrics collected from AppDynamics controller and raising anomalies on detection of such events.
- The AppDynamics integration uses API server and multiple instances of Telegraph data collecting container to support load balancing of the onboarded controllers.
- Fabric flow impact calculation for AppDynamics anomalies.

## Onboarding for SaaS or Cloud Deployments

Starting from Nexus Dashboard Insights release 6.0.2, you can connect to an AppDynamics controller using a proxy for SaaS or cloud deployments. For onboarding an AppDynamics Controller running on a cloud, Nexus Dashboard Insights uses a proxy configured in Cisco Nexus Dashboard's Admin Console to connect to the AppDynamics Controller.

## Guidelines and Limitations

- After Nexus Dashboard Insights upgrade, AppDynamics takes about 5 minutes to report the information in AppDynamics GUI.
- The health and count of AppDynamics business transactions displayed in the application details do not match the flow count in Nexus Dashboard Insights.
- Nexus Dashboard Insights does not support fabric topologies as a transit-leaf switch does not have the VRF instance deployed and the flow table in the transit-leaf switch will not export the flow record to Nexus Dashboard Insights. Hence, Nexus Dashboard Insights will not stitch the path fully and will not display complete path summary with all the information.
- To connect an HTTPS AppDynamics controller using an HTTP proxy you must configure HTTPS proxy in Nexus Dashboard's Admin Console with the HTTP proxy server URL address.
- To connect an HTTP AppDynamics controller using an HTTP proxy you must configure HTTP proxy in the Admin Console with the HTTP proxy server URL address.
- Scale limits for AppDynamics integration:
  - Number of apps: 5
  - Number of tiers: 50
  - Number of nodes: 250
  - Number of net links: 300
  - Number of flow group: 1000

## Installing AppDynamics

Before you begin using Nexus Dashboard Insights **Integrations**, you must install AppDynamics Application Performance Management and Controller. See [Getting Started](#) for details.

# Onboard AppDynamics Controller

For Cisco Nexus Dashboard Insights and AppDynamics integration, the Cisco Nexus Dashboard's data network must provide IP reachability to the AppDynamics controller. See the [Cisco Nexus Dashboard Deployment Guide](#).

## Before you begin

- You must have installed AppDynamics application and controller.
- You must have administrator credentials for Nexus Dashboard Insights.
- You must have user credentials for AppDynamics controller.
- You must have configured proxy in Nexus Dashboard's Admin Console to connect to AppDynamics controller using a proxy. See section **Cluster Configuration** in the [Cisco Nexus Dashboard User Guide](#)

## Procedure

1. Click **Admin > Integrations > Add Integration**.
2. Select **App Dynamics** for **Integration Type**.
3. AUTHENTICATION
  - Enter the Controller Name, Controller IP or Hostname, Controller Protocol, and Controller Port. The Controller Name can be alphanumeric, but spaces are not allowed.



The AppDynamics Controller Name cannot be the same name as the Nexus Dashboard fabric name.

- Put a check in the **Enable** box to connect to the AppDynamics controller using a proxy. The proxy must be configured in the Admin Console.
- Enter the AppDynamics Account Name, User Name, and Password.

A screenshot of the 'Add Integration' configuration page in the Cisco Nexus Dashboard. The page is titled 'Add Integration' and has a sidebar on the left with four steps: 1. Integration Type, 2. Authentication (selected), 3. Associations, and 4. Summary. The main content area is titled 'Authentication' and contains several input fields: 'Controller Name\*' (text), 'Controller IP or Hostname\*' (text), 'Controller Port' (text), 'Controller Protocol\*' (dropdown menu with 'Select' visible), 'Use Proxy' (radio button, currently off), 'Enable' (checkbox, currently unchecked), 'Account\*' (text), 'User\*' (text), and 'Password\*' (text with a toggle icon). At the bottom left is a 'Cancel' button, and at the bottom right are 'Back' and 'Next' buttons.

## 4. ASSOCIATIONS

- Select a fabric or multiple fabrics. You can view the number of anomalies for each severity



level, SW Analytics, Flow Collection, and the Anomaly Trend for each fabric before selecting it.

- o Click **Select**.

5. The Summary displays an overview of the Integration created.

6. Click Submit to add the integration. The post completion success screen allows you to **Add Another Integration** or **View Integrations**.

When the **Status** is Connected, the onboarding for the controller is complete.

Each controller supports multiple account names for the same host name. Each account name supports multiple applications monitored by the controller. Therefore, a controller can support multiple applications monitored by AppDynamics.

## Cisco Nexus Dashboard Insights and AppDynamics Integration Dashboard

The AppDynamics Dashboard allows you to onboard controllers and presents a view of the **Top Applications by Anomaly Score** along with various metrics. Once a controller is onboarded, data related to applications monitored by that controller is pulled by Nexus Dashboard Insights. It can take up to 5 minutes for the first set of data to appear on the GUI. The AppDynamics health state information provided for each entity is aggregated and reported by Nexus Dashboard Insights on the dashboard.


The AppDynamics dashboard displays the overview of the applications monitored by the AppDynamics controller.

- **Controller Connectivity** – Represents the number of integrations that are **Up** or **Down**.
- **Anomalies by Severity** – Nexus Dashboard Insights runs statistical analytics on the metrics received from the AppDynamics controller. Click the number on **Anomalies by Severity** for Anomalies.
- **Top Applications by Anomaly Score** displays top six out of all the applications based on the anomaly score.
- **Application widget** displays the top application by anomaly score. This includes the anomaly score of the application as computed in Nexus Dashboard Insights, health state of tiers and nodes as reported by AppDynamics. Click the widget for additional details about the monitored application.

## AppDynamics Integration Application

Detailed information including operational, statistics, and metrics, for each tier or application is also presented.

- **Summary** lists the anomaly score, controller name, account, application name, number of tiers, number of nodes, throughput, TCP loss, and errors.
- \*Anomaly in the summary to display additional details.

- **Analyze Anomaly** details displays estimated impact application, recommendations, mutual occurrences, and other details affected by the anomaly.
- **View Report** displays the flow groups affected where each flow group can correspond to multiple fabric flows. View reports also display the proxy/entity IP address, node source, and node destination IP address.
- **Number of Tiers** lists the available tiers. Click each tier from the list to display health score, number of nodes, and usage statistics.
- **Number of Nodes** lists the available nodes. Click each node from the list to display statistics about the node.
- **Application Name** displays additional details such as general information of the application, controller name, controller IP, account name, health of the tier, health of the node, business transaction health, and usage analytics.
-  icon on the right top corner is to open **AppDynamics Application** details. This page displays application statistics details such as anomaly score, application tiers summary, application nodes summary, network charts for the node communication, and summary table of anomalies.
- **Application Network Links** table shows how the different components of AppDynamics application network flow map are communicating among each other. Detailed information about a network link, including flow counts and anomalies are used for further analysis.
- **AppDynamics Application View** - Double-click each row in the summary for the particular AppDynamics monitored application.

## AppDynamics Application View

AppDynamics Application View presents an overview of the application health state including tier health, node health, and business transaction health.

- **Application Statistics** displays the graphical representation of the flow properties and a timeline graph representing the properties.
- **Tiers** displays the health state of the tiers in the application. Click each row in the tier section for the side panel to display additional tier usage details.
- **Nodes** displays the health state of the nodes in the application. Click each row in the node section for the side panel to display additional node usage details.
- **Application Network Links** displays the link summary for the nodes.
- **Network Connection** displays additional flow connection details.
- **Browse Network Flows** to navigate to Browse Flow Records with the flow properties set in the filter.
- **Anomalies** summarizes the anomalies with severity and other essential details of the anomaly. Click each row in the **Anomalies** section for the side pane to pop up with additional details of the anomaly.
- **Analyze** for in-depth analysis, mutual occurrences, estimated impact, lifespan, and recommendations on the anomaly.

## Topology View

The topology view represents the stitching between nodes where these nodes are connected to the

fabric.

The topology view include application nodes and leaf nodes. Toggle between show or not show to view/hide the nodes with anomaly score. The anomaly score is represented by the dot in the topology.

The topology view represents a hierarchical view of **Application > Node > Leaf** and the links between them with a logical or network view of how various objects are related.

## **AppDynamics Anomalies**

From AppDynamics application, you can create your own health rule on the available metrics, which contributes to the overall anomaly score of the entity. If the health rules are violated and a violation is generated by the AppDynamics controller, then Nexus Dashboard Insights pulls these health violations and generates anomalies on these violations.

The anomalies in the summary table include the following:

- Anomalies raised on the metrics from the AppDynamics controller.
- Health violation on the network metrics that the AppDynamics controller raised.
- Anomalies at the application level and node level.

If there is an anomaly on the interface of application(s) impacted by the interface, then an anomaly is identified and shown.

Depending on the anomaly score and the level at which the anomaly occurs, the corresponding flows impacted are identified. Information related to the flow metrics with the leaf nodes information enable statistics analytics, pin point the source of the anomaly, whether it is the application or network, and the impacted entities.

The fabric flow impact calculation for AppDynamics anomalies calls flow APIs to fetch the fabric flows corresponding to the AppDynamics flow groups that were affected by the anomaly. Nexus Dashboard Insights displays the top 100 fabric flows ordered by the anomaly score for AppDynamics anomalies.

# vCenter Integration

## About VMware vCenter Server Integration

Integrating VMware vCenter server allows Nexus Dashboard Insights to collect data and metrics of the virtual machines and hosts monitored by VMware vCenter, and then correlate the collected information with the data collected from the Cisco ACI or Cisco NDFC fabric.

Data collected from vCenter includes

- Virtual machine data
- Network data
- Virtual machine NIC data
- Host data
- Datastore data
- Standard switch information
- DVS information
- vCenter Alarms

Nexus Dashboard Insights collects data from vCenter every 15 minutes. A system anomaly is raised if Nexus Dashboard Insights is unable to reach vCenter.

### vCenter Anomalies

In Nexus Dashboard Insights, the alarms from vCenter are displayed as anomalies. The following types for anomalies are generated for vCenter Integration in the category **vCenter**.

- Host, VM, and Datastore alarms from vCenter
- Baseline anomalies for checks such as CPU, memory, storage
- Threshold anomalies

### Prerequisites

- You have installed VMware vCenter 6.5 and later.
- You have read-only privileges for VMware vCenter.

### Guidelines and Limitations

- Number of VMs supported for VMware vCenter integration is 1000.
- Number of vNIC hosts supported for VMware vCenter integration is 10,000.
- In Nexus Dashboard Insights release 6.3.1.44 and later multiple vCenters per fabric are supported.


# Add vCenter Server Integration

1. Click **Admin > Integrations > Add Integration**.
2. Select **vCenter Server** for the **Integration Type**.
3. AUTHENTICATION
  - o Enter Controller Name, Controller IP or Hostname, and Controller Port. Controller Name can be alphanumeric and spaces are not allowed.
  - o Enter vCenter Username and Password.
4. ASSOCIATIONS
  - o Select a fabric. You can view the number of anomalies for each severity level, SW Analytics, Flow Collection, and the Anomaly Trend for each fabric before selecting it.
  - o Click **Select**.
5. The Summary displays an overview of the Integration created.
6. Click **Submit** to add the integration. The post completion success screen allows you to **Add Another Integration** or **View**.

## vCenter Virtual Machine Dashboard

Select **Virtual Machines**. Select the timeline.

The dashboard presents the **Top Virtual Machines** by CPU plotted on a timeline. From the drop-down list, select CPU, memory, storage, or network usage to view the graphical representation of the top virtual machines based on drop-down list selection.



Use the filter bar to filter by vCenter IP, vCenter Controller, VM, Host, State, Status, Guest OS, DNS Name, Datacenter, Network Adapters, Network Usage, CPU, Memory, and Storage.

Virtual Machines also displays the virtual machines in a tabular format.

The **Virtual Machines** table displays the following information:

- Anomaly Score
- vCenter IP address
- Virtual machine IP address
- State
- Network Adapters
- IP address
- Network Usage
- CPU
- Memory
- Storage

The **Gear** icon can be used to customize the columns to be displayed in the table.

Select any entry in the table to display the additional details:

- **Anomaly score** categorized by Critical, Major, Minor and Warning.
- **General Information** like State, Status, Guest OS, DNS Name, Host, IP Addresses, VCenter, Datacenter, and Network Adapters.
- **Usage graphs** for CPU, Memory, Storage and Network.
- **Storage** which displays the number of Datastores.

## Virtual Machine Details

Virtual machine details can be navigated to in two ways:

Click any VM name in the table to view details

OR


Click the  icon (Expand Icon) after clicking any row in the table to view details



The details mentioned below consist of all the data available in both the views of Virtual Machine Details.

### Overview

The overview section displays the following information:



- Host IP address to view details for the selected host.

See [vCenter Hosts Dashboard](#) for more information.

- The "+" under IP addresses to view all the addresses for the virtual machine.
- The usage graph can be viewed as separate graphs for each type of virtual machine or as a cumulative graph of all virtual machines.

## ***Datastore***

Click the datastore name to view the Status, Type, Cluster, Hosts, Virtual Machines and the Usage graph for the datastore selected.

## ***Network Adapters***

They can be filtered based on the Adapter MAC, Port Group, Type, Virtual Switch, Adapter State, and Physical Adapters.

## ***Adapter State***

The adapter state shows details for network adapters.

## ***Port Group***

Click any port group to view the Type, Virtual Switch, VLAN, Hosts, and Virtual Machines. Select any of the port groups to view more details.





- Verification Status
- IP Address
- MAC Address
- Interface
- VPC
- EPG
- VRF
- BG

## Topology

Topology represents a hierarchical view of **virtual machine > host > leaf switch** in the fabric and the links between them with a logical or network view of how various objects are related.

When there is an intermediate switch between the host and the leaf switch, the leaf switch in the host topology view is displayed as detached. Nexus Dashboard Insights is unable to determine the attached leaf switch port in such topologies. This will affect Cisco UCS B Series Blade Servers that have fabric switches between host blades and leaf switches, and it will also affect any other topologies with intermediate switches.

### Virtual Machine Ixia\_VC

Overview Anomalies Topology Trends and Statistics



Topology can be filtered for the following different objects:


- Host
- Datastore
- DVS
- Network
- VM Network
- VSS

- Leaf
- Application

Click any of the nodes to view more information about it.

## Trends and Statistics

This displays the usage graphs for CPU, Memory, Storage and Network. It can be viewed as separate graphs for each type of virtual machine or as a cumulative graph for all.




## Anomalies

See [Anomalies and Advisories](#) for more information.

# vCenter Hosts Dashboard

Select **Hosts**. Select the timeline.



The dashboard presents the **Top Hosts** by CPU plotted on a timeline. From the drop-down list, select CPU, memory, storage, or network usage to view the graphical representation of the top virtual machines based on drop-down list selection.

Use the filter bar to filter by vCenter IP, vCenter Controller, VM, Host, State, Status, Guest OS, DNS Name, Datacenter, Network Adapters, Network Usage, CPU, Memory, and Storage.

Use the following operators for the filter refinement:

Operator	Description
==	With the initial filter type, this operator, and a subsequent value, returns an exact match.
!=	With the initial filter type, this operator, and a subsequent value, returns all that do not have the same value.
contains	With the initial filter type, this operator, and a subsequent value, returns all that contain the value.
!contains	With the initial filter type, this operator, and a subsequent value, returns all that do not contain the value.

Hosts also displays the hosts in a tabular format.

The **Hosts** table displays the following information:

- Anomaly Score
- vCenter IP address
- Host IP address
- State
- NVirtual Machines
- Cluster
- Network Usage
- CPU
- Memory
- Storage

The **Gear** icon can be used to customize the columns to be displayed in the table.

Select any entry in the table to display the additional details:

- **Anomaly score** categorized by Critical, Major, Minor and Warning.
- **General Information** like State, Status, Guest OS, DNS Name, Host, IP Addresses, VCenter, Datacenter, and Network Adapters.

- **Usage graphs** for CPU, Memory, Storage and Network.
- **Storage** which displays the number of Datastores.

## Hosts Details

Host details can be navigated to in two ways:

Click any host name in the table to view details

OR

Click the  icon (Expand Icon) after clicking any row in the table to view details



The details mentioned below consist of all the data available in both the views of Host Details.

## Overview

**Host 172.29.132.92** 🔍 📄

Overview [Anomalies](#) [Topology](#) [Trends and Statistics](#)

---

**Anomaly Score**

**No anomalies found**

No anomalies found

---

**General Information**

Name	State	Status	Cluster	Up Time	Physical Adapters	Datacenter	Hypervisor	Model	Processor Type
172.29.132.92	<span style="color: green;">● Connected</span>	<span style="color: orange;">● Warning</span>	-	135 Days	10	NXOS_NAE_SYSTEST	VMware ESXi 6.7.0 build-20497097	UCSC-C240-M5SX	Intel(R) Xeon(R) Platinum 8180M CPU @ 2.50GHz

Logical Processors  
112

---

**VMs**

Filter ✎

Anomaly Score	vCenter	VM	State	Status	Network Adapters	IP Addresses	Network Usage	CPU	Memory	Storage
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Ixia_VC	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	2	172.29.132.110	16.6 KBps	124 MHz	327 MB	23.811 GB
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Ixia_VLM1	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	2	192.168.1.10	7.93 KBps	24 MHz	163 MB	18.009 GB
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Teleixia-NS3-1	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1	172.29.132.212	151.8 KBps	1.4 GHz	7.86 GB	248.086 GB
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Teleixia-NS3	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1	172.29.132.211	149.67 KBps	6.51 GHz	6.39 GB	248.086 GB
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Teleixia-NS3-2	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1	172.29.132.213	101.8 KBps	1.65 GHz	4.92 GB	248.085 GB

This displays the general information for the host along with the Anomaly Score, and tables listing the Virtual Machines, Datastores, Standard Switches, and Distributed Switches.

### Physical Adapters

Click the number for Physical Adapters to view the entire list of adapters available. Select any of the adapters to view details like:

- Link Status
- Protocol
- Interface
- Node

- Chassis ID
- Management Address
- Usage graphs for Network, Network Broadcast and Network Multicast

## Network Adapters

Click the number for Network Adapters to view the entire list of adapters available. Select any of the adapters to view details like Endpoint address, Port Group, Type, Virtual Switch, VLAN, Adapter State, Physical Adapters, IP Addresses. Click on the Expand icon to view more details.

Host 172.29.132.92

### General Information

Name: 172.29.132.92  
 State: ● Connected  
 Status: ● Warning  
 Logical Processors: 112

Cluster: -  
 Up Time: 135 Days  
 Physical Adapters: 10  
 Datacenter: NXOS\_NAE\_SYST

### Network Adapters - Ixia\_VC

Search:

- 00:0c:29:8d:25:c9
- 00:0c:29:8d:25:d3

### General Information

Endpoint: 00:0c:29:8d:25:c9  
 Port Group: VM Network  
 Type: Standard Port Group  
 Virtual Switch: vSwitch0  
 VLAN: -  
 Adapter State: ● Connected  
 Physical Adapters: vmmic0  
 IP Addresses: 172.29.132.110

### VMs

Anomaly Score	vCenter	VM	State	Status	Netwo
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Ixia_VC	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	2
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Ixia_VLM1	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	2
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Teleixia-NS3-1	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Teleixia-NS3	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Teleixia-NS3-2	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Teleixia-NS3-3	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	NXOS-ISE	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	6
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	DCNM_11.5	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	3
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Ixia_Windows_VM_1	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1
<span style="color: green;">● Healthy</span>	SJC15-vCenter 172.29.132.100	Ixia_Windows_VM_3	<span style="color: green;">● Powered On</span>	<span style="color: green;">● Normal</span>	1

## VMs

Click the number for VMs to view the entire list of virtual machines available. Select any of the virtual machines to view details.

Host 172.29.132.92

Health	Host	Role	Status	Alerts	Count
Healthy	SJC15-vCenter	DCNM_11.5	Powered On	Normal	3
Healthy	SJC15-vCenter	Ixia_Windows_VM_1	Powered On	Normal	1
Healthy	SJC15-vCenter	Ixia_Windows_VM_3	Powered On	Normal	1

10 Rows

**Datstores**

Name	Status	Type
datastore1 (1)	Critical	VMFS

10 Rows

**Distributed Switch**

Filter

Virtual Machines - datastore1 (1)

Search

- DCNM\_11.5  
NXOS\_NAE\_SYSTEST
- DCNM\_11.5\_Compute\_Standby  
NXOS\_NAE\_SYSTEST
- Ixia\_VC  
NXOS\_NAE\_SYSTEST
- Ixia\_VLM1  
NXOS\_NAE\_SYSTEST
- Ixia\_Windows\_VM\_1  
NXOS\_NAE\_SYSTEST
- Ixia\_Windows\_VM\_3  
NXOS\_NAE\_SYSTEST
- NXOS-ISE  
NXOS\_NAE\_SYSTEST
- Telexia-NS3  
NXOS\_NAE\_SYSTEST
- Telexia-NS3-1  
NXOS\_NAE\_SYSTEST
- Telexia-NS3-2  
NXOS\_NAE\_SYSTEST
- Telexia-NS3-3  
NXOS\_NAE\_SYSTEST

Virtual Machine: DCNM\_11.5

0 Critical, 0 Major, 0 Minor, 0 Warning

**General Information**

State: Powered On

Status: Normal

Guest OS: CentOS 4/5/6/7 (64-bit)

DNS Name: candid-sys-nxos-dcnm-11-5.cisco.com

Host: 172.29.132.92

IP Addresses: 6

VCenter: 172.29.132.100

Datcenter: NXOS\_NAE\_SYSTEST

Network Adapters: 3

## Hosts

Click the number for hosts to view the entire list of hosts available. Select any of the hosts to view details.

Host 172.29.132.92

Health	Host	Role	Status	Alerts	Count
Healthy	SJC15-vCenter	Telexia-NS3-1	Powered On	Normal	1
Healthy	SJC15-vCenter	Telexia-NS3	Powered On	Normal	1
Healthy	SJC15-vCenter	Telexia-NS3-2	Powered On	Normal	1
Healthy	SJC15-vCenter	Telexia-NS3-3	Powered On	Normal	1
Healthy	SJC15-vCenter	NXOS-ISE	Powered On	Normal	6
Healthy	SJC15-vCenter	DCNM_11.5	Powered On	Normal	3
Healthy	SJC15-vCenter	Ixia_Windows_VM_1	Powered On	Normal	1
Healthy	SJC15-vCenter	Ixia_Windows_VM_3	Powered On	Normal	1

10 Rows

**Datstores**

Name	Status	Type
datastore1 (1)	Critical	VMFS

10 Rows

**Distributed Switch**

Filter

Host - datastore1 (1)

Search

- 172.29.132.92  
NXOS\_NAE\_SYSTEST

Host: 172.29.132.92

0 Critical, 0 Major, 0 Minor, 0 Warning

**General Information**

State: Connected

Up Time: 135 Days

Status: Warning

Cluster: -

Hypervisor: VMware ESXi 6.7.0 build-20497097

Model: UCSC-C240-M5SX

Processor Type: Intel(R) Xeon(R) Platinum 8180M CPU @ 2.50GHz

Logical Processors: 112

**Usage**

172.29.132.212 | 151.8 KBps | 1.4 GHz | 7.86 GB | 248.086 GB



The information available for the host listed is the same as the information available from the Host Details screen.

## Anomalies


Anomalies displays the list of anomalies. The anomalies can be viewed as grouped or ungrouped and

can be viewed for a selected timeline.

See [Anomalies and Advisories](#) for more information.

## Trends and Statistics

Trends and Statistics displays the usage graphs for Network, Network Broadcast and Network Multicast and can be viewed as separate graphs for each type of network or as a cumulative graph of all networks.



## Alerts

Alerts displays the alarms from vCenter. In Nexus Dashboard Insights, the alarms from vCenter are displayed as anomalies. From the **Actions** drop-down menu, select an action to configure properties on an anomaly. The alerts can be filtered based on the following:

- Acknowledgement
- Anomaly ID
- Assignee
- Category
- Check Code
- Comment
- Description
- Detection Time
- Entity Name
- Last Seen Time
- Nodes

- Severity
- Status
- Sub-category
- Tags
- Title
- Verification Status
- IP Address
- MAC Address
- Interface
- VPC
- EPG
- VRF
- BG

## Topology

Topology represents a hierarchical view of **virtual machine > host > leaf switch in the fabric** and the links between them with a logical or network view of how various objects are related.

When there is an intermediate switch between the host and the leaf switch, the leaf switch in the host topology view displays as detached. Nexus Dashboard Insights is unable to determine the attached leaf switch port in such topologies. This will affect Cisco UCS B Series Blade Servers that have fabric switches between host blades and leaf switches, and it will also affect any other topologies with intermediate switches.

### Virtual Machine Ixia\_VC

Overview Anomalies Topology Trends and Statistics



Topology can be filtered for the following different objects:

1. Host



2. Datastore
3. DVS
4. Network
5. VM Network
6. VSS
7. Leaf
8. Application

Click any of the nodes to view more information about it.

# DNS Integration

## About DNS Integration

The Nexus Dashboard Insights Domain Name System (DNS) integration feature enables the name resolution feature to telemetry data. DNS integration can be associated at the Fabric level.

For DNS integration you can use any of the following 3 data source methods:

### DNS File Upload

This method is simple because mappings do not change often. In the GUI, you can upload a file containing mappings. Use one of the supported formats (.csv and .json). Nexus Dashboard Insights verifies the integrity of the file. When required, you can also download or delete the file from the GUI.

If no VRF or Fabric name is specified, DNS will be applied to the fabrics for which the DNS server is configured based on the selections in **Add Integrations** and **Associations** section. If the DNS server is configured for multiple fabrics, then DNS will be applied to all the fabrics.

The DNS file upload size is limited to 1.8 MB.

### Example CSV file

This section provides an example of a CSV file's contents.

```
recordType fqdn      ips      siteName tenant  vrf
dnsEntry   WebSrv1.foo.com 10.101.11.1 ACI-Fab1 prod    vrf_prod
dnsEntry   WebSrv2.foo.com 10.101.11.2 ACI-Fab1 prod    vrf_prod
dnsEntry   WebSrv3.foo.com 10.101.11.3 ACI-Fab1 prod    vrf_prod
dnsEntry   WebSrv4.foo.com 10.101.11.4 ACI-Fab1 prod    vrf_prod
```

### Example JSON file

This section provides an example of a JSON file's contents.

```
[
  {
    "recordType": "dnsEntry",
    "fqdn": "WebSrv1.foo.com",
    "ips": [
      "10.101.11.1"
    ]
  },
  {
    "recordType": "dnsEntry",
    "fqdn": "WebSrv2.foo.com",
    "ips": [
```

```

    " 10.101.11.2",
    " 52::2"
  ]
},
{
  "recordType": " dnsEntry",
  "fqdn": " WebSrv3.foo.com",
  "ips": [
    " 10.101.11.3",
    " 52::3"
  ]
}, {
  "recordType": " dnsEntry",
  "fqdn": " WebSrv4.foo.com",
  "ips": [
    " 10.101.11.4",
    " 10::101:0:4"
  ]
}
]

```

## DNS Query

Use this method one query at a time to retrieve data from the DNS server using reverse lookup. Reverse lookup zone(s) must be configured on the DNS server.

Nexus Dashboard Insights queries the DNS server at regular intervals and resolves IP addresses that are learned using endpoints.

Nexus Dashboard Insights allows one primary and multiple secondary DNS servers, the primary DNS server will be polled first. If the resolution does not succeed, the secondary servers will be polled thereafter.

## DNS Zone Transfer

DNS Zone Transfer is also known as AXFR downloads. Nexus Dashboard Insights can retrieve zone data in bulk from the DNS server using AXFR downloads. This method is convenient for large quantities of data as you no longer have to work on one query at a time.

A zone transfer requires at least one DNS zone. If you configure a forward mapping zone, then all the A and AAAA records will be fetched from a DNS server, and if you configure a reverse mapping zone, then PTR records will be fetched. When onboarding the DNS server, you must provide a list of zones from which to fetch the data. Nexus Dashboard Insights will fetch the data from each zone configured from the DNS server.

TSIG (transaction signature) is a computer-networking protocol defined in RFC 2845. Primarily it enables the DNS to authenticate updates to a DNS database. For a secure transfer, Nexus Dashboard Insights allows you to configure the TSIG key for a zone to initiate the transaction. Configure the zone

with the TSIG key, and an associated algorithm. In the Nexus Dashboard Insights GUI, the supported algorithms are displayed in a drop-down list.

When you delete an onboarded DNS server, all the zones will be un-configured automatically. A zone can be a forward mapping or a reverse mapping zone.

When information is changed on the DNS server it may take up to 3 hours to update corresponding name mappings on Cisco Nexus Dashboard Insights. During that interval, the old name will be displayed for endpoints until the sync is completed.

## Guidelines and Limitations

- DNS onboarding can be done at a fabric level.
- Only one type of DNS integration method is supported in one fabric. For example, in a fabric, you cannot configure using DNS file uploads as well as DNS Zone Transfer methods.
- Multiple DNS integration onboarding of the same type is allowed in a fabric. For example, multiple files can be onboarded, to a fabric using the DNS file uploads method.
- If you perform DNS integration onboarding for multiple fabrics, you cannot also onboard a fabric in that group.
- When a corrupted or malformed .CSV or .JSON file is uploaded to the DNS server, Cisco Nexus Dashboard Insights raises system anomalies. However, the Connectivity Status of the third-party onboarding server, remains in the initialized state and does not change to display a failed state. If the third-party onboarding server remains in the initialized state, check the system anomalies for any anomalies related to the specific integration.
- The supported scale for DNS integration is 40,000 DNS entries. For vND application profiles, the supported scale for DNS integration is 10,000 DNS entries.
- Data from DNS servers will be polled or refreshed every 3 hours. So, any changes in the mapping on the DNS server will reflect after the next polling cycle.

## Configure DNS



The .json or .csv file used in this task must be uploaded in a specific schema. See the following section for the formats to use.

1. Click **Admin > Integrations > Add Integration**.
2. Select **DNS** for the **Integration Type**.
3. In the **Authentication** section, select one of the following DNS types to view the corresponding fields:
  - a. Zone Transfer - Enter the **Name**, **DNS Server IP**, **DNS Server Port**, and **Zones**. In the **Zones** area, enter the value for Zone Name. Optional values that can be entered are TSIG Key Name, TSIG Key Value, TSIG Algorithm. The **TSIG Algorithm** dropdown menu selections are hmac-sha1, hmac-sha256, hmac-sha512, hmac-md5.
  - b. Query Server - Enter the **Name**, **DNS Server IP**, **DNS Server Port**, and **Secondary Servers**.
  - c. Mapping File - Enter the **Name**, **Description**, and **Upload a JSON or CSV file**.

4. In the **Associations** area, click **Add Associations** to associate a fabric or multiple fabrics.
5. The Summary displays an overview of the Integration created.
6. Click Save to add the integration. The post completion success screen allows you to **Add Another Integration** or **View Integrations**.

## Edit or Delete DNS Configuration

To edit your DNS configuration, click the Actions icon and click **Edit**. When you have completed editing, click **Add**.

To delete your DNS configuration, click the Actions icon and click **Delete**.

## Formats for Files Used in DNS File Uploads

When configuring the DNS file uploads, .json and .csv formats are supported. Use the formats provided below for the files that you upload.

The fields in a DNS file upload can have optional VRF or Fabric name information. If you have a file that contains the fabric name, specifying the VRF is optional.

### Format .json

```
[
  {
    "recordType": "dnsEntry",
    "fqdn": "host1.cisco.com",
    "ips": ["1.1.0.0"],
    "vrf": "vrf-1",
    "siteName": "swmp3",
  },
  {
    "recordType": "dnsEntry",
    "fqdn": "host2.cisco.com",
    "ips": ["1.1.0.1"],
    "vrf": "vrf-1",
    "siteName": "swmp3",
  }
  {
    "recordType": "dnsEntry",
    "fqdn": "host3.cisco.com",
    "ips": ["1.1.0.2"],
  },
]
```

### Format .csv

recordType,fqdn,ips,siteName,vrf

dnsEntry,swmp3-leaf1.cisco.com," 101.22.33.44",swmp3,vrf-1

dnsEntry,swmp5-leaf1.cisco.com," 10.2.3.4,10.4.5.6,1.2.3.4",fabric2,vrf-2

dnsEntry,swmp4-leaf1.cisco.com," 1.1.1.1",,,

# Panduit PDU Integration

## Panduit PDU Integration

Panduit Power Distribution Unit (PDU) Integration in Nexus Dashboard Insights enables you to monitor energy usage and unlock sustainability insights for fabrics and individual devices connected to a Panduit PDU. Monitoring energy consumption gives you insight into how much electricity your devices and/or Panduit PDUs are using.

The workflow for integration of Panduit PDU consists of the following steps:

1. Install Panduit PDU collector and PDUs.
2. Add PDU collector to Nexus Dashboard Insights. The PDU collector collects telemetry from PDUs in your environment.
3. Associate PDUs to the PDU collector. The associated PDUs send telemetry to the Panduit PDU collector, and Nexus Dashboard Insights displays PDU statistics in the Sustainability Report. See [Sustainability Report](#).

## Prerequisites


- You have installed Panduit Collector and PDUs.
- You have associated the PDUs to the collector.
- You have configured a persistent IP address for PDU collector to stream telemetry information for one or multiple PDUs in your fabric in Nexus Dashboard's Admin Console. In Nexus Dashboard's Admin Console, navigate to **Admin > System Settings > General > External Service Pools > Add Data Service IP Address** to configure the persistent IP address.
- You have configured the SNMP protocol in the PDU.

## Guidelines and Limitations

- After you onboard the PDU collector in Nexus Dashboard Insights, it will take at least 15 minutes for the number of number of devices powered by the PDU collector to be displayed in the Nexus Dashboard Insights GUI.
- Once the number of number of devices powered by the PDU collector to be displayed in the Nexus Dashboard Insights GUI, the PDU data is updated every 15 minutes in Nexus Dashboard Insights.
- Scale limits for Panduit PDU integration:
  - Maximum number of PDUs supported per Nexus Dashboard cluster - 1000
  - Maximum number of PDUs supported per fabric - 500
- If you have not configured the PDU name in the Panduit PDU GUI, the PDU name is not displayed in the PDU table in Nexus Dashboard Insights.

Some information for the PDU may not be available until at least 15 minutes after onboarding.

## Collection Status



Filter by attributes

Add PDU

PDU Name	Serial Number	Model	Type	Collection Status	IP Address(es)	Outlets	Total Power	
	IN229N6026	346-415V, 24A, 17.3kVA, 50/60Hz Panduit	ThreePhase-Wye	Not OK		36	853 Watts	...
SJC02-R16	IN235E6042	200-240V, 24A, 5.0kVA, 50/60Hz Panduit	Single	OK		36	4077 Watts	...
SJC02-R15 Daisy-chained PDU	IN235E6054	200-240V, 24A, 5.0kVA, 50/60Hz Panduit	Single	OK	<a href="#">SJC02-R16</a>	36	2803 Watts	

## Add PDU Integration

1. Navigate to **Admin > Integrations > Add Integration**.
2. Select Integration Type **Panduit PDU**.
3. Complete the following fields for **PDU Collector**.
  - a. Enter the name of the PDU Collector.
  - b. Enter the IP address of the PDU Collector.
  - c. Enter the username and password to authenticate the PDU Collector.
  - d. Select an online fabric to associate with the PDU Collector. A PDU Collector is associated with single fabric.



Snapshot fabric is not supported.

- e. Click **Next**.
4. Complete the following fields for **Add PDUs** to add PDUs to the PDU collector.
    - a. The PDU collector version and status is displayed in the summary. Once the PDU collector is added successfully, you can add the PDUs to the collector.
    - b. Enter the IP address of the PDU.
    - c. Click **Add to Collector**.
  5. Complete the following fields for PDU credentials.



Ensure that you have configured the SNMP protocol in the PDU.

- a. Select the SNMP protocol version.
- b. For SNMP protocol version 2, enter the community string and click **Submit**.



- c. For SNMP protocol version 3, enter the user name.
  - d. Select the Authentication Type and Protocol.
  - e. Enter the Authentication password.
  - f. Select the Privacy Protocol and enter the password.
  - g. Click **Submit**.
  - h. After the PDU credentials are verified, the PDU is added to the collector and the PDU status is displayed in the table. In the table you can view details such as PDU status, PDU name, IP address of primary and secondary PDU, model, and serial number. For secondary PDU or Daisy-chained PDUs, you can view all the PDUs linked to the primary PDU.
  - i. Click **Next**.
6. Review the PDU information in the PDU Summary and click **Done**.
    - a. To add another PDU Collector click **Add Another PDU Collector**.
    - b. To view PDU Collector details, click **View PDU Collector**.

## View PDU Integration

1. Navigate to **Admin > Integrations**. In the Integrations Dashboard you can view the list of Panduit PDUs associated with a fabric. For each PDU integration you can view the Name, Connectivity Status, Type, IP address, Last Active, and Associations.
2. Click PDU collector name to view additional details.
3. Click **Overview** to view information such as collector IP address, connectivity to Nexus Dashboard, number of PDUs associated with the PDU collector, and number of devices powered by the PDU collector.

The screenshot shows the 'Overview' page for a Panduit PDU collector named 'SJC02\_1222'. The page is divided into two main sections: 'General' and 'Inventory'.

**General Section:**

- Vendor:** Panduit
- Connectivity to Nexus Dashboard:** OK (indicated by a green checkmark)
- Collector IP Address:** (field is empty)

**Inventory Section:**

- PDUs:** 3
- Devices Powered:** 32

4. Click **PDUs** to view the onboarding status of the PDUs associated with the PDU collector as a doughnut chart.
5. Use the search bar to filter the PDUs by name, serial number, model, type, collection status, IP addresses, outlets, and total power.
6. The PDUs table displays the filtered PDUs. The PDU table displays the PDU name name, serial number, model, type ( single or three phase), collection status, IP addresses, outlets, and total power.
7. Click the column heading to sort the PDUs in the table.
8. Click the gear icon to configure the columns in the PDUs table.

9. Click the ellipsis icon and click **Remove from this Collector** to remove the PDU.

Admin > Integrations > SJC02\_1222

## SJC02\_1222

candid-scale2

Refresh Actions

Overview PDU

Some information for the PDU may not be available until at least 15 minutes after onboarding.

### Collection Status

■ Not OK 1  
■ OK 2

3 Total

Filter by attributes Add PDU

PDU Name	Serial Number	Model	Type	Collection Status	IP Address(es)	Outlets	Total Power	
	<a href="#">IN229N6026</a>	346-415V, 24A, 17.3kVA, 50/60Hz Panduit	ThreePhase-Wye	Not OK		36	853 Watts	...
<a href="#">SJC02-R16</a>	<a href="#">IN235E6042</a>	200-240V, 24A, 5.0kVA, 50/60Hz Panduit	Single	OK		36	4077 Watts	...
<a href="#">SJC02-R15</a> Daisy-chained PDU	<a href="#">IN235E6054</a>	200-240V, 24A, 5.0kVA, 50/60Hz Panduit	Single	OK	<a href="#">SJC02-R16</a>	36	2803 Watts	

10. Click PDU name to view additional details such as general information, phases, and circuits. For Three Way type PDUs, you can view the different phases.

# PDU IN229N6026

SJC02\_1222

## General

Serial Number	Vendor	Model	Type	IP address(es)	Total Power
IN229N6026	 Panduit	346-415V, 24A, 17.3kVA, 50/60Hz	ThreePhase-Wye		851 Watts


## Phases







L1-N L2-N L3-N

Total Power  
685 Watts


## Circuits







### Circuit 1

 Output Power **421** Connected Outlets **3/6**

-  Outlet 1 0 Watts
-  Outlet 2 0 Watts
-  Outlet 3 139 Watts
-  Outlet 4 139 Watts
-  Outlet 5 142 Watts
-  Outlet 6 0 Watts

### Circuit 4

 Output Power **263** Connected Outlets **1/6**

-  Outlet 19 263 Watts
-  Outlet 20 0 Watts
-  Outlet 21 0 Watts
-  Outlet 22 0 Watts
-  Outlet 23 0 Watts
-  Outlet 24 0 Watts

# Copyright

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

The documentation set for this product strives to use bias-free language. For the purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2017–2024 Cisco Systems, Inc. All rights reserved.