



## MPLS OAM Commands

---



---

**Note** All commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router that is introduced from Cisco IOS XR Release 6.3.2. References to earlier releases in Command History tables apply to only the Cisco NCS 5500 Series Router.

---



- 
- Note**
- Starting with Cisco IOS XR Release 6.6.25, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 560 Series Routers.
  - Starting with Cisco IOS XR Release 6.3.2, all commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router.
  - References to releases before Cisco IOS XR Release 6.3.2 apply to only the Cisco NCS 5500 Series Router.
  - Cisco IOS XR Software Release 7.0.1 specific updates are not applicable for the following variants of Cisco NCS 540 Series Routers:
    - N540-28Z4C-SYS-A
    - N540-28Z4C-SYS-D
    - N540X-16Z4G8Q2C-A
    - N540X-16Z4G8Q2C-D
    - N540X-16Z8Q2C-D
    - N540-12Z20G-SYS-A
    - N540-12Z20G-SYS-D
    - N540X-12Z16G-SYS-A
    - N540X-12Z16G-SYS-D
-

This module describes Multiprotocol Label Switching (MPLS) label switched path (LSP) verification commands. These commands provide a means to detect and diagnose data plane failures and are the first set of commands in the MPLS Operations, Administration, and Maintenance (OAM) solution.

For detailed information about MPLS concepts, configuration tasks, and examples, see .

- [address-family ipv4](#), on page 3
- [address-family ipv4 reply](#), on page 4
- [address-family ipv6 reply](#), on page 6
- [clear mpls oam counters](#), on page 8
- [echo disable-vendor-extension](#), on page 9
- [echo revision](#), on page 10
- [mpls oam](#), on page 11
- [ping mpls ipv4](#), on page 12
- [ping mpls traffic-eng](#), on page 17
- [ping mpls traffic-eng tunnel-tp](#), on page 20
- [ping pseudowire \(AToM\)](#), on page 25
- [ping mpls traffic-eng tunnel-te \(P2P\)](#), on page 29
- [ping pseudowire multisegment](#), on page 32
- [show mpls oam](#), on page 36
- [show mpls oam database](#), on page 38
- [traceroute mpls ipv4](#), on page 39
- [traceroute mpls multipath](#), on page 43
- [traceroute mpls traffic-eng](#), on page 47
- [traceroute pseudowire multisegment](#), on page 50
- [traceroute mpls traffic-eng tunnel-te \(P2P\)](#), on page 52
- [traceroute mpls traffic-eng tunnel-tp](#), on page 55

# address-family ipv4

To configure the IPv4 address family parameters for MPLS OAM, use the **address-family ipv4** command in MPLS OAM configuration mode.

```
address-family ipv4 { apply-group group-name | exclude-group group-name | reply
ip-header-source source-ip }
```

Syntax Description		
<b>apply-group</b> <i>group-name</i>		Applies configuration from the specified group.
<b>exclude-group</b> <i>group-name</i>		Excludes the specified group from applying configuration.
<b>reply ip-header-source</b> <i>source-ip</i>		Configures the reply parameters for the specified IPv4 source ip address.

**Command Default** None

**Command Modes** MPLS OAM configuration mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write
	mpls-static	read, write

## Examples

This example displays the **address-family ipv4** command parameters.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# address-family ipv4 ?

  apply-group      Apply configuration from a group
  exclude-group    Exclude apply-group configuration from a group
  reply            Configure reply parameters for MPLS OAM address family
  <cr>
```

## address-family ipv4 reply

To configure the reply parameters for MPLS OAM IPv4 address family, use the **address-family ipv4 reply** command in MPLS OAM configuration mode.

**address-family ipv4 reply ip-header-source** *source-ip-address*

<b>Syntax Description</b>	<b>ip-header-source</b> <i>source-ip-address</i> Configures the specified MPLS OAM IPv4 source IP address in the reply node.	
<b>Command Default</b>	None	
<b>Command Modes</b>	MPLS OAM configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0	This command was introduced.
	Release 24.3.1	A new keyword, <b>ip-header-source</b> , was added to configure the MPLS OAM IPv4 source IP address in the reply node.
<b>Usage Guidelines</b>	Use the <b>address-family ipv4 reply ip-header-source</b> <i>source-ip-address</i> command if an explicit source ip is required in the MPLS OAM reply packets when route policies block packets with non-routed source addresses. By default, the MPLS OAM packets use the local interface address as the source.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-te	read, write
	mpls-ldp	read, write
	mpls-static	read, write

### Examples

This example configures the specified MPLS OAM IPv4 source IP address in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# address-family ipv4 reply ip-header-source 1.1.1.4
RP/0/RP0/CPU0:router(config-oam)# commit
```

This example verifies the above MPLS OAM source IPv4 address configuration in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# show running-config mpls oam
```

```
Thu Jun 20 13:43:28.855 IST
mpls oam
  address-family ipv4
    reply ip-header-source 1.1.1.4
!
```

# address-family ipv6 reply

To configure the reply parameters for MPLS OAM IPv6 address family, use the **address-family ipv6 reply** command in MPLS OAM configuration mode.

**address-family ipv6 reply ip-header-source** *source-ip-address*

<b>Syntax Description</b>	<b>ip-header-source</b> <i>source-ip-address</i> Configures the specified MPLS OAM IPv6 source IP address in the reply node.								
<b>Command Default</b>	None								
<b>Command Modes</b>	MPLS OAM configuration mode								
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.0</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 24.3.1</td> <td>A new keyword, <b>ip-header-source</b>, was added to configure the MPLS OAM IPv6 source IP address in the reply node.</td> </tr> </tbody> </table>	Release	Modification	Release 6.0	This command was introduced.	Release 24.3.1	A new keyword, <b>ip-header-source</b> , was added to configure the MPLS OAM IPv6 source IP address in the reply node.		
Release	Modification								
Release 6.0	This command was introduced.								
Release 24.3.1	A new keyword, <b>ip-header-source</b> , was added to configure the MPLS OAM IPv6 source IP address in the reply node.								
<b>Usage Guidelines</b>	Use the <b>address-family ipv6 reply ip-header-source</b> <i>source-ip-address</i> command if an explicit source ip is required in the MPLS OAM reply packets when route policies block packets with non-routed source addresses. By default, the MPLS OAM packets use the local interface address as the source.								
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>mpls-te</td> <td>read, write</td> </tr> <tr> <td>mpls-ldp</td> <td>read, write</td> </tr> <tr> <td>mpls-static</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	mpls-te	read, write	mpls-ldp	read, write	mpls-static	read, write
Task ID	Operations								
mpls-te	read, write								
mpls-ldp	read, write								
mpls-static	read, write								

## Examples

This example configures the specified MPLS OAM IPv6 source IP address in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# address-family ipv6 reply ip-header-source 192::4
RP/0/RP0/CPU0:router(config-oam)# commit
```

This example verifies the above MPLS OAM source IPv6 address configuration in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# show running-config mpls oam
```

```
Thu Jun 20 13:55:12.142 IST
mpls oam
  address-family ipv6
    reply ip-header-source 192::4
!
```

# clear mpls oam counters

To clear MPLS OAM counters, use the **clear mpls oam counters** command in XR EXEC mode.

**clear mpls oam counters** {**global** | **interface** [*type interface-path-id*] | **packet**}

Syntax Description		
<b>global</b>		Clears global counters.
<b>interface</b>		Clears counters on a specified interface.
<i>type</i>		Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>		Physical interface or virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.
<b>packet</b>		Clears global packet counters.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	execute
	mpls-ldp	execute
	mpls-static	execute

## Examples

The following example shows how to clear all global MPLS OAM counters:

```
RP/0/RP0/CPU0:router# clear mpls oam counters global
```



# echo disable-vendor-extension

To disable sending the vendor extension type length and value (TLV) in the echo request, use the **echo disable-vendor extension** command in MPLS OAM configuration mode. To return to the default behavior, use the **no** form of this command.

```
echo disable-vendor-extension
no echo disable-vendor-extension
```

**Syntax Description** This command has no arguments or keywords.

**Command Default** The default value is 4.

**Command Modes** MPLS OAM configuration mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write
	mpls-static	read, write

## Examples

The following example shows how to disable inclusion of the vendor extensions TLV in the echo requests:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# echo disable-vendor-extension
```

# echo revision

To set the echo packet revision, use the **echo revision** command in MPLS OAM configuration mode. To return to the default behavior, use the **no** form of this command.

**echo revision** {1 | 2 | 3 | 4}  
**no echo revision**

<b>Syntax Description</b>	1   2   3   4 Draft revision number: <ul style="list-style-type: none"> <li>• 1: RFC-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2: RFC-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3: RFC-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4: RFC-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
---------------------------	---

**Command Default** The default echo revision is 4 (in RFC 9).

**Command Modes** MPLS OAM configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-te	read, write
	mpls-ldp	read, write
	mpls-static	read, write

## Examples

The following example shows how to set the echo packet default revision:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# mpls oam
RP/0/RP0/CPU0:router (config-oam)# echo revision 1
```

# mpls oam

To enable MPLS OAM LSP verification, use the **mpls oam** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

**mpls oam**  
**no mpls oam**

**Syntax Description** This command has no arguments or keywords.

**Command Default** By default, MPLS OAM functionality is disabled.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** The **mpls oam** command and OAM functionality is described in the RFC 4379.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write
	mpls-static	read, write

## Examples

The following example shows how to enable MPLS OAM:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)#
```

## ping mpls ipv4

To check MPLS host reachability and network connectivity by specifying the destination type as a Label Distribution Protocol (LDP) IPv4 address, use the **ping mpls ipv4** command in XR EXEC mode.

**ping mpls ipv4** *address/mask* [**destination** *start-address end-address increment*] [**dsmap**] [**exp** *exp-bits*] [**force-explicit-null**] [**interval** *min-send-delay*] [**output interface** *type interface-path-id*] [**nexthop** *nexthop-address*][[**pad** *pattern*][**repeat** *count*] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **no-reply** | **router-alert**} | **reply pad-tlv**}] [**revision** *version*] [**size** *packet-size*] [**source** *source-address*] [**sweep** *min value max value increment*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**] [**fec-type** {**bgp** | **generic** | **ldp**}]

<b>Syntax Description</b>	<i>address/mask</i>	Address prefix of the target and number of bits in the target address network mask.
	<b>destination</b> <i>start address end address address increment</i>	(Optional) Specifies a network 127/8 address to be used as the destination address in the echo request packet.  <i>start address</i> Start of the network address.  <i>end address</i> Start of the ending network address.  <i>address increment</i> Incremental value of the network address, which is expressed as a decimal number value or IP address.
	<b>dsmap</b>	(Optional) Indicates that a downstream mapping (DSMAP) type length and value should be included in the LSP echo request.
	<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
	<b>force-explicit-null</b>	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
	<b>interval</b> <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
	<b>output interface</b>	(Optional) Specifies the output interface where echo request packets are sent.

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information, use the question mark (?) online help function.
<b>nexthop</b>	(Optional) Specifies the nextop as an IP address.
<i>nexthop-iaddress</i>	(Optional) IP address for the next hop.
<b>pad pattern</b>	(Optional) Specifies the pad pattern for an echo request.
<b>repeat count</b>	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
<b>reply dscp dscp-value</b>	Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>reply mode [ ipv4   router-alert   no-reply ]</b>	Specifies the reply mode for the echo request packet.  <b>no-reply</b> Do not reply  <b>ipv4</b> Reply with an IPv4 UDP packet (this is the default)  <b>router-alert</b> Reply with an IPv4 UDP packet with the IP router alert set
<b>reply pad-tlv</b>	Indicates that a pad TLV should be included.
<b>revision version</b>	(Optional) Specifies the Cisco extension TLV versioning field:  <ul style="list-style-type: none"> <li>• 1 RFC-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2 RFC-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3 RFC-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4 RFC-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
<b>size packet size</b>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.

<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>sweep</b> <i>min value max value interval</i>	(Optional) Specifies a range of sizes for the echo packets sent.  <b>min value</b> Minimum or start size for an echo packet (range is 100 to 17986)  <b>max value</b> Maximum or end size for an echo packet (range is 100 to 17986)  <b>interval</b> Number used to increment an echo packet size (range is 1 to 8993)
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.
<b>fec-type</b>	(Optional) Specifies FEC type to be used.  <b>bgp</b> Use FEC type as BGP  <b>generic</b> Use FEC type as generic  <b>ldp</b> Use FEC type as LDP

**Command Default**

**exp** *exp bits*: 0  
**interval** *min-send-delay*: 0  
**repeat** *count* : 5  
**reply-mode**: IPv4  
**timeout** *timeout* : 2

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the sweep keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.



**Note** The **ping mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

For detailed configuration information about the MPLS **ping** command, see *Cisco ASR 9000 Series Router Cisco IOS XR System Monitoring Configuration Guide for the CRS-1 Router Cisco XR 12000 Series Router*.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write

## Examples

The following example shows the destination type as a label distribution protocol (LDP) prefix and specifies a range of sizes for the echo packets sent:

```
RP/0/RP0/CPU0:router# ping mpls ipv4 140.140.140/32 verbose sweep 100 200 15 repeat 1

Sending 1, [100..200]-byte MPLS Echos to 140.140.140.140/32,
timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.
! size 100, reply addr 196.100.1.26, return code 3
! size 115, reply addr 196.100.1.26, return code 3
! size 130, reply addr 196.100.1.26, return code 3
! size 145, reply addr 196.100.1.26, return code 3
! size 160, reply addr 196.100.1.26, return code 3
! size 175, reply addr 196.100.1.26, return code 3
! size 190, reply addr 196.100.1.26, return code 3

Success rate is 100 percent (7/7), round-trip min/avg/max = 5/6/8 ms
```

The following example shows the destination type as a label distribution protocol (LDP) prefix and specifies FEC type as generic and verbose option:

```
RP/0/RP0/CPU0:router# ping mpls ipv4 11.11.11.11/32 fec-type generic output interface
gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose
```

```
Sending 5, 100-byte MPLS Echos to 11.11.11.11/32,
timeout is 2 seconds, send interval is 0 msec:
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3
```

```
Success rate is 100 percent (5/5), round-trip min/avg/max = 3/4/6 ms
```



## ping mpls traffic-eng

To specify the destination type as an MPLS-TE tunnel and tunnel interface, use the **ping mpls traffic-eng** command in XR EXEC mode.

```
ping mpls traffic-eng tunnel tunnel-ID [dsmap] [exp exp-bits] [force-explicit-null] [interval
min-send-delay] [pad pattern] [repeat count] [reply {dscp dscp-value | reply mode {ipv4 | no-reply
| router-alert} | reply pad-tlv}] [revision version] [size packet-size] [source source-address] [sweep
min-value max-value increment] [timeout timeout] [ttl value] [verbose]
```

Syntax Description		
<b>tunnel</b> <i>tunnel-ID</i>		Specifies the destination type as an MPLS traffic engineering (TE) tunnel and the tunnel interface number. The range for the tunnel interface number is from 0 to 65535.
<b>dsmap</b>		(Optional) Indicates that a downstream mapping (DSMAP) type length and value should be included in the LSP echo request.
<b>exp</b> <i>exp-bits</i>		(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>force-explicit-null</b>		(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
<b>interval</b> <i>min-send-delay</i>		(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
<b>pad</b> <i>pattern</i>		(Optional) Specifies the pad pattern for an echo request.
<b>repeat</b> <i>count</i>		(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
<b>reply dscp</b> <i>dscp-value</i>		(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>reply mode</b> [ <b>ipv4</b>   <b>router-alert</b>   <b>no-reply</b> ]		(Optional) Specifies the reply mode for the echo request packet. <b>no-reply</b> Do not reply <b>ipv4</b> Reply with an IPv4 UDP packet (this is the default) <b>router-alert</b> Reply with an IPv4 UDP packet with the IP router alert set
<b>reply pad-tlv</b>		(Optional) Indicates that a pad TLV should be included.

<b>revision</b> <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: <ul style="list-style-type: none"> <li>• 1 draft-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2 draft-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3 draft-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4 draft-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
<b>size</b> <i>packet-size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>sweep</b> <i>min-value max-value interval</i>	(Optional) Specifies a range of sizes for the echo packets sent. <p><b>min-value</b></p> <p>Minimum or start size for an echo packet (range is 100 to 17986)</p> <p><b>max-value</b></p> <p>Maximum or end size for an echo packet(range is 100 to 17986)</p> <p><b>interval</b></p> <p>Number used to increment an echo packet size(range is 1 to 8993)</p>
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

**Command Default**

**exp** *exp-bits*: 0  
**interval** *min-send-delay*: 0  
**repeat** *count*: 5  
**reply-mode**: IPv4  
**timeout** *timeout* : 2

**Command Modes**

XR EXEC mode

**Command History**

Release	Modification
Release 6.0	This command was introduced.

**Usage Guidelines**

The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.



**Note** The **ping mpls traffic-eng** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write

### Examples

The following example shows how to check connectivity by using the **ping mpls traffic-eng** command when a TE tunnel 10 is present. Return code, reply address, and packet size are displayed due to the **verbose** keyword.

```
RP/0/RP0/CPU0:router# ping mpls traffic-eng tunnel 10 repeat 1 verbose

Sending 1, 100-byte MPLS Echos to tunnel-te10,
      timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.
!   size 100, reply addr 196.100.1.18, return code 3

Success rate is 100 percent (1/1), round-trip min/avg/max = 15/15/15 ms
```

## ping mpls traffic-eng tunnel-tp

To specify the destination type as an MPLS-TP tunnel and tunnel interface, use the **ping mpls traffic-eng tunnel-tp** command in XR EXEC mode.

```
ping mpls traffic-eng tunnel-tp tunnel-id [ddmap] [destination start-address end-address increment]
[dsmap] [encap {cv-ip | cv-non-ip | ip}] [exp exp-bits] [flags {fec | reverse-verification}] [interval
min-send-delay][lsp {active | protect | working}][pad pattern][repeat count] [reply {dscp dscp-value
| mode {control-channel | no-reply } | pad-tlv}] [size packet-size] [source source-address] [sweep
min value max value increment] [timeout timeout] [ttl value] [verbose]
```

Syntax Description	
<b>tunnel-tp</b> <i>tunnel-ID</i>	Specifies the destination type as an MPLS Transport Profile (MPLS-TP) tunnel and the tunnel interface number. The range for the tunnel interface number is 0 to 65535.
<b>ddmap</b>	(Optional) Indicates that a downstream detailed mapping (DDMAP) TLV should be included in the LSP echo request.
<b>destination</b> <i>start-address end-address increment</i>	Specifies a network 127/8 address to be used as the destination address in the echo request packet.  <i>start address</i> Start of the network address.  <i>end address</i> Start of the ending network address.  <i>address increment</i> Incremental value of the network address, which is expressed as a decimal number value or IP address.
<b>dsmap</b>	(Optional) Indicates that a downstream mapping (DSMAP) type length and value should be included in the LSP echo request.
<b>encap</b> { <b>cv-ip</b>   <b>cv-non-ip</b>   <b>ip</b> }	(Optional) Specifies the MPLS-TP encapsulation type to use.  <b>cv-ip</b> Use IP encapsulation with GACH channel 0x0021.  <b>cv-non-ip</b> Use non-IP encapsulation with GACH channel 0x0025.  <b>ip</b> Use IP encapsulation.
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.

<b>flags</b> { <b>fec</b>   <b>reverse-verification</b> }	(Optional) Specifies the flag options to use. <b>fec</b> Request forwarding equivalent class (FEC) stack checking is to be performed at transit routers. <b>reverse-verification</b> Request reverse path connectivity verification.
<b>interval</b> <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
<b>lsp</b> { <b>active</b>   <b>protect</b>   <b>working</b> }	(Optional) Specifies the LSP to use. <b>active</b> Active MPLS-TP tunnel. <b>protect</b> Protect MPLS-TP tunnel. <b>working</b> Working MPLS-TP tunnel. <b>Note</b> Use this option to identify error in the LSP path if the MPLS-TP tunnel is not up.
<b>pad</b> <i>pattern</i>	(Optional) Specifies the pad pattern for an echo request.
<b>repeat</b> <i>count</i>	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>mode</b> [ <b>control-channel</b>   <b>no-reply</b> ]	(Optional) Specifies the reply mode for the echo request packet. <b>control-channel</b> Send reply through a control channel. <b>no-reply</b> Do not reply.
<b>pad-tlv</b>	(Optional) Indicates that a pad TLV should be included.
<b>size</b> <i>packet-size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.

<b>sweep</b> <i>min-value max-value interval</i>	(Optional) Specifies a range of sizes for the echo packets sent.  <b>min-value</b> Minimum or start size for an echo packet (range is 100 to 17986)  <b>max-value</b> Maximum or end size for an echo packet(range is 100 to 17986)  <b>interval</b> Number used to increment an echo packet size(range is 1 to 8993)
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

**Command Default**

**exp** *exp-bits*: 0  
**interval** *min-send-delay*: 0  
**repeat** *count*: 5  
**timeout** *timeout* : 2

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines**

In cases where the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted. The **ping** command sends an echo request packet to an address, and then waits for a reply. Ping output helps you evaluate path-to-host reliability, delays over the path. It also helps you determine whether the host is reachable or is functioning.

Task ID	Task ID	Operation
	mpls-te	read, write
	mpls-ldp	read, write

## Examples

The following sample output is from the **ping mpls traffic-eng tunnel-tp** command using the non-IP-ACH encapsulation:

```
RP/0/RP0/CPU0:router# ping mpls traffic-eng tunnel-tp 1 encap cv-non-ip

Sending 5, 100-byte MPLS Echos to tunnel-tp1,
      timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 3/11/45 ms
```

The following sample output is from the **ping mpls traffic-eng tunnel-tp** command using the non-IP-ACH encapsulation and verbose option:

```
RP/0/RP0/CPU0:router# ping mpls traffic-eng tunnel-tp 1 encap cv-non-ip

Sending 5, 100-byte MPLS Echos to tunnel-tp1,
      timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

!      size 100, reply node id 12.12.12.3, global id 0, return code 3
!      size 100, reply node id 12.12.12.3, global id 0, return code 3
!      size 100, reply node id 12.12.12.3, global id 0, return code 3
!      size 100, reply node id 12.12.12.3, global id 0, return code 3
!      size 100, reply node id 12.12.12.3, global id 0, return code 3

Success rate is 100 percent (5/5), round-trip min/avg/max = 3/3/4 ms
```

The following sample output is from the **ping mpls traffic-eng tunnel-tp** command using the non-IP-ACH encapsulation and DSMAP/DDMAP option:

```
RP/0/RP0/CPU0:router# ping mpls traffic-eng tunnel-tp 1 encap cv-non-ip

Sending 1, 100-byte MPLS Echos to tunnel-tp1,
      timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
```

```
'P' - no rx intf label prot, 'p' - premature termination of LSP,  
'R' - transit router, 'I' - unknown upstream index,  
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
L      size 100, reply node id 12.12.12.3, global id 0, return code 8  
Echo Reply received from Node ID 12.12.12.3, Global ID 0  
  DSMAP 0, Ingress Link ID 3, Egress Link ID 4  
    Depth Limit 0, MRU 1500 [Labels: 1100 Exp: 0]
```

Success rate is 0 percent (0/1)



## ping pseudowire (AToM)

To verify connectivity between provider edge (PE) LSRs in an Any Transport over MPLS (AToM) setup, use the **ping pseudowire** command in XR EXEC mode.

```
ping [mpls] pseudowire remote-PE-address pw-id [exp exp-bits] [interval min-send-delay] [pad
pattern] [repeat count] [reply {dscp dscp-value | reply mode {ipv4 | no-reply | router-alert |
control-channel} | reply pad-tlv}] [size packet-size] [source source-address] [sweep min-value
max-value increment] [timeout timeout] [ttl value] [verbose]
```

Syntax Description	
<b>mpls</b>	(Optional) Verifies the Labeled Switch Path (LSP).
<i>remote-PE address</i>	IP address of the remote PE LSR.
<i>pw-id</i>	Pseudowire ID that identifies the pseudowire in which MPLS connectivity is being verified. The pseudowire is used to send the echo request packets. The range is from 1 to 4294967295.
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>interval</b> <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
<b>pad</b> <i>pattern</i>	(Optional) Specifies the pad pattern for an echo request.
<b>repeat</b> <i>count</i>	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

<b>reply mode</b> { <b>ipv4</b>   <b>router-alert</b>   <b>no-reply</b>   <b>control-channel</b> }	(Optional) Specifies the reply mode for the echo request packet.  <b>no-reply</b> Do not reply  <b>ipv4</b> Reply with an IPv4 UDP packet (the default)  <b>router-alert</b> Reply with an IPv4 UDP packet with the IP router alert set  <b>control-channel</b> Force the use of a VCCV control channel.  Reply using an application for a defined control channel. This applies only to pseudowires in which VCCV is used in the reply path. This is the default choice for pseudowire ping.
<b>reply pad-tlv</b>	(Optional) Indicates that a reply pad TLV should be included.
<b>size</b> <i>packet-size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>sweep</b> <i>min-value max-value interval</i>	Specifies a range of sizes for the echo packets sent.  <b>min-value</b> Minimum or start size for an echo packet (range is 100 to 17986)  <b>max-value</b> Maximum or end size for an echo packet(range is 100 to 17986)  <b>interval</b> Number used to increment an echo packet size(range is 1 to 8993)
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval in seconds. Range is 0 to 3600. Default is 2 seconds.
<b>ttl</b> <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

**Command Default**

**exp** *exp bits*: 0  
**interval** *min-send-delay*: 0  
**repeat** *count*: 5  
**reply-mode**: IPv4  
**timeout** *timeout* : 2

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.
	Release 6.3.2	Supports segment routing and SR-TE policy preferred path as transport to reach remote PE. <b>Note</b> Label distribution protocol (LDP) is required to signal PW up, but is not required as transport.

**Usage Guidelines** In cases in which the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.



**Note** The **ping mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

AToM VCCV allows the sending of control packets inband of an AToM pseudowire (PW) from the originating provider edge (PE) router. The transmission is intercepted at the destination PE router, instead of being forwarded to the customer edge (CE) router. This lets you use MPLS LSP ping to test the pseudowire section of AToM virtual circuits (VCs).

The no interactive version of the **ping pseudowire (AToM)** command is supported.

The control word setting is either enabled along the entire path between the Terminating-Provider Edge (T-PE) or it is completely disabled. If the control word configuration is enabled on one segment and disabled on another segment, the multisegment pseudowire does not come up.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write

### Examples

The following example shows how the **ping mpls pseudowire** command is used to verify PE to PE connectivity in which the remote PE address is 150.150.150.150. Only one echo request packet is sent and the remote PE is to answer using IPv4 instead of the control channel.

```
RP/0/RP0/CPU0:router# ping mpls pseudowire 150.150.150.150 21 repeat 1 reply mode ipv4
```

```
Sending 1, 100-byte MPLS Echos to 150.150.150.150 VC: 21,  
timeout is 2 seconds, send interval is 0 msec:
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,  
'L' - labeled output interface, 'B' - unlabeled output interface,  
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,  
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,  
'P' - no rx intf label prot, 'p' - premature termination of LSP,  
'R' - transit router, 'I' - unknown upstream index,  
'X' - unknown return code, 'x' - return code 0
```

```
Type escape sequence to abort.
```

```
!
```

```
Success rate is 100 percent (1/1), round-trip min/avg/max = 23/23/23 ms
```

## ping mpls traffic-eng tunnel-te (P2P)

To specify the destination type as an MPLS-TE tunnel and tunnel interface, use the **ping mpls traffic-eng tunnel-te** command in XR EXEC mode.

```
ping mpls traffic-eng tunnel-te tunnel-ID {destination start-address end-address increment}[dsmap]
[exp exp-bits] [force-explicit-null] [interval min-send-delay] [lsp {active | path-protect}][pad
pattern] [repeat count] [reply {dscp dscp-value | mode {ipv4 | no-reply | router-alert} | pad-tlv}]
[revision version] [size packet-size] [source source-address] [sweep min-value max-value increment]
[timeout timeout] [ttl value] [verbose]
```

### Syntax Description

<b>tunnel-te</b> <i>tunnel-ID</i>	Specifies the destination type as an MPLS traffic engineering (TE) tunnel and the tunnel interface number. The range for the tunnel interface number is 0 to 65535.
<b>destination</b> <i>start-address end-address increment</i>	Specifies a network 127/8 address to be used as the destination address in the echo request packet.  <i>start address</i> Start of the network address.  <i>end address</i> Start of the ending network address.  <i>address increment</i> Incremental value of the network address, which is expressed as a decimal number value or IP address.
<b>dsmap</b>	Specifies a <b>downstream mapping</b> type length and value which should be included in the LSP echo request.
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>force-explicit-null</b>	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
<b>interval</b> <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
<b>lsp</b> { <b>active</b>    <b>path-protect</b> }	(Optional) Specifies the LSP to use.
<b>pad</b> <i>pattern</i>	(Optional) Specifies the pad pattern for an echo request.
<b>repeat</b> <i>count</i>	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
<b>reply</b> <b>dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

<b>mode</b> [ <b>ipv4</b>   <b>router-alert</b>   <b>no-reply</b> ]	(Optional) Specifies the reply mode for the echo request packet.  <b>no-reply</b> Do not reply  <b>ipv4</b> Reply with an IPv4 UDP packet (this is the default)  <b>router-alert</b> Reply with an IPv4 UDP packet with the IP router alert set
<b>reply pad-tlv</b>	(Optional) Indicates that a pad TLV should be included.
<b>revision</b> <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field:  <ul style="list-style-type: none"> <li>• 1 RFC-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2 RFC-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3 RFC-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4 RFC-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
<b>size</b> <i>packet-size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>sweep</b> <i>min-value max-value interval</i>	(Optional) Specifies a range of sizes for the echo packets sent.  <b>min-value</b> Minimum or start size for an echo packet (range is 100 to 17986)  <b>max-value</b> Maximum or end size for an echo packet(range is 100 to 17986)  <b>interval</b> Number used to increment an echo packet size(range is 1 to 8993)
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).

---

**verbose** (Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

---

**Command Default**

**exp** *exp-bits*: 0  
**interval** *min-send-delay*: 0  
**repeat** *count*: 5  
**reply-mode**: IPv4  
**timeout** *timeout* : 2

**Command Modes** XR EXEC mode

**Command History**

Release	Modification
Release 6.0	This command was introduced.

**Usage Guidelines**

The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then waits for a reply. Ping output helps you evaluate path-to-host reliability, delays over the path. It also helps you determine whether the host is reachable or is functioning.

**Task ID**

Task ID	Operation
mpls-te	read, write
mpls-ldp	read, write

## ping pseudowire multisegment

To verify the ping over the multisegment pseudowire, use the **ping pseudowire multisegment** command in XR EXEC mode.

```
ping [mpls] pseudowire multisegment end-address pw-id [destinationfec sender-address
remote-address pw-id-address] [exp exp-bits] [interval min-send-delay] [pad pattern] [repeat
count] [segment-count segment-number] [reply {dscp dscp-value | mode {ipv4 | no-reply | router-alert
| control-channel} | pad-tlv}] [size packet-size] [source source-address] [sweep min value max value
increment] [timeout timeout] [verbose]
```

Syntax Description	
<b>mpls</b>	(Optional) Verifies the Label Switched Path (LSP).
<i>end-address</i>	Target end address.
<i>pw-id</i>	Virtual circuit of the pseudowire ID that identifies the pseudowire in which MPLS connectivity is being verified. The pseudowire sends the echo request packets. Range is from 1 to 4294967295.
<b>destinationfec</b> <i>sender-address</i> <i>remote-address</i> <i>pw-id-address</i>	(Optional) Specifies the destination for the Forwarding Equivalence Class (FEC) .  <b>sender-address</b>  Sender-PE (S-PE) address for the destination FEC. The S-PE address is placed in the S-PE address field of the FEC 128 Pseudowire (RFC 4379).  <b>remote-address</b>  Remote address (S-PE address for the partial ping) for the destination FEC. The address is placed in the remote PE address of the FEC 128 Pseudowire (RFC 4379).  <b>pw-id-address</b>  Pseudowire ID of the pseudowire segment to the remote T-PE address (S-PE address for the partial ping).
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>interval</b> <i>min-send-delay</i>	(Optional) Specifies a send interval between requests (in milliseconds). Range is 0 to 3600000. Default is 0.
<b>pad</b> <i>pattern</i>	(Optional) Specifies the pad pattern for an echo request.
<b>repeat</b> <i>count</i>	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.



<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>reply mode</b> { <b>ipv4</b>   <b>router-alert</b>   <b>no-reply</b>   <b>control-channel</b> }	(Optional) Specifies the reply mode for the echo request packet.  <b>no-reply</b> Do not reply  <b>ipv4</b> Reply with an IPv4 UDP packet (the default)  <b>router-alert</b> Reply with an IPv4 UDP packet with the IP router alert set  <b>control-channel</b> Force the use of a VCCV control channel.  Reply using an application for a defined control channel. This applies only to pseudowires in which VCCV is used in the reply path. This is the default choice for pseudowire ping.
<b>segment-count</b>	(Optional) Specifies the segment count for the FEC destination of the multisegment pseudowire . The segment count is used for the pseudowire label for the TTL value.
<i>segment-number</i>	(Optional) Value of the segment count. Range is 1 to 255.
<b>pad-tlv</b>	(Optional) Indicates that a pad TLV should be included.
<b>size</b> <i>packet-size</i>	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
<b>sweep</b> <i>min value max value interval</i>	Specifies a range of sizes for the echo packets sent.  <b>min value</b> Minimum or start size for an echo packet (range is 100 to 17986)  <b>max value</b> Maximum or end size for an echo packet (range is 100 to 17986)  <b>interval</b> Number used to increment an echo packet size(range is 1 to 8993)

<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval in seconds. Range is 0 to 3600. Default is 2 seconds.
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

**Command Default**

**exp** *exp-bits* : 0  
**interval** *min-send-delay* : 0  
**repeat** *count*: 5  
**reply-mode**: ipv4  
**size** *packet-size* : 100  
**timeout** *timeout* : 2 seconds

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines**

The partial ping works only if the **destinationfec** keyword is used.

The control word setting is either enabled along the entire path between the Terminating-Provider Edge (T-PE) or it is completely disabled. If the control word configuration is enabled on one segment and disabled on another segment, the multisegment pseudowire does not come up.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write

The following example shows the local pseudowire segment from T-PE1 is set to S-PE1 80.80.80.80 and the pseudowire ID is set to 100. The last pseudowire segment of the multisegment pseudowire is from S-PE1 80.80.80.80 to T-PE2 90.90.90.90 and the pseudowire ID is set to 300.

```
RP/0/RP0/CPU0:router# ping pseudowire multisegment 80.80.80.80 100 destinationfec
80.80.80.80 90.90.90.90 300 segment-count 2
```

```
Sending 5, 100-byte MPLS Echos to 80.80.80.80 VC: 100, 90.90.90.90 VC: 300
timeout is 2 seconds, send interval is 0 msec, PW Label TTL is 2:
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
```

'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,  
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,  
'P' - no rx intf label prot, 'p' - premature termination of LSP,  
'R' - transit router, 'I' - unknown upstream index,  
'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

!!!!

Success rate is 100 percent (5/5), round-trip min/avg/max = 6/10/18 ms

# show mpls oam

To display MPLS OAM information, use the **show mpls oam** command in XR EXEC mode.

**show mpls oam** {**client** | **counters** {**global** | **packet**} | **interface** *type interface-path-id*}

Syntax Description	
<b>client</b>	Displays clients registered with LSPV server.
<b>counters global</b>	Displays LSP verification global counters.
<b>counters packet</b>	Displays LSP verification packet counters.
<b>interface</b>	Displays LSP verification information for a specific interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.
	<p><b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read
	mpls-ldp	read
	mpls-static	read

## Examples

The following example shows how to display MPLS OAM client information:

```
RP/0/RP0/CPU0:router# show mpls oam client

Client Process: l2vpn_mgr Node: 0/0/SP Pid: 418014
Client Process: te_control Node: 0/0/SP Pid: 639227
```

This table describes the significant fields shown in the display.

*Table 1: show mpls oam client Command Field Descriptions*

<b>Field</b>	<b>Description</b>
Client Process	Process of client.

# show mpls oam database

To display MPLS OAM database information, use the **show mpls oam database** command in XR EXEC mode.

**show mpls oam database** { **requests** | **tt-requests**} [**detail**] [**handle** *handle-value* ]

Syntax Description	
<b>requests</b>	Displays request database
<b>tt-requests</b>	Displays tree trace request database
<b>detail</b>	(Optional) Displays displayed information.
<b>handle</b>	(Optional) Displays handle information.
<i>handle-value</i>	Generic handle value. Range is from 0 to 4294967295.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	mpls-te	read
	mpls-ldp	read
	mpls-static	read

## Examples

The following example shows how to display detailed MPLS OAM database information:

```
RP/0/RP0/CPU0:router# show mpls oam database request detail
```

## traceroute mpls ipv4

To learn the routes that packets follow when traveling to their Label Distribution Protocol (LDP) IPv4 destination, use the **traceroute mpls** command in XR EXEC mode.

```
traceroute mpls ipv4address/mask [destination start-address end-address address-increment] [exp
exp-bits] [flags fec] [force-explicit-null] [output {interface type interface-path-id [nexthop
nexthop-address] | [nexthop nexthop-address}}] [reply {dscp dscp-value | reply mode {ipv4 |
router-alert}}] [revision version] [source source-address] [timeout timeout] [ttl value] [verbose]
[fec-type {bgp | generic | ldp}]
```

### Syntax Description

<i>address/mask</i>	Specifies the destination type as a label distribution protocol (LDP) prefix. Address prefix of the target and number of bits in the target address network mask.
<b>destination</b> start-address end-address address-increment	Specifies a network 127 address to be used as the destination address in the echo request packet.  <b>start address</b> Start of the network address.  <b>end address</b> End of the network address.  <b>address increment</b> Incremental value of the network address.
<b>exp</b> exp-bits	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>flags fec</b>	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
<b>force-explicit-null</b>	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
<b>output interface</b>	(Optional) Specifies the output interface in which echo request packets are sent.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information, use the question mark (?) online help function.
<b>nexthop</b>	(Optional) Specifies the IP address for the next hop.

<i>nexthop-address</i>	(Optional) IP address for the next hop.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>reply mode</b> { <b>ipv4</b>   <b>router-alert</b> }	(Optional) Specifies the reply mode for the echo request packet. <b>ipv4</b> Reply with IPv4 UDP packet (this is the default) <b>router-alert</b> Reply with IPv4 UDP packet with router alert
<b>revision</b> <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: <ul style="list-style-type: none"> <li>• 1 RFC-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2 RFC-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3 RFC-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4 RFC-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>timeout</b> <i>timeoutt</i>	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the maximum number of hops (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.
<b>fec-type</b>	(Optional) Specifies FEC type to be used. <b>bgp</b> Use FEC type as BGP <b>generic</b> Use FEC type as generic <b>ldp</b> Use FEC type as LDP

**Command Default**  
**exp** *exp-bits*: 0  
**reply mode**: IPv4  
**timeout** *timeout*: 2

**Command Modes**  
XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0	This command was introduced.



## Usage Guidelines



**Note** The **traceroute mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSPs path, it is treated as a physical interface.

For detailed configuration information about MPLS LSP trace operations, see *System Monitoring Configuration Guide*.

Task ID	Task ID	Operations
	mpls-te	read, write
	mpls-ldp	read, write

## Examples

The following example shows how to trace a destination:

```
RP/0/RP0/CPU0:router# traceroute mpls ipv4 140.140.140.140/32
destination 127.0.0.10 127.0.0.15 1
```

```
Tracing MPLS Label Switched Path to 140.140.140.140/32, timeout is 2
seconds
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
Destination address 127.0.0.10
```

```
 0 196.100.1.41 MRU 4470 [Labels: 19 Exp: 0]
L 1 196.100.1.42 MRU 4470 [Labels: 86 Exp: 0] 360 ms
 2 196.100.1.50 MRU 4470 [Labels: implicit-null Exp: 0] 8 ms
! 3 196.100.1.18 9 ms
```

The following example shows how to trace a destination with FEC type specified as generic and verbose option:

```
RP/0/RP0/CPU0:router# traceroute mpls ipv4 11.11.11.11/32 fec-type generic output interface
gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose
```

```
Tracing MPLS Label Switched Path to 11.11.11.11/32, timeout is 2 seconds
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
```

'P' - no rx intf label prot, 'p' - premature termination of LSP,  
'R' - transit router, 'I' - unknown upstream index,  
'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

```
0 172.40.103.1 172.40.103.2 MRU 1500 [Labels: 16038 Exp: 0]
L 1 172.40.103.2 173.101.103.1 MRU 1500 [Labels: 16037 Exp: 0] 6 ms, ret code 8
L 2 173.101.103.1 11.101.11.11 MRU 1500 [Labels: implicit-null Exp: 0] 4 ms, ret code 8
! 3 11.101.11.11 6 ms, ret code 3
```

## traceroute mpls multipath

To discover all possible paths of an LSP between the ingress and egress routers, use the **traceroute mpls multipath** command in XR EXEC mode.

```
traceroute mpls multipath ipv4 address/mask [destination start-address/end-address address-increment]
[exp exp-bits] [flags fec] [force-explicit-null] [hashkey ipv4 bitmap bit-size] [interval min-send-delay]
[output {interface type interface-path-id [nexthop nexthop-address] | [nexthop nexthop-address]}]
[reply {dscp dscp-value | reply mode {ipv4 | router-alert}}] [retry-count count] [revision version]
[source source-address] [timeout timeout] [ttl value] [verbose] [fec-type {bgp | generic | ldp}]
```

### Syntax Description

<b>ipv4</b>	Specifies the destination type as a Label Distribution Protocol (LDP) IPv4 address.
<i>address/mask</i>	Address prefix of the target and number of bits in the target address network mask.
<b>destination</b> <i>start-address end-address address-increment</i>	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet. <b>start-address</b> Start of the network address. <b>end-address</b> End of the network address. <b>address-increment</b> Incremental value of the network address.
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>flags fec</b>	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
<b>force-explicit-null</b>	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
<b>hashkey ipv4 bitmap</b> <i>bit-size</i>	(Optional) Allows user control of the hash key/multipath settings. Range is 0 to 256. The default is 32.
<b>interval</b> <i>min-send-delay</i>	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
<b>output interface</b>	(Optional) Specifies the output interface where echo request packets are sent.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.

<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information, use the question mark (?) online help function.
<b>nexthop</b>	(Optional) Specifies the IP address for the next hop.
<i>nexthop-address</i>	(Optional) IP address for the next hop.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>reply mode</b> [ <b>ipv4</b>   <b>router-alert</b> ]	(Optional) Specifies the reply mode for the echo request packet.  <b>ipv4</b> Reply with IPv4 UDP packet (this is the default)  <b>router-alert</b> Reply with IPv4 UDP packet with router alert
<b>retry-count</b> <i>count</i>	(Optional) Specifies the number of retry attempts during multipath LSP traceroute. A retry is attempted if an outstanding echo request <ul style="list-style-type: none"> <li>• times out waiting for the corresponding echo reply.</li> <li>• fails to find a valid destination address set to exercise a specific outgoing path. Range is 0 to 10. Default is 3.</li> </ul>
<b>revision</b> <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: <ul style="list-style-type: none"> <li>• 1 RFC-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2 RFC-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3 RFC-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4 RFC-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the maximum number of hops (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

---

<b>fec-type</b>	(Optional) Specifies FEC type to be used.
	<b>bgp</b>
	Use FEC type as BGP
	<b>generic</b>
	Use FEC type as generic
	<b>ldp</b>
	Use FEC type as LDP

---



---

<b>Command Default</b>	<b>exp</b> <i>exp-bits</i> : 0
	<b>hashkey ipv4 bitmap</b> <i>bit-size</i> : 4
	<b>interval</b> <i>min-send-delay</i> : 0
	<b>reply mode</b> : IPv4
	<b>retry-count</b> : 3
	<b>timeout</b> <i>timeout</i> : 2

---

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.0	This command was introduced.

---

**Usage Guidelines** The **hashkey ipv4 bitmap** keyword and *bit-size* value control how many addresses are encoded in the DSMAP multipath field. Larger values allow more coverage of equal cost multiple paths throughout the network, but with more processing at the head, mid, and tail routers.

---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-te	read, write
	mpls-ldp	read, write

---

**Examples** The following example shows how to specify the destination type as an LDP IPv4 prefix:

```
RP/0/RP0/CPU0:router# traceroute mpls multi ipv4 140.140.140.140/32 verbose
force-explicit-null
```

```
Starting LSP Path Discovery for 140.140.140.140/32
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
```

```

'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

LL!
Path 0 found,
output interface POS0/2/0/3 source 196.100.1.61 destination 127.0.0.1
0 196.100.1.61 196.100.1.62 MRU 4470 [Labels: 18/explicit-null Exp: 0/0] multipaths 0
L 1 196.100.1.62 196.100.1.10 MRU 4470 [Labels: 17/explicit-null Exp: 0/0] ret code 8
multipaths 1
L 2 196.100.1.10 196.100.1.18 MRU 4470 [Labels: implicit-null/explicit-null Exp: 0/0] ret
code 8 multipaths 1
! 3 196.100.1.1018, ret code 3 multipaths 0
LL!
Path 1 found,
output interface GigabitEthernet0/3/0/0 source 196.100.1.5 destination 127.0.0.1
0 196.100.1.5 196.100.1.37 6 MRU 1500 [Labels: 18/explicit-null Exp: 0/0] multipaths 0
L 1 196.100.1.6 196.100.1.10 MRU 4470 [Labels: 17/explicit-null Exp: 0/0] ret code 8
multipaths 1
L 2 10196.0100.21.5 1010 196.0100.21.10 18 MRU 4470 [Labels: implicit-null/explicit-null
Exp: 0/0] ret code 8 multipaths 1
! 3 10196.0100.21.1018, ret code 3 multipaths 0

Paths (found/broken/unexplored) (2/0/0)
Echo Request (sent/fail) (6/0)
Echo Reply (received/timeout) (6/0)
Total Time Elapsed 80 ms

```

The following example shows how to specify the FEC type as LDP with verbose option:

```

RP/0/RP0/CPU0:router# traceroute mpls multipath ipv4 11.11.11.11/32 fec-type ldp output
interface gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose

```

Starting LSP Path Discovery for 11.11.11.11/32

```

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0

```

Type escape sequence to abort.

```

LL!
Path 0 found,
output interface GigabitEthernet0/0/0/3 nexthop 172.40.103.2
source 172.40.103.1 destination 127.0.0.0
0 172.40.103.1 172.40.103.2 MRU 1500 [Labels: 16038 Exp: 0] multipaths 0
L 1 172.40.103.2 173.101.103.1 MRU 1500 [Labels: 16037 Exp: 0] ret code 8 multipaths 1
L 2 173.101.103.1 11.101.11.11 MRU 1500 [Labels: implicit-null Exp: 0] ret code 8 multipaths
1
! 3 11.101.11.11, ret code 3 multipaths 0

Paths (found/broken/unexplored) (1/0/0)
Echo Request (sent/fail) (3/0)
Echo Reply (received/timeout) (3/0)
Total Time Elapsed 21 ms

```

## traceroute mpls traffic-eng

To specify the destination type as an MPLS traffic engineering (TE) tunnel, use the **traceroute mpls traffic-eng** command in XR EXEC mode.

```
traceroute mpls traffic-eng tunnel tunnel-ID [destination start-address end-address address-increment
increment-mask] [exp exp-bits] [flags fec] [force-explicit-null] [reply {dscp dscp-value | reply mode
{ipv4 | router-alert}}] [revision version] [source source-address] [timeout timeout] [ttl value]
[verbose]
```

Syntax Description	
<b>tunnel</b>	Specifies the MPLS-TE tunnel type.
<i>tunnel-ID</i>	Tunnel interface.
<b>destination</b> <i>start-address end-address address-increment increment-mask</i>	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet. <b>start-address</b> Start of the network address. <b>end-address</b> End of the network address. <b>address-increment</b> Incremental value of the network address. <b>increment-mask</b> Incremental mask of the network address.
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>flags fec</b>	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
<b>force-explicit-null</b>	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>reply mode</b> [ <b>ipv4</b>   <b>router-alert</b> ]	(Optional) Specifies the reply mode for the echo request packet. <b>ipv4</b> Reply with IPv4 UDP packet (this is the default) <b>router-alert</b> Reply with IPv4 UDP packet with router alert

<b>revision</b> <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: <ul style="list-style-type: none"> <li>• 1 RFC-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2 RFC-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3 RFC-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4 RFC-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the maximum number of hops (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

**Command Default**

**exp** *exp-bits* : 0

**reply mode**: IPv4

**timeout** *timeout* : 2

**Command Modes** XR EXEC mode

**Command History**

Release	Modification
Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

**Task ID**

Task ID	Operation
mpls-te	read
mpls-ldp	read

The following example shows how to specify the destination as a MPLS-TE tunnel:

```
RP/0/RP0/CPU0:router# traceroute mpls traffic-eng tunnel 13

Tracing MPLS TE Label Switched Path on tunnel-te13, timeout is 2 seconds

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

0 0.0.0.0 11.0.0.1 MRU 1500 [Labels: 16003 Exp: 0]
```



```
L 1 192.168.200.2 192.168.170.1 MRU 1500 [Labels: implicit-null Exp: 0] 110 ms
! 2 192.168.170.1 0.0.0.0 MRU 0 [No Label] 169 ms
```

## tracertoute pseudowire multisegment

To verify the Labeled Switch Path (LSP) for the multisegment pseudowire, use the **tracertoute pseudowire multisegment** command in XR EXEC mode.

```
tracertoute pseudowire multisegment address pw-id [exp exp-bits] [flags fec] [reply {dscp dscp-value | mode {ipv4 | no-reply | router-alert | control-channel} | pad-tlv}] [source source-address] [timeout timeout] [verbose]
```

Syntax Description	
<i>address</i>	Address of the next S-PE.
<i>pw-id</i>	Pseudowire ID of the pseudowire segment to the next S-PE.
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>flags fec</b>	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>mode</b> { <b>ipv4</b>   <b>router-alert</b>   <b>no-reply</b>   <b>control-channel</b> }	(Optional) Specifies the reply mode for the echo request packet. <b>no-reply</b> Do not reply <b>ipv4</b> Reply with an IPv4 UDP packet (the default) <b>router-alert</b> Reply with an IPv4 UDP packet with the IP router alert set <b>control-channel</b> Force the use of a VCCV control channel. Reply using an application for a defined control channel. This applies only to pseudowires in which VCCV is used in the reply path. This is the default choice for pseudowire ping.
<b>pad-tlv</b>	(Optional) Indicates that a pad TLV should be included.
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval in seconds. Range is 0 to 3600. Default is 2 seconds.
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.
<b>Command Default</b>	<b>exp</b> <i>exp-bits</i> : 0

**reply-mode:** ipv4

**timeout** *timeout* : 2 seconds

---

**Command Modes** XR EXEC mode

---

**Command History**

Release	Modification
Release 6.0	This command was introduced.

---



---

**Usage Guidelines** No specific guidelines impact the use of this command.

---

**Task ID**

Task ID	Operation
mpls-te	read
mpls-ldp	read

---

The following example shows that the next pseudowire segment and traceroute go through each hop in which each hop is a S-PE or remote T-PE. The local segment from T-PE1 is set to S-PE1 80.80.80.80 and the pseudowire ID is set to 100. The last pseudowire segment of the multisegment pseudowire is from S-PE1 80.80.80.80 to T-PE2 90.90.90.90 and the pseudowire ID is set to 300.

```
RP/0/RP0/CPU0:router# traceroute pseudowire multisegment 80.80.80.80 100
```

```
Tracing MS-PW to 80.80.80.80 VC: 100, timeout is 2 seconds
```

```
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
'L' - labeled output interface, 'B' - unlabeled output interface,
'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
'P' - no rx intf label prot, 'p' - premature termination of LSP,
'R' - transit router, 'I' - unknown upstream index,
'X' - unknown return code, 'x' - return code 0
```

Type escape sequence to abort.

```
0 1.2.1.2 MRU 1500 [Outgoing Labels: 20495 Exp: 0]
L 1 1.2.1.1 MRU 1500 [Outgoing Labels: 24587 Exp: 0] 13 ms
   local 70.70.70.70 remote 80.80.80.80 pw-id 100
! 2 1.4.1.1 9 ms
   local 80.80.80.80 remote 90.90.90.90 pw-id 300
```

## traceroute mpls traffic-eng tunnel-te (P2P)

To specify the destination type as an MPLS traffic engineering (TE) tunnel for a point-to-point connection, use the **traceroute mpls traffic-eng tunnel-te (P2P)** command in XR EXEC mode.

```
traceroute mpls traffic-eng tunnel-te tunnel-ID [destination start-address end-address
address-increment increment-mask] [exp exp-bits] [flags fec] [force-explicit-null] [reply {dscp
dscp-value | mode {ipv4 | router-alert}}] [revision version] [source source-address] [timeout
timeout] [ttl value] [verbose]
```

### Syntax Description

<b>tunnel-te</b>	Specifies the MPLS-TE tunnel type.
<i>tunnel-ID</i>	Tunnel interface.
<b>destination</b> <i>start-address end-address address-increment increment-mask</i>	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet.  <i>start-address</i> Start of the network address.  <i>end-address</i> End of the network address.  <i>address-increment</i> Incremental value of the network address.  <i>increment-mask</i> Incremental mask of the network address.
<b>exp</b> <i>exp-bits</i>	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
<b>flags fec</b>	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
<b>force-explicit-null</b>	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>reply-mode</b> [ <b>ipv4</b>   <b>router-alert</b> ]	(Optional) Specifies the reply mode for the echo request packet.  <b>ipv4</b> Reply with IPv4 UDP packet (this is the default)  <b>router-alert</b> Reply with IPv4 UDP packet with router alert

<b>revision</b> <i>version</i>	(Optional) Specifies the Cisco extension TLV versioning field: <ul style="list-style-type: none"> <li>• 1 RFC-ietf-mpls-lsp-ping-03 (initial)</li> <li>• 2 RFC-ietf-mpls-lsp-ping-03 (rev 1)</li> <li>• 3 RFC-ietf-mpls-lsp-ping-03 (rev 2)</li> <li>• 4 RFC-ietf-mpls-lsp-ping-09 (initial)</li> </ul>
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the maximum number of hops (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

**Command Default**  
**exp** *exp-bits* : 0  
**reply-mode**: IPv4  
**timeout** *timeout* : 2

**Command Modes**  
XR EXEC mode

**Command History**

Release	Modification
Release 6.0	This command was introduced.

**Usage Guidelines**  
No specific guidelines impact the use of this command.

**Task ID**

Task ID	Operation
mpls-te	read
mpls-ldp	read

The following example shows how to specify the destination as a MPLS-TE tunnel:

```
RP/0/RP0/CPU0:router# traceroute mpls traffic-eng tunnel-te 13
Tracing MPLS TE Label Switched Path on tunnel-te13, timeout is 2 seconds
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
       'L' - labeled output interface, 'B' - unlabeled output interface,
       'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
       'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
       'P' - no rx intf label prot, 'p' - premature termination of LSP,
       'R' - transit router, 'I' - unknown upstream index,
       'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

0 0.0.0.0 11.0.0.1 MRU 1500 [Labels: 16003 Exp: 0]
```

```
tracroute mpls traffic-eng tunnel-te (P2P)
```

```
L 1 192.168.200.2 192.168.170.1 MRU 1500 [Labels: implicit-null Exp: 0] 110 ms  
! 2 192.168.170.1 0.0.0.0 MRU 0 [No Label] 169 ms
```

## traceroute mpls traffic-eng tunnel-tp

To learn the routes that packets follow when traveling to their destination, use the **traceroute mpls traffic-eng tunnel-tp** command in XR EXEC mode.

```
traceroute mpls traffic-eng tunnel-tp tunnel-id [ddmap] [destination start-address end-address increment] [encap {cv-ip | cv-non-ip | ip}] [exp exp-bits] [flags {fec | reverse-verification}] [lsp {active | protect | working}][reply {dscp dscp-value | mode {control-channel | no-reply} | pad-tlv}] [source source-address] [timeout timeout] [ttl value] [verbose]
```

Syntax Description		
<b>tunnel-tp</b> <i>tunnel-ID</i>		Specifies the destination type as an MPLS Transport Profile (MPLS-TP) tunnel and the tunnel interface number. The range for the tunnel interface number is 0 to 65535.
<b>ddmap</b>		(Optional) Indicates that a downstream detailed mapping (DDMAP) TLV should be included in the LSP echo request.
<b>destination</b> <i>start-address end-address increment</i>		Specifies a network 127/8 address to be used as the destination address in the echo request packet.  <i>start address</i> Start of the network address.  <i>end address</i> Start of the ending network address.  <i>address increment</i> Incremental value of the network address, which is expressed as a decimal number value or IP address.
<b>encap</b> { <b>cv-ip</b>   <b>cv-non-ip</b>   <b>ip</b> }		(Optional) Specifies the MPLS-TP encapsulation type to use.  <b>cv-ip</b> Use IP encapsulation with GACH channel 0x0021.  <b>cv-non-ip</b> Use non-IP encapsulation with GACH channel 0x0025.  <b>ip</b> Use IP encapsulation.
<b>exp</b> <i>exp-bits</i>		(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.

<b>flags</b> { <b>fec</b>   <b>reverse-verification</b> }	(Optional) Specifies the flag options to use. <b>fec</b> Request forwarding equivalent class (FEC) stack checking is to be performed at transit routers. <b>reverse-verification</b> Request reverse path connectivity verification.
<b>lsp</b> { <b>active</b>   <b>protect</b>   <b>working</b> }	(Optional) Specifies the LSP to use. <b>active</b> Active MPLS-TP tunnel. <b>protect</b> Protect MPLS-TP tunnel. <b>working</b> Working MPLS-TP tunnel. <b>Note</b> Use this option to identify error in the LSP path if the MPLS-TP tunnel is not up.
<b>reply dscp</b> <i>dscp-value</i>	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
<b>mode</b> [ <b>control-channel</b> ]	(Optional) Specifies the reply mode for the echo request packet. <b>control-channel</b> Send reply via a control channel.
<b>source</b> <i>source-address</i>	(Optional) Specifies the source address used in the echo request packet.
<b>timeout</b> <i>timeout</i>	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
<b>ttl</b> <i>value</i>	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
<b>verbose</b>	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

**Command Default****exp** *exp-bits*: 0**timeout** *timeout* : 2**Command Modes**

XR EXEC mode



Command History	Release	Modification
	Release 6.0	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	mpls-te	read, write
	mpls-ldp	read, write

### Examples

The following sample output is from the **traceroute mpls traffic-eng tunnel-tp** command using the non-IP-ACH encapsulation:

```
RP/0/RP0/CPU0:router# traceroute mpls traffic-eng tunnel-tp 1 encap cv-non-ip

Tracing MPLS TP Label Switched Path on tunnel-tp1, timeout is 2 seconds

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
        'L' - labeled output interface, 'B' - unlabeled output interface,
        'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
        'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
        'P' - no rx intf label prot, 'p' - premature termination of LSP,
        'R' - transit router, 'I' - unknown upstream index,
        'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

 0 Node ID 10.10.10.1, Global ID 0 MRU 1500 [Labels: 1000 Exp: 0]
L 1 Node ID 10.10.10.2, Global ID 0 MRU 1500 [Labels: 1100 Exp: 0] 3 ms
! 2 Node ID 12.12.12.3, Global ID 0 4 ms
```

The following sample output is from the **traceroute mpls traffic-eng tunnel-tp** command using the non-IP-ACH encapsulation and verbose option:

```
RP/0/RP0/CPU0:router# traceroute mpls traffic-eng tunnel-tp 1 encap cv-non-ip

Tracing MPLS TP Label Switched Path on tunnel-tp1, timeout is 2 seconds

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
        'L' - labeled output interface, 'B' - unlabeled output interface,
        'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
        'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
        'P' - no rx intf label prot, 'p' - premature termination of LSP,
        'R' - transit router, 'I' - unknown upstream index,
        'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

 0 Node ID 10.10.10.1, Global ID 0 MRU 1500 [Labels: 1000 Exp: 0]
    Ingress Link ID 0, Egress Link ID 1
L 1 Node ID 10.10.10.2, Global ID 0 MRU 1500 [Labels: 1100 Exp: 0] 3 ms
```

```
tracroute mpls traffic-eng tunnel-tp
```

```
Ingress Link ID 2, Egress Link ID 3  
! 2 Node ID 12.12.12.3, Global ID 0 4 ms
```