

Configuration VPN de base sur RV130 et RV130W

Objectif

Un réseau privé virtuel (VPN) est souvent utilisé par les entreprises comme moyen d'étendre les intranets du réseau d'entreprise, qui sont des sites conçus pour être utilisés uniquement par les employés de l'entreprise. Un VPN est un réseau privé construit dans une infrastructure de réseau public. Dans un environnement de petite entreprise typique, les réseaux privés virtuels peuvent étendre la connectivité géographique, réduire les coûts d'exploitation par rapport aux réseaux étendus (WAN) traditionnels et améliorer la productivité dans le workflow des employés.

La page Basic VPN Setup vous permet de configurer facilement un tunnel VPN passerelle à passerelle avec d'autres périphériques de passerelle. Le tunnel VPN permet également aux utilisateurs distants d'accéder au réseau local (LAN) de votre routeur à l'aide du logiciel client VPN.

Note: Les modèles RV130 et RV130W prennent en charge les logiciels VPN IPSec tiers. Pour plus d'informations, reportez-vous au guide d'administration du produit.

L'objectif de ce document est d'expliquer comment configurer le VPN de base sur des périphériques RV130.

Périphériques pertinents | Version du micrologiciel

- RV130 | V 1.0.3.28 ([Télécharger la dernière version](#))
- RV130W | V 1.0.3.28 ([Télécharger la dernière version](#))

Afficher les paramètres VPN par défaut

Étape 1. Utilisez l'utilitaire de configuration du routeur pour choisir **VPN > Site-to-Site IPSec VPN > Basic VPN Setup**. La page *Basic VPN Setup* s'ouvre :

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Save](#)

[Cancel](#)

Étape 2. Cliquez sur le bouton **View Default Settings** pour voir les valeurs par défaut définies par Basic VPN.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Save

Cancel

La page *Basic VPN Setup* affiche les paramètres par défaut :

Basic VPN Setup

Basic VPN Setup Default Values for IKE

Exchange Mode:	Main
Local WAN (Internet) ID:	Local WAN (Internet) IP Address
Remote WAN (Internet) ID:	Remote WAN (Internet) IP Address
Encryption Algorithm:	AES-128
Authentication Algorithm:	MD5
Authentication Method:	Pre-Shared Key
Diffie-Hellman (DH) Group:	Group2 (1024 bit)
SA-Lifetime:	8 Hours

Basic VPN Setup Default Values for VPN

Encryption Algorithm:	AES-128
Integrity Algorithm:	MD5
SA-Lifetime:	1 Hours
PFS Key Group:	Group 2(1024 bit)

Back

Étape 3. Cliquez sur le bouton **Back** pour revenir à la fenêtre *Basic VPN Setup*.

Basic VPN Setup

Basic VPN Setup Default Values for IKE

Exchange Mode:	Main
Local WAN (Internet) ID:	Local WAN (Internet) IP Address
Remote WAN (Internet) ID:	Remote WAN (Internet) IP Address
Encryption Algorithm:	AES-128
Authentication Algorithm:	MD5
Authentication Method:	Pre-Shared Key
Diffie-Hellman (DH) Group:	Group2 (1024 bit)
SA-Lifetime:	8 Hours

Basic VPN Setup Default Values for VPN

Encryption Algorithm:	AES-128
Integrity Algorithm:	MD5
SA-Lifetime:	1 Hours
PFS Key Group:	Group 2(1024 bit)

Back

Configuration VPN de base

Étape 1. Utilisez l'utilitaire de configuration du routeur pour choisir **VPN > Site-to-Site IPSec VPN > Basic VPN Setup**. La page *Basic VPN Setup* s'ouvre :

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint: ▼

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Save](#) [Cancel](#)

Étape 2. Entrez un nom de connexion dans le champ *Nouveau nom de connexion*. Ce nom sera utilisé à des fins de gestion et n'a aucun impact sur le fonctionnement du VPN.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

cisco_sb

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

IP Address ▾

Remote WAN (Internet) IP Address:

(Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address:

(Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask:

(Hint: 255.255.255.0)

Local LAN (Local Network) IP Address:

(Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask:

(Hint: 255.255.255.0)

[Save](#)

[Cancel](#)

Étape 3. Entrez une clé pré-partagée dans le champ *Pre-Shared Key (Clé pré-partagée)*. Cette clé est requise par un client ou un modem routeur VPN pour établir une connexion VPN.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Save](#)

[Cancel](#)

Étape 4. Dans la liste déroulante *Remote Endpoint*, sélectionnez **IP Address** ou **FQDN** pour le type d'adresse que la passerelle distante utilisera pour établir une connexion.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Save](#)

[Cancel](#)

Les options disponibles sont définies comme suit :

- Adresse IP : chaîne unique de nombres séparés par des points qui identifie chaque machine utilisant le protocole Internet pour communiquer sur un réseau.
- FQDN (Fully Qualified Domain Name) : nom de domaine complet pour Internet, un ordinateur spécifique ou un hôte spécifique. Le FQDN se compose de deux parties : le nom d'hôte et le nom de domaine. Par exemple, un nom de domaine complet pour un serveur de messagerie hypothétique peut être *mymail.companyname.org*. Le nom d'hôte est *mymail*, et l'hôte est situé dans le domaine *companyname.org*.

Étape 5. Entrez l'adresse IP ou le nom de domaine complet, selon votre sélection à l'étape 4, dans le champ *Remote WAN (Internet) IP Address*.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Save](#)

[Cancel](#)

Étape 6. Entrez l'adresse IP et le masque de sous-réseau du réseau local distant dans les champs *Remote LAN (Local Network) IP Address* et *Remote LAN (Local Network) Subnet Mask*.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Save](#)

[Cancel](#)

Étape 7. Entrez votre adresse IP et le masque de sous-réseau du réseau local dans les champs *Local LAN (Local Network) IP Address* et *Local LAN (Local Network) Subnet Mask*.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Save](#)

[Cancel](#)

Étape 8. Cliquez sur **Save** pour enregistrer les paramètres.

Basic VPN Setup

About Basic VPN Setup

The basic VPN setup sets most parameters to defaults as proposed by the VPN Consortium (VPNC), and assumes a Pre-shared Key, which greatly simplifies setup. After creating the policies through the Basic VPN Setup, you can always update the parameters through the Policies menu

[View Default Settings](#)

Connection Name and Remote IP Type

New Connection Name:

Pre-Shared Key:

Endpoint Information

Remote Endpoint:

Remote WAN (Internet) IP Address: (Hint: 1.2.3.4 or abc.com)

Secure Connection Remote Accessibility

Remote LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Remote LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

Local LAN (Local Network) IP Address: (Hint: 1.2.3.4)

Local LAN (Local Network) Subnet Mask: (Hint: 255.255.255.0)

[Voir une vidéo liée à cet article...](#)

[Cliquez ici pour afficher d'autres présentations techniques de Cisco](#)

À propos de cette traduction

Cisco a traduit ce document en traduction automatisée vérifiée par une personne dans le cadre d'un service mondial permettant à nos utilisateurs d'obtenir le contenu d'assistance dans leur propre langue.

Il convient cependant de noter que même la meilleure traduction automatisée ne sera pas aussi précise que celle fournie par un traducteur professionnel.