

Ative uma linha no adaptador de telefone série SPA100

Objetivo

Quando a linha está ativada, os serviços de voz podem ser estabelecidos através das linhas para as respectivas portas de telefone. Este artigo explica como habilitar linhas diferentes no Adaptador de telefone analógico SPA100 Series, para que dois usuários possam se comunicar diretamente (por exemplo, Gerenciador geral para Gerente de conta).

Dispositivo aplicável

SPA112
SPA122

Versão de software

•1.1.0

Habilitar linha

Etapa 1. Efetue login no Phone Adapter Configuration Utility e escolha **Voice > Line1** ou **Line2**. A página *Linha 1* é aberta:

The screenshot shows the 'Line 1' configuration page. The 'General' section is highlighted with a red box. The 'Line Enable' dropdown is set to 'no'. Other sections include Streaming Audio Server (SAS), NAT Settings, Network Settings, and SIP Settings, each with various configuration options and dropdown menus.

| Section | Parameter | Value |
|------------------------------|--------------------------|----------|
| General | Line Enable | no |
| | SAS DLG Refresh Intvl | 30 |
| Streaming Audio Server (SAS) | SAS Enable | no |
| | SAS Inbound RTP Sink | |
| NAT Settings | NAT Mapping Enable | no |
| | NAT Keep Alive Msg | \$NOTIFY |
| | NAT Keep Alive Enable | no |
| | NAT Keep Alive Dest | \$PROXY |
| Network Settings | SIP ToS/DiffServ Value | 0x68 |
| | RTP ToS/DiffServ Value | 0xb8 |
| | Network Jitter Level | high |
| | SIP CoS Value | 3 [0-7] |
| SIP Settings | RTP CoS Value | 6 [0-7] |
| | Jitter Buffer Adjustment | yes |
| | SIP Transport | UDP |
| | SIP Port | 5060 |
| | SIP 100REL Enable | no |
| | EXT SIP Port | |
| | Auth Resync-Reboot | yes |
| | SIP Proxy-Require | |
| | SIP Remote-Party-ID | yes |
| | SIP GUID | no |
| SIP Debug Option | none | |
| RTP Log Intvl | 0 | |
| Restrict Source IP | no | |
| Referor Bye Delay | 4 | |
| Referree Bye Delay | 0 | |

Note: As configurações para ativar a Linha 1 são aplicáveis à Linha 2.

The image shows a software interface window titled "Line 1". Inside the window, there is a section labeled "General". Under "General", there is a label "Line Enable:" followed by a dropdown menu. The dropdown menu currently displays the word "yes" and a downward-pointing arrow. A red circle is drawn around the dropdown menu. At the bottom of the window, there are three buttons: "Submit", "Cancel", and "Refresh".

Etapa 2. Escolha **sim** na lista suspensa Habilitar linha. Isso ativa a linha e todas as outras configurações podem ser feitas nessa linha.

Etapa 3. Clique em **Enviar** para salvar as configurações.